

EUT:MOUSE

FCC ID:FSUGMZFX

KYE SYSTEMS CORP.

USER'S MANUAL



NetScroll USB Mouse Installation Guide

Introduction

This mouse device with its innovative shape will give you better comfort, quality, and control over a long period of time. It has plug and play features and is very easy to install.

Installing USB mouse driver for Windows 95 OSR2

1. Insert the mouse driver diskette in to Drive A (or B).
2. Click on the **Start** button in the Windows 95 task bar, then select **Run**
3. Type A:\SETUP (or B:\SETUP) and click on OK
the USB supplement will automatic installation.
4. Follow on the on-screen messages to finish the installation procedures then the Windows will restart.
5. The system will detect the USB mouse when you plug in the mouse to PC system
and display a dialog box on screen. Please input "A:\\" in the box then mouse can work properly after installing driver.

Cleaning Your Mouse

You can protect your mouse by keeping your work area clean and free from dust.

Note: Make sure the system is off before you attempt to clean it

1. Remove the ball by turning the ball retainer counter-clockwise until it becomes loose.
2. Use a soft or non-abrasive cleaner to clean the ball and rollers. You can also use a cotton swab to clean the ball container.
3. Reinstall the ball and the ball retainer.