

PROHEAR®



EM030 BT SHOOTING EARMUFFS USER MANUAL

READ THIS BEFORE USING

EM030 Electronic Bluetooth Hearing Protector

- **Bluetooth Function:**

The earmuff has all Bluetooth connecting function, it can answer/reject/redial the call and listen to music etc.

- **Sound Amplification:**

The Electronic Bluetooth Earmuff amplify surrounding low level sounds such as footsteps, voices, warning signals to 82dB yet it provides good hearing protection.

- **Noise Reduction:**

The electronic circuit helps protect hearing from harmful loud sounds which is over 82dB by reducing the amplification of those sounds to a safe level.

- **Volume Control&Directional Sound:**

Ergonomics design volume control knob allows for total adjustment of the two built-in omni directional microphone.

- **MP3 connecting input Jack:**

3.5mm input jack that can listen to music, ipod etc **(Please don't forget to turn on the Bluetooth Sync Button when using it)**

Bluetooth Operation



- **Insert 2 AAA batteries**
- **Turn on the "1" knob to enable PROHEAR 030**
- **Turn on the "2" knob so that you can hear the sound of Bluetooth enable**
- **Bluetooth Pairing**
 - Long press and hold the BT button for 1 second to enter pairing mode after turn on. Blue Led will light on every 2 seconds.
 - Open Bluetooth wireless setting on your phone or other devices.
 - Make sure Bluetooth is on and select "EM030BT" to connect.
 - Auto re-connect to previous last connected device during pairing if the BT device has been paired previously.
 - After showing pairing success,the BT function can be used succeed.
 - Press and hold the BT button for 3 seconds to turn OFF the Bluetooth Pairing
- **How To Operate To Get Enough Volume**
 - Adjust the volume of your phone/other devices you paired to the highest level.
 - Turn the "1" knob to the lowest but don't turn it off.
 - Adjust the "2" knob to find your suitable volume.

- **Answer Call**

To answer the incoming call, short press the BT button.

- **Reject Call**

To reject the call, long Press the BT button.

- **Cancel/End call**

To cancel/end call, short press the BT button.

- **Call On Hold/Waiting**

-During phone calls, if another new call is received, double press the BT button to switch from the first call to second call.
-Short press the BT button to end the second call and switch to the first call.

- **Last Number Redial**

Quickdouble press the BT button to re-dial the last phone number.

- **Audio Pause/Play**

To pause/play music, short press the BT button.



**Scan Code to Choose
"PROHEAR 030"
to Watch Video!**

If Your Earmuff Whistle

Whistling (feedback) generally occurs if the volume level is set too high and if there is something such as a hand near or covering the external mics. Turn the volume level down or adjust the earmuff to fit the head or change the direction of wearing earmuff until the whistling stops.

PROHEAR EM030 FCC Statement BT NOTE

FCC ID: 2AYWU-EM030

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

PROHEAR®

LIMITED WARRANTY

PROHEAR, LLC warrants this product to the original purchaser to be free from defects in materials and workmanship, under normal use and conditions for a period of one-year parts from the date of purchase.

PROHEAR provides **1-YEAR-WARRANTY**. And we take customer satisfaction as our top priority. If you have any questions, suggestions, concerns, or issues, please feel free to contact us:

support@proheartac.com, Our friendly customer service team will respond within 24 hours.

KNOW MORE PROHEAR

Store Name: PROHEAR

Store Link: <https://amzn.to/2Np4hft>



Scan code to PROHEAR



Scan Code To Watch Video!

<https://bit.ly/3kA7rf5>