

Setting Up Your AM10B

Introduction

The first step is to download and install the APP SMARTTIME PRO indicated on the user manual and shown up on the watch. Enter the APP and create an account for info sync. The app allows you to check data analysis every day and to personalize some functionalities, such as setting sedentary, calls notification, exercise goals and so on. Connect AM10B to your smartphone

SMART-TIME PRO APP supports the operating system of IOS 12 and Android 5.1 or above, and BT 5.3&3.0. It is available for more than 150 mobile devices. 1. Turn on Bluetooth on the mobile:

- 2. Download APP: SMART-TIME PRO:





First step: Open APP>device>add new device> choose AM10B

3. How to pair the watch for iOS users:

4. In the search list, select the AM10B with the strongest signal and confi rm the pairing by clicking the pairing button on the watch screen as prompted by your phone in . The Bluetooth icon on the watch will be blue in color . indicating that you are connected to Bluetooth 5.3.

## \* Bluetooth 3.0 connection:

iPhone users support Bluetooth 5.3 + 3.0 dual Bluetooth one-key link ( (match according to the system prompts box Android users need to first time in the Bluetooth pairing

interface in the "call service pairing options" click "to bind" and then follow the interface operation prompts to complete the Bluetooth 5.3 + 3.0 pairing , subsequent links to the phone will be on the watch 3.0 Bluetooth memory, so as to achieve dual Bluetooth one-key link (if not automatically connected to Bluetooth 3.0, please manually search for Bluetooth watch model "AM10B" on the phone)



# Quick Fit Strap

AM10B contains two parts(watch body and wristband), you can purchase separately strap and switch as your preference.

# Charging Instructions

Turn the watch over, align the bottom of the watch with the charging dock, and the charging level indicator will appear on the watch screen within 5 seconds. It takes about 3 hours for the watch to be fully charged, and the battery icon on the screen will show a full state when it is fully charged. Before charging, please dry the watch first to avoid other risks caused by residual sweat.



\*To get the maximum charging current and magnetic attraction, please refer to photo 2 for the right charging angle (the charging dock is aligned with the center line of the button on the watch)

## Functions

## Change watch face

Long press the screen, swipe to choose, click to confirm. Download more from APP, Open APP---Device---Watch Face, you can choose Online Dial or Custom Dial with your phone







Walk



AM10B watch supports up to 100+ sports modes, fitness, leisure,

competition Classes, ball games, dance classes. including:

running, walking, treadmill, mountaineering, cycling, Spinning

bike, yoga, basketball, football, badminton and other sports.

AM10B watch supports sports customization, which can be

customized in more than 100 sports modes favorite sport.

Climbina

Football

Sports customization:APP "sports" - "custom" - "add" to

blood pressure or any other heart diseases. Please contact

3. AM10B smartwatch data such as heart rate, blood pressure,

etc. may not be completely accurate due to factors such as

interference with environmental signals, wearing posture,

changes in the climate environment, and physical condition.

monitoring data provided by AM10B, and should follow

4. DO NOT carry out drugs and treatment on the basis of the

medical advice when medication and treatment are required,

11

and we are not liable for the inaccuracy of monitoring data

and the consequences of misuse of monitoring data and

information

your physician for more professional diagnostic opinions.

jump to sports category page, click the sport name to add

Treadmill



Cvclina

Badminton Free movemen

Wearing AM10B correctly, not too tight or loose, make sure no green light leak, open the "Heart Rate" application in the watch application, automatically measure the heart rate after entering the application.

## Stress:

Heart rate:

After wearing the watch correctly, open the "stress" in the watch; check how much psychological pressure you are feeling.

# Activity:

After wearing the watch correctly, open the "step counting" in the watch; display the number of steps, calories, distance and other parameters of the day's exercise.

After wearing the watch correctly, open the "SpO2" in the watch: manual blood oxygen measurement is required.

## Sleep:

After wearing the watch correctly, open the "Sleep" in the watch; record the sleep status throughout the night.

Open the "Music" app in the watch app; you can control the music playback of your phone, and support operations such as previous track, play/pause, next track, and volume adjustment.

## World clock:

APP "Device" - "World Time" - "Add", you can Scroll down to select or click the search icon at the top right to enter a region name Search to add.

APP "Device" - "Stock Market" - "Add" jump

searchpage, click the search icon at the top

right to enter the stock name to searchAdd to.

### Camera:

Stock market:

Control the camera on the mobile phone to take pictures remotely. When using it, please click "Device-Take Picture" on the APP to turn on the camera.

## Blood pressure:

Wear the watch in a right way, and open the menu--blood pressure, measure it manual.

Please open your mobile phone Alipay 10.0 and above, scan the QR code of the watch, complete the binding and follow the watch prompts Just carry out the operation.

### Breathing exercises:

In the menu bar click on "breathing exercises" and, depending on your needs, Select different



The AM10B smart watch supports Bluetooth calls, and users can make, answer, and reject calls directly on the watch.

**User Manual** 

Version1.1

You can view the text messages in the mobile phone and the real-time information pushed to the watch

## Find phone:

When the watch is connected to the APP, the phone will make a sound after tapping it.

# Anti-lost reminder:

When the watch is disconnected from the Bluetooth of the mobile phone, the watch will make a sound and vibrate to prevent loss.



# fun to your healthy life

Relaxed, easy-to-use small game, bring



Turn on the watch calculator function, make calculations more convenient and simpler



8 9

## Calendar

View dates faster and plan ahead



•	Stopwatch:
	Electronic timer
•	can record one
•	time or record
,	annual Albanda Albanda a



The same way to calculate the remaining time



forecast




Set the alarms in APP and sync to watch, maximum 5 alarms



## Shortcut menu:

1. The screen is often on 2. Raising the screen on the screen 3. Flashlight 4. Exemptation 5. Brightness adjustment 6. Setting 7.BT3.0 switch



- 12. Password 13. Flight mode 14. Calendar

# Specification

Walstband length	266mm
Walstband width	22mm
V⊯ight	55.1 g
Battery	260 mAh Poly-Li
\#aterproof	IP67

# Troubleshooting

## Heart-rate signal missing

The AM10B smart watch keeps paying attention to your heart rate data during your exercise and your daily life. Sometime the watch may not get a suitable heart rate signal. At this time, the missing heart rate data will appear at the dotted

If you can't get the heart rate signal, first you should confirm that you wear the watch correctly, adjust it to avoid being too high or too low, neither too tight nor too loose on your wrist. After adjustment, turn on real-time heart rate monitoring to get the data.

If there is still no heart rate data, check if the heart rate monitoring function is turned on at SMART-TIME PRO APP.

## Other problems

If your mobile cannot pair the watch, click Settings Bluetooth in your mobile and check if there is signal of AM10B. If yes, it means there is no problem with the Bluetooth signal. Please check if the watch is paired with other phones, please unbind it. IOS device users should click Setting - Bluetooth - ignore this device and then pair it.

# **Exemption Clause**

- 1.The Heart Rate, Pressure, Blood Oxygen and Blood Pressure data output by AM10B are not intended to be a medical or diagnostic basis.
- 2. Self-diagnosis and self-treatment are dangerous. Only qualified physicians are allowed to diagnose and treat high 10

# **FCC** Warnning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection againstharmful interference in a residential installation. This equipment generates, uses and can radiateradio frequency energy and, if not installed and usedin accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee thatinterference will not occur in a particular installation. If this equipment does cause harmfulinterference to radio or television reception, which can be determined by turning the equipmentoff and on,the user is encouraged to try to corect the interference by one or more of thefollowing measures: ·Reorient or relocate the receiving antenna. ·Increase the separation between the equipment and receiver.

·Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. ·Consult the dealer or an experienced radio/TV technician for

Caution: Any changesor modifications to this devicenot explicitly approvedby manufacturer could void your authority to operate

this equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1)This device may not cause harmful interference, and (2) this device must accept anvinterference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.

# Warranty Clause

Our company always pursues the service concept of "creating value for customers"

We offer 1 year warranty period for AM10B smart watch. If there is any damage or malfunction during normal use, the warranty service will be provided to the customer for free after confirmation by our technician. The following conditions are not covered by the warranty:

A. Accident or human damage

B. Testing, repairing or disassembling without authorization

C. Contamination due to human reasons D. Damage caused by connection with equipment which is

not compatible E. Natural aging

F. Damage caused by Force majeure





13





