

← Use the soother

The projection light is located on the top of the soother. Use MyVTech

Soother App to turn on and select a light color to soothe your little baby.

Ę

C)

-SAR-

📭 🗰 Magic Key

Several functions can be performed using Magic key Start or stop the soother

• When inactive, tap Magic key **prime** to start and resume the Soother to its previous settings. When active, tap Magic key to stop the soother.

Change your favorite mode

Tap Magic key minimum twice to go to the next favorite mode.

Adjust the night light brightness With the night light the souther can illuminate a soft hue to calm your baby in a dark room. You can control the brightness level of its glow directly on the soother and adjust the night light color remotely in **MyVTech Soother App**.

Tap and hold Magic key III III to adjust the night light's brightness level.

CABLE MANAGEMENT



NEED HELP?

~

× Audio streaming from your mobile device

Press and hold the Bluetooth pairing key () for 5 seconds to enter Bluetooth

Place you mobile device next to the soother during the whole pairing process.

After the soother enters Bluetooth pairing mode, the soother will keep fading in and out blue light until it is connected to a device.

Set your mobile device to discoverable mode before pairing.

Select "V-Hush Mini" under the device list.

_

____^

* ……

Þ...., 🛞

The soother is able to function as a Bluetooth speaker after pairing with a mobile device via Bluetooth so you can play your own music from your mobile device through the soother.

Connect your device with the soother via

superson autor To use a Bluetooth enabled mobile device with your soother, you must first pair and connect your Bluetooth mobile device with the soother. Before you begin, make sure that your Bluetooth enabled mobile device is not connected to any other Bluetooth device.

Bluetooth audio

On the soother

On your device

NOTE



FCC AND IC REGULATIONS FCC Part 15

FCCPH13 be separate that also been stricted and found to comply with the requirements for a Case 8 digital device under managements of the separate that the separate term of the separate term of the separate management of the separate term of the separate term of the separate term of the separate performance of the separate term of the separate term of the separate term of the performance term of the separate term of the separate term of the separate performance term of the separate term of the separate term of the separate performance term of the separate term of the separate term of the separate performance term of the separate term of the separat

ore of the following measures: int or relocate the receiving antenna. In the senaration between the equipment and receiver

Increase the separation between the equipment and receiver.
 Connect the explainment into an outer of a circuit different from that to which the receiver is connected.
 Consult the dealer or an experienced radio/TV technician for help.
 WARNING: Changes or modifications to this equipment not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

his device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device hav not cause harmful interference, and (2) this device must access that must have received. Including interference may not cause hamful interference, and (2) this davice must accept any interference inclived, including interference that may cause underted operation. To ensure addry of users, the FCC has established criteria for the amount of nation frequency energy that can be addly absorbed by a user or bystrader according to the interfed caused of the product. The beat netted and found in comply with the FCC criteria. The isomer shall be initialed and used such that parts of all person's body are matimated at a distance of approximately b in 20 m of m cortics. The somer for addly are matimated at a distance of approximately b in 20 m of more.

This Class B digital apparatus compiles with Canadian requirement: CAN ICES-3 (B)/NMB-3(B)

Industry Canada The dovice contraints (bence-evenget transmission)/received() that comply with innovation. Science and Economic the dovice contraints (bence-evenget transmission)/received() that comply with innovation. Science and Economic may not cause innerference. (2) This dovice must accept any interference, including interference that may cause understeined operation of the dovice. The term C⁺ Lakes the accent that interference in the term of significe that the industry Canada technical the product meet the applicable involved. Science and Economic Development Canada technical specifications

The product mean in equipations minorande, some an excerning control in excerning appointance **RF radiation exposes statement** The control excerning is a product on the statement of the statement of the statement of the control in handlo be installed and operated with a mainten datase of a flor of the between the control and all periodic body. Use of their accession environment of the statement of the statement of the statement of the statement body. Use of their accession environment of the statement of the statement of the statement of the statement Fields.

LIMITED WARRANTY

Whence the initial of a result of the second second

During the limited warranty period, VTech's authorized service representative will replace at VTech's option, without charge, a Materially Defective Product. If we choose to replace the Product, we may replace it with a

without charge, a fasteriary barective Hobuct. It we choose to repued the Product, we may repeate it was new circlettrafished Product of the same or similar design. We will relate defaulte parts, module, or equipment Replacement of the Product at VTach's option, it your exclusive remedy. VTach' will relate defaulte parts, module, or equipment to you'n working condition. You should appet the replacement to take approximately 30 days. How long is the limited warranty period?

How long is the limited warranty period? The limited warranty period for the Product oreands for CNR (1) YEAR from the date of purchase (PG days on product purchased as Refurbiched?). This limited warranty also applies to the replacement Product for a period or beint (a) 90 days from the date the replacement Product to Happed Is you or (b) the time remaining on the original one-year warranty (PO day limited warranty or product that are purchased as Refurbiched?), whichever is longer "Body biotic days are under the regiment of the original or the original days are also been as the also been as the original days are also been are also been as the original days are also

"Refurbished products purchased from our online store carry a 90-day replacement warranty. What is not covered by this limited warranty? This limited warranty does not cover:

The immediate watering does not cover. In order that has been subjected to misuse, accident, thipping or other physical damage, improper installation, abnormal operation or handling, neglect, invasitation, fire, water or other liquid intrusion; or Product that has been damaged due to repair, alteration or modification by anyone other than an authorized service representative of VTed; or an end hypersements or VTRCP; Or 3. Product to the extent that the problem experienced is caused by signal conditions, network reliability, or cable or antenna systems; or

Product to the extent that the problem is caused by use with non-VTech accessories; or

Product whose warranty/quality stickers, product serial number plates or electronic serial numbers have been
removed, altered or rendered illeoible: or

6. Product purchased, used, serviced, or hipped for repair from outside the United States of America or Chanda, or used for commercial or institutional purposes; forciding but not limited to Product used for remain purposes; or 7. Product returned without a valid proof of purchase (see item 2 below) or 8. Charges for institution or set us, adjument of o customer controls, and institution or repair of systems outside the set of the se

How do you get warranty service?

ty service in Canada, go to www.vtechcanada.com or call 1 (800) 267-7377. NOTE: Before call of controls and features manual - a check of the Product's controls and features ma save you a service call.

save you's service cat. Except at provide by applicable law, you assume the risk of loss or damage during transmistant and preportation and a table to the service of the will rotation replaced Product under this limited warranty. Transportation, delivery or handling charges are prepaid. Viter harms into in risk of damage or loss of the Product In transf. What must you return with the Product to get warranty service?

. Return the entire original package and contents including the Product to the VTech service location along with a description of the malfunction or difficulty, and

Include a "valid proof of purchase" (rales receipt) identifying the Product purchased (Product model) and the date of purchase or receipt; and

Provide your name, complete and correct mailing address, and telephone number.

Other limitations This warranty is the co

The start of the complete and exclusive agreement between you and VFach. It supersides all other written or inclusion related to this Product. U Yeah provides no other warranties for this Product. The warranty exclusion all of VIAch's regordbline seguriting the Product. There are not warrantees that the loss of the inclusion relation of the Product and the start of the Product There are not warrantees the loss of all Law Rights. This warranty gives you specific tegal rights, and you may also have other rights, which way to a table to provide to provide.

summaries to grade approximate the principles. If the end principle table table to grade approximate the principle section of the principle sectio

ain your original sales receipt as proof of purchase

(II) Intertek



