

# DT Research Rugged Tablet



## BASIC OPERATION GUIDE

# DT300Q

### INTRODUCTION

Thank you for acquiring the DT300Q, part of DT Research's line of tablets. Featuring a slim yet robust enclosure, the DT300Q with 8" TFT display is powered by the Intel® Atom™ quad-core or Qualcomm octa-core processor, offering optimal combinations of performance and power savings. The DT300Q is available with Microsoft® Windows® or Android operating system. The software operating system features web browser, client/ server computing software, media player, accessories, and applications support.

### PACKAGE CONTENTS

- One DT300Q with Battery Pack and Handstrap
- AC-DC Power Adapter with Power Cord
- Basic Operation Guide

\* If your DT300Q contains camera or barcode scanner, please refer to the Tablet Modules Basic Operation Guide for detailed operation.

DT300Q:



Input/ Output Ports

A	Headphone Jack
B	USB Port
C	DC Power Input
D	Back Camera (optional on DT380CR)
E	Barcode Scanner (optional)

Button Functions

BUTTON	ACTION
1	power button
2	Programmable Button without the scanner module As Scanner Trigger when equipped with the scanner module
3	Battery Latch

## Power/Battery LED Status:

- Blue indicates the battery is 25% to 100% charged
- Blinking blue indicates the battery is charging
- Orange indicates that the battery is between 11% to 25%
- Blinking Orange indicates that the battery is below 10%

## PRECAUTIONS

- Always exercise care when operating and handling the DT300Q.
- Do NOT apply excessive pressure to the display screen.
- Avoid prolonged exposure of the display panel to any strong heat source. Wherever possible, the DT300Q should face away from direct light to reduce glare.
- If the AC-DC power adapter is used to recharge or power the tablet, do NOT use any AC-DC adapter other than the one provided or acquired from the manufacturer or its partners.
- In the unlikely event that smoke, abnormal noise, or strange odor is present, immediately power off the DT300Q and disconnect all power sources. Report the problem to your device provider immediately.
- Never attempt to disassemble the DT300Q, as this will void the warranty.

## BASIC FEATURES

The DT380CR/ DT380Q wireless tablet integrates a bright and multi-touch display, one USB port, and embedded networking elements such as wireless LAN and Bluetooth. The DT300Q is complemented by a suite of accessories, including battery gang charger, and charging cradles, for a comprehensive user experience.

A DT300Q typically integrates an 802.11ac wireless LAN (WLAN) adapter that may connect to other wireless devices or access points. If your DT300Q does not come with such a network adapter, please consult your device provider to establish the desired network connectivity.

# OPERATION

## Powering ON and OFF

To activate the DT300Q, push and quickly release the Power Button. The display will come on in a few seconds. To put the DT300Q in Standby mode, push and quickly release the Power Button. To turn the DT300Q off for extended storage, power off safely using any software function that “shuts down computer” provided in the software operating system.

### NOTE:

The battery pack shipped with your tablet may be low in power—please use the AC-DC adapter with the DT300Q when setting up for the first time to fully charge the battery pack.

### NOTE:

When the battery pack is charging, the blue-colored Battery LED should blink slowly. If plugging in the AC-DC adapter does not trigger this blinking activity and the LED stays dark, the battery pack(s) may have been drained substantially. Try unplugging/ replugging the AC-DC adapter to the DT300Q a few times to activate the charging process.

### NOTE:

To conserve power, use (push and quick release) the Power Button to put the tablet in “Standby” mode while not in use. Pushing briefly on the same button will wake up the system within seconds.

### NOTE:

For DT380CR, avoid using the Power Button (“hold 4+ seconds” feature) to turn off the tablet—this form of hardware shutdown is intended to be a means of recovery from lockups, and not as normal operation.

## Start Up

If the power up (from Standby mode or otherwise) is successful, the appropriate interface will be displayed after a launch sequence of several seconds. The wireless LAN connection may take 10-15 seconds to be established.

## Configuring the Mobile Tablet

The DT300Q may be configured using the utilities and methods dictated by the software operating system. The DT300Q should be configurable for various properties such as user profiles, network features, and several system elements.

## Wireless Networking

### Wireless LAN

The DT300Q is often delivered with an embedded (user-inaccessible) 802.11ac WLAN adapter equipped with a hidden custom antenna.

- Through the support of typical WLAN adapters, the DT300Q should be able to detect all 802.11 access points in the vicinity for you to select the access point of your choice for connection.
- The SSID and WEP/WPA/WPA2 (if enabled) parameters on the DT300Q and the access points have to match. The SSID is case-sensitive and it is recommended that you enable WEP/WPA/WPA2 encryption (or advanced alternatives) for secure access.
- When WEP/WPA/WPA2 is enabled, you may need to consult your network administrator or your networking equipment literature to properly configure associated settings such as Authentication mode, etc.
- Refer to the access point operating manuals for setting up the 802.11 access points.

## Bluetooth

The Bluetooth configuration application is enabled from the Windows System Tray or from the Android Settings APP. Follow the instructions and options provided within the application to configure and invoke Bluetooth connectivity with the corresponding peripherals.

# USING THE MOBILE TABLET

## Peripherals Support

Through its USB port, the DT300Q supports a wide range of USB-based peripherals. These peripherals are applicable for software installation, applications storage, data storage, and system software recovery and updates.

## For More Support

Users can download the Tablet Modules Basic Operation Guides from the DT Research website.



### To Hold the Tablet

Left hand: grip the left back side of the tablet with your left hand four index fingers, with thumb resting on the top of the back side of the tablet and palm securely against the back.

Right hand: grip the right back side of the tablet with your right hand four index fingers, with thumb resting on the top of the back side of the tablet and palm securely against the back.

## Specifications:

	DT300Q	DT380CR
<b>System</b>		
CPU	Qualcomm Octa-Core, 2.0GHz	Intel® Atom™ Quad Core, 1.44GHz (up to 1.92GHz)
RAM	4GB	4GB
Storage	64GB flash	128GB flash
Operating System	Android 9.0	Microsoft® Windows® 10 IoT Enterprise
Display	8" LED-backlight, high-brightness (850 nits) capacitive touch screen	
Display Resolution	1920 x 1200	1920 x 1200
Network Interface	Wi-Fi 802.11ac, 2.4GHz/ 5GHz dual band; Bluetooth 4.2 LE	
Fan/ Fanless	Fanless	Fanless
Control Switch and Buttons	1 power button and 1 trigger buttons	1 power button and 1 trigger buttons
Speaker	Built-in Speaker	Built-in Speaker
<b>I/O Ports</b>		
USB port	1 (USB 3.0)	1 (USB 3.0)
Audio Jack	1 (3.5mm)	1 (3.5mm)
DC-in	1	1
SD Slot	1 micro SD card slot	1 micro SD card slot
<b>Mechanical</b>		
AC/DC Adapter	<b>Input:</b> 100 – 240V AC; <b>Output:</b> 12V DC, 5A	<b>Input:</b> 100 – 240V AC; <b>Output:</b> 12V DC, 5A
Battery Pack	Hot swappable battery, 3.7V, 8800mAh	Hot swappable battery, 3.7V, 8800mAh
Enclosure	ABS + PC plastics and magnesium-aluminum alloy	
Dimensions (H x W x D)	5.7 x 8.3 x 0.8 in/ 145.4 x 210 x 20.4 mm	5.7 x 8.3 x 0.8 in/ 145.4 x 210 x 20.4 mm
Weight	1.99 lbs/ 900 g	1.99 lbs/ 900 g
<b>Environmental</b>		
Operating Temperature	<b>Operation:</b> 32°F to 122°F (-0°C to 50°C); <b>Storage:</b> -4°F to 140°F (-20°C to 60°C)	
Humidity	0% – 90% non-condensing	0% – 90% non-condensing

### FCC Regulatory Compliance

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

### RF Exposure Compliance

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

The device has been tested for use against the body with 0mm separation in Specific Absorption Rate (SAR) testing.

User must follow the specific operating instructions for satisfying RF exposure compliance.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

### Supplier's Declaration of Conformity

#### 47 CFR § 2.1077 Compliance Information

Unique Identifier Trade Name:  , Model No.: SC600TA

#### Responsible Party – U.S. Contact Information

##### **DT Research, Inc.**

2000 Concourse Drive, San Jose, CA 95131

<http://www.dtresearch.com>

#### FCC Compliance Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.



#### **DT Research, Inc.**

2000 Concourse Drive, San Jose, CA 95131 <http://www.dtresearch.com>

Copyright © 2020, DT Research, Inc. All Rights Reserved.