

USER MANUAL

SC-5514WNB





I Precautions before use

- · Avoid obstruction of the air inlet and outlet.
- The power indicator on the keyboard will remain lit after the power is turned on.
- The system will start up when it is used for the first time. Do not force power off to avoid data loss or damage to the system.



Descriptions

Precautions

Please follow the following safety precautions when using your device.

Do not use power cords, damaged plugs or loose plugs. Do not bend or damage the power cord. Do not touch the power cord with wet hands or pull the cord to disconnect the charger.

Do not use the device while it is charging or touch it with wet hands .

Do not hit or drop the charger and do not charge the battery with chargers that are not approved by the manufacturer.

Do not use your device during an electrical storm. Handle and discard batteries and chargers with care

Do not handle damaged lithium ion batteries or that show leakage .

Do not use the device near a pacemaker. If possible, avoid using it at a distance inferior to 15 cm, because the device can interfere with the pacemaker.

Do not use the device in a hospital or near medical equipment that can be interfered by radio frequency.

If you use medical equipment always make sure they are protected against radio frequencies. If you use a hearing aid, let the manufacturer know to obtain further information about interference.

In potentially explosive environments , turn off the device .

Always respect the rules, instructions and warning signs

Do not use the device in or near other annable chemicals refueling points service stations) and / or explosives

Do noflstore or transport ammable liquids, gases or explosive materials in the same compartment as the device, its parts or accessories

If you want to charge the device, you must install an easily accessible power outlet.

The images in this manual are only for information purposes and may differ from the actual product.

The charging time is about 3 hours, and the battery life is about 5 hours for daily use.

For more information, visit http://www.supersonicinc.com/

II. Introduction to Desktop

1. Windows 11 Startup Menu: On the start screen, you can see many application programs you can select the programs you need to open.

You will need to log on to your Microsoft account for some application program to completely run.



2. Introduction to app Interface

Besides the application programs already fixed on the start screen, you can also add and start other software application programs.



If you want to fix more application programs on the start interface, see the operation in the figure below, (1) Right click the properties icon (2) Select " pin to start".



Conversely, if you want to cancel or delete a certain application in the start screen, (1) Right click the properties icon (2) Select " Unpin from start".



4. Search menu

Use the External Keyboard connected to your device and Type on the Search box for Apps, Settings, Documents, photos, Music, WEB, etc...

A Bertine and the	-		
Summer .	Tel martin		1.00
O termine	Annal State	berning.	
C	Report Conne	Residence Instanton	
0 =	Interating Association		
Bernet	Name -		
Op heavy her	-		
D Incide and	and the second		
	-	-	
2 hoursening	19	9	16
a ratio		1010	00.0
3			
-			
The second second second			-

III. Basic Operations

1. Sleep, restart ,power on and power off

On the start screen you can find power options, select 'Sleep' then your tablet will sleep; select 'Shut down' then your tablet will power off; select 'Restart' then your tablet will reboot.



Other way to power on/off:

When your tablet is on,hold the power button for $3\sim4$ seconds, then slide to shutdown; when your tablet if off ,hold the power button for $1\sim2$ seconds, it will power on.



2. Bluetooth connect



to open the Bluetooth. Click the



then click "Settings"; enter to the setting interface, then click

Bluetooth & devices

to search other devices.



9



3. WIFI Connect

Click the to open the Wi-Fi, and then choose the Wi-Fi you need to connect, enter the password.

n an ඟ Nam
Constantiation
 9= 9=-
 - 6 - 200 -

4. Display Brightness and Power management Display brightness:

There are two ways to change brightness.

A. Click icon on the taskbar and click the sun icon to switch the brightness.

· ·		*
	-	-81
a	_	
9 m		/ 8

B. Settings>System>Display>Brightness

+ ===	Spiner / Dialog	
	+ 100	
-	+ mm	-+1-
1-		
1	* 2010	-
8	*	

Power and Battery management:

Settings>system>Power & battery

4 == -	Server - Prese & Selfary	- 0
	42% K)	kunum
	1	-
	1	1
·	-	

5. Add an account

Add a location account:

Settings>Accounts>Other users Click "Add account" at "Add other user"

2.000			1.00
4	Accounts + Other	Users	
	T (method		
	1.000		
	a		

If this account is for a chief followerff account. Other pr	a harrager receive	which the Back and a string to which a biling	erating + colf eccentric
If you want to use a patient	el. Cloude samellos	egen of that will be easy for	pine foi contractidané
but baid for pillers to gene		1992 (1996) 1997 - 1997 (1997)	
What is going to use this PC	12		
Dier same		-	
Maké Ki sebijesi			
been parents			
Notice parameters			

Add a Microsoft account:

Settings>Accounts>Email & accounts Click "Add a Microsoft account" and fill in a Microsoft account following the guild.

2.004		- * *
8 mm	According + Ernal & accounts	
·	A comparison of the second second second	
1		
	The second second	
a summary and		
	Minute 101101	sting monoment
2 marsh		
A sum	A. an anno	
a presente		
and the second		
E hearth		
P Tatlant		
· · · · · · · · · ·		
	1 · b - 0 0 · ··	- 0.000 H
Hend	tainet	
	EP Internet	
	Sign in	
	had more at these	
	And the second s	
	No a cost time-an	
	The second second sec 12	
	Sq. Springton	
	and the second se	(d)

6. Adjust the date and time Date and time:

Settings>Time&Language>Date&time

"Set time automatically" option is on by default. The time will be set automatically when Internet is connected via wifi.

You can change the time zone through "time zone" option.

0.00	Time & Tempurger Data & time	2.8/8
francis à	Company prime	
		-
	tion over any discountry.	- 60
# .m.	\$ 1000	
9 Linklagen		
a news	Transaction of the local division of the loc	
P malanta	and a second sec	
	The Rest Management of Concession of	
	The structure of the structure of	And the second second of the

If you need to set the time by yourself, please turn off "Set time automatically" option and the "change" option will be active.

Change date and time	
Date:	
JANY → 10 → 2011 →	
Brig.	
10 · · 34 · · 74 ·	
	Dange Canad

Region:

Settings>Time&Language> Language&Region



7. Camera

On the start screen , get into 'All apps' and click 'Camera'



	(Take Statem	
	and the second second	
4	Eater Photos	
*		
		1.11.0.14. 100

8. HDMI Connect

Connect the tablet and Display device by MINI HDMI cable, set up the project options following the guide.

Tips: You can also open the project option by pressing 'Win+P'on the keyboard.

Display device and HDMI cable need to be purchased separately.







9. Reset the PC

Settings>system>Recovery

Click "Reset PC" and select one option you want. Then follow the guilding steps to reset this PC.

- mm 1		
8.2	System - Recourty	
	Concerning where the solid is not interesting on the specific	
and the second state	a home more than 1	
1 (mail)	and the second s	
	Second Se	
B Theory is not	a manuf	Local de la companya
1	*	and the second second
#		
A rear		
	8 mm	
0.772	& Section	
and and set		
TRUE IN A PL		
Choose a Respony fil Semantic au	m option m m and settings, hel keeps year personal files. systemy	
Junuar al	of your principal films apply and writings.	
and the second s	Record and the contract of the second	





10. Troubleshoot

You can find almost troubleshoot tips in Settings>system>Troubleshoot

1 mm		
	System a http://www.accounter.com	
	· ·	1
	o man	F
	d Tallana	
	0	· · · · ·
	=	4
	# <u>******</u>	F.
	W Television and the second se	E.
	B THE CONTRACTOR	
	×==	
	A here	1
	# Televisia	

Item	SC-5514WNB
Display	1920x1080 IPS
OS	Windows 11
Built-in keyboard	Built-in keyboard USB or bluetooth Keyboard
	and mouse
DDR RAM	4GB
Capacity	128GB
Audio	AAC, FLAC, MP3, OGG, WAV, etc (some need
	third party software support)
Video	3GP, MOV, MP4, MPG, AVI, etc (some need third
	party software support
E-book	Support
Wireless network	Support WIFI
Language	English (other languages need to be downloaded
	from Internet)
OTG	Support
Temperature	-20°C to 60°C
Battery	7.6V/5000mAh
Charge Adapter	12V/2A

Package contents: AC adapter ; Manual .

Warranty

Basic Warranty Statement

Supersonic Inc. ("Supersonic") warrants this product to the original purchaser ONLY, to be free from defects in materials and workmanship under normal use, for ninety (90) DAYS from the date of original purchase. Proof of purchase (receipt) required.

Please visit <u>http://www.supersonicinc.com/warranty</u> for additional information.

FC

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, (2) This device must accept any interference received, including interference that may cause undesired operation.

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception,

which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different

from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Specific Absorption Rate (SAR) information:

This device meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health. FCC RF Exposure Information and Statement the SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types: This device has also been tested against this SAR limit.

This device was tested for typical body-worn operations with the back of the This device kept 0mm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain an 0mm separation distance between the user's body and the back of This device. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.