

#### Step 1



##### Download The App

The GOSUNCN app is available for free in the Apple App Store and on Google Play. Search 'GOSUNCN' in your app store, or go to: [www.downloadtheapp.com](http://www.downloadtheapp.com)



**Tip:** Make sure you are running the latest version of your operating system and that your phone meets the minimum technical requirements to run the app.

#### Step 2



##### Launch the App & Sign Up

Easily create your profile by adding a photo, first and last name, email, mobile number, and a secure password.

#### Step 3



##### Verify

After you create your profile and agree to the terms of service, you will be asked for a four-digit verification code that we will instantly send to your mobile phone.

#### Step 4



##### Enter Your Address

Providing your address helps your contacts and the professional monitoring service to better assist you in the event of a Red Alert emergency.

#### Step 5



##### Create an Alert PIN

This four-digit PIN can be used to close an alert sent from any device on your account. The professional monitoring service may also ask for this PIN when responding to a Red Alert.

#### Step 6



##### Allow Permissions

You will be asked to allow the app access to three permissions: microphone, location, and contacts. The app needs all three permissions to function properly.

#### Step 7



##### Pair Your Device

Turn on your mobile device's Bluetooth. Press and hold the button on your GOSUNCN device for 10 seconds, until the light stops blinking and turns solid green. Back in the app, choose the device you want to pair, and we'll finish up for you!

**Note:** Feel the vibration? Your GOSUNCN device will do that any time an alert is sent or viewed.

#### Step 8



##### Choose a User

Select who will be using the GOSUNCN device - you, or someone else. If the device is for someone else, just fill out their profile information, like you did for yourself in step two.

#### Step 9



##### Add Contacts

Add your contacts' information by tapping the menu button in the top left corner of the app and tapping on Alert Contacts & Settings.

##### Know Your Alerts



**Check In (Press Button Once):** Shares location with contacts.



**Yellow Alert (Press Button Twice):** Sends an alert to contacts with location and audio.



**Red Alert (Press Button Three Times):** Sends an alert to contacts and professional monitoring service.



#### Understanding Your GOSUNCH Signal

1. Speaker
2. Alert Button
3. Alert LED
4. Connection Status LED
5. Location LED
6. Power LED
7. Power Button
8. Microphone LED

#### The Device Lights

##### POWER LED FLASHING RED

Battery power lower than 30%

##### POWER LED SOLID RED

Device is charging

##### POWER LED OFF

Device is fully charged

##### CONNECTION STATUS LED SOLID GREEN

LTE network mode, connected

##### CONNECTION STATUS LED FLASHING GREEN

Attempting to connect to LTE network

##### CONNECTION STATUS LED SOLID BLUE

Bluetooth mode

#### The Device Lights (Continued)

##### CONNECTION STATUS LED FLASHING BLUE

Bluetooth pairing

##### CONNECTION STATUS LED SOLID RED

Network disconnected

##### ALERT LED SOLID YELLOW

Yellow Alert

##### ALERT LED SOLID RED

Red Alert

##### LOCATION LED SOLID RED

The device is outside the 50 United States or Puerto Rico and EMS monitoring is not available.

#### The Menu

You can go to the app's menu at any time to see Alert Contacts & Settings, Alerts & Check Ins, Users & Devices, Account Info, and Support.

#### Additional Information

You can select which kinds of alerts you want each of your contacts to receive, and you can pre-load personalized messages to be sent in an email accompanying Yellow and Red Alerts.

#### Legal

Copyright 2019 CORPORATION NAME. All rights reserved.

No part of this publication may be excerpted, reproduced, translated, or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm, without the prior written permission of CORPORATION NAME.

The manual is published by CORPORATION NAME. We reserve the right to make modifications on print errors or update specifications without prior notice.

GOSUNCH, powered by GOSUNCH, and the GOSUNCH logo are trademarks and registered trademarks of CORPORATION NAME. 2019. All rights reserved.

#### Support

Need more help? Get in touch. Customer Care representatives are available daily from 3:00am to 10:00pm PT.

Here's how to reach us:  
From your T-Mobile phone: 611  
Call: 1-877-453-1304

If you are calling about a technical issue with your T-Mobile service, please call from a different phone so that we can troubleshoot with you.

Call Us - TTY  
TTY service is available for the hearing and speech impaired. Hours are 5:00am to 10:00pm PT, daily.

Call us via TTY toll free at 1-877-296-1018.  
For access to our T-Mobile Support Community, visit  
<https://support.t-mobile.com>.



- Phone Free  
No phone needed
- Location Aware  
Continuously updated location information
- Discreet  
Send alerts with the simple press of a button
- Speed  
The fastest way to get the help you need
- Focus  
No need to divert your attention
- 4G 4G LTE  
Cellular Service capable device

