




POWERUVC PRO

360° UV-C Sanitizer with Bluetooth Speaker



Model: iUVBT1 Quick Start Guide QUESTIONS? visit www.ihome.com

TOP PANEL



BACK PANEL BOTTOM PANEL

Battery Back-up ---Compartment*

(°□°/

UNDER THE LID






FRONT PANEL 710,000

DISPLAY



USING THE SANITIZER

This superior quality UV-C LED light safely kills up to 99.9% of surface germs in under 3 minutes, without using harmful phonocolors.



SANI/LZING III-MS

I. Make sure fat/PST1 is plugged into a working wall outlet. Lift the ido of the unit and place items on the shelf, making just not fat, outlett, better. Close items to the shelf, making just not fat, outlett, better. Close the lat is sent time to the control of the control of the control of the capital control of the capital control of the capital control of the capital solvey blink, and a tone will sound where the cycle is competitive.

optimal effect.

4. To cancel a sanitizing cycle, press the Sanitize Button.

CLOCK AND BLUETOOTH SETUP

Step One: Connecting the Unit



Step Two: Setting Your Clock

- Remove battery pull tab from the bottom of the unit
 Press and hold the Time Set Button until the
 display flashes.
 Press the or * Buttons to adjust selections and tap
 Time Set to confirm (make sure you set the correct
 AM/PM time). Do this for time, year, month and date.
 All done!

Tip: Press either Alarm Button during clock set to toggle between 12/24 hour display modes. Step Three: Bluetooth Pairing

- Press the Power Button to turn the unit ON. Turn on your Bluetooth device and make it 'discoverable' by turning on Bluetooth mode. The unit will automatically enter pairing mode. Select 'Home iUVBTI' on your device's Bluetooth menu to connect!

(To manually pair your device, press and hold the **Bluetooth Pairing Button** until the Bluetooth Pairing loon flashes to indicate the unit is in pairing mode.)

USING THE AUTO DIMMER

USING THE AUTO DIMMER

This unit is equipped with a sensor that will automatically adjust the brightness of the dock display based on ambert light in your room. When the room is well it, the display will adjust to H in the state of the dock display that the state of the state o

USING ALARMS

Dual alarms can be set to different times and alarm sources. Each is set in the same way instructions are given as "Alarm Button"; use Alarm 1 Button or Alarm 2 Button to set respective alarms.

- 2 Button to set respective alarms.

 1 Press and not the Alarm Button for 2 seconds until the display flashes. A been sounds.

 2 Press the or ** Buttons to adjust the alarm time to the desired time (hold for rapid setting). Make sure yous set the concret AM/PM alarm time. The PM indicator appears to the left of the display. Press the Alarm Button to confirm the alarm time setting. The alarm schedule will flash: 7 (every day), 5 (tweekdays) or 2 (veneleding orly). Press the 1-or ** Buttons to select on alarm schedule.

USING THE ALARMS (CONTINUED)

- 4. Press the Alarm Button to confirm the alarm schedule. The wake-to source will flash.
 5. Press the or + Buttons to select the desired wake-to alarm source: Bluetooth or Tone.
- wake-to alarm source Buetooth or Tone.

 Wake to Buetooth You will wake to the currently linked Buetooth device. If no device is detected, the adam will default to the last to no elected. If the adam will default to the last to no elected. If the adam will default to the last to no elected. If the property of the prop

To Preview: Press and release the Alarm Button to view the current alarm time. view the current alarm time.

Turning Alarms ON/OFF: Press and release the Alarm Button twice within 5 seconds to toggle the alarm ON and OFF, indicated by the related white alarm indicator.

SNOOZE / DISPLAY DIMMER

Snooze: When the alarm is sounding, press the ZZZ/Dimmer Button to snooze for 9 minutes. Dimmer: Press the ZZZZ/Dimmer Button (when alarm is NOT sounding) to adjust display brightness. (Display can be dimmed during Snooze mode.)

PROGRAMMABLE SNOOZE

- To adjust the snooze duration:

 1. Press and hold the ZZZ/Dimmer Button.

 2. Use the + or Buttons to adjust the snooze duration from 1-29 minutes. Press the ZZZ/Dimmer Button again to confirm.

CHARCING DEVICES VIA USB

There are 2 USB charging ports on the IUVBT1 - each is 1A. To charge your devices, connect a standard USB capit (not included) to a USB port on the unit, and legith the other oil into the changing port on your Note. Unit must be plugged into a working outlet in order to charge devices.

Battery Back-Up

Battery Back-Up
The unit comes with a CR-2450 back-up battery
installed to provide continuous alarm operation and
clock settings in the event of a temporary power
installed to provide continuous alarm operation and
clock settings in the event of a temporary power
the battery icon in the clock display is flashing, it is
time to replace the back-up battery. The battery
compartment is closed on the bottom if the function
time and alarm settings during
battery replacement.

battery replacement.

5. Remove exhausted battery from compartment and
insert I CR-2450 battery, checking that the * sales
facing you. Replace compartment door. Do not
overlighten.

- Do not ingest the battery. Chemical Burn Hazard. This product contains a coin/button cell battery. If the coin/button cell battery is availowed, it can cause severe internal burns in just 2 hours and can cause severe internal burns in just 2 hours and can Keep new and useb Datteries away from children. If the battery compartment does not close securely, stop using the product and keep it away been swallowed or placed inside any part of the body, seek immediate medical attention."

 Attention should be drawn to the environmental sepects of buttery disposal.

Maintenance + Caring For Your Device

- Maintenance + Caring For Your Device
 Place the unit on a level surface away from sources of direct sunlight or excessive heat. Remove the plastic protective film from the clock. Protect your furniture when placing your unit on a natural wood and lacquered first, A cloth or other protective material should be placed. Should the casing of your device become soiled, you may wipe down with a most cloth, you may wipe down with a most cloth, cloth you for any cleaning solvents device into water or any cleaning solvents device into white or any cleaning solvents device into white or any cleaning solvents device into white cleaning, cleaning solvents and clinic plant white cleaning, cleaning solvents.

IMPORTANT SAFETY INSTRUCTIONS

All users should be alerted to the potential hazards indicated by the product safety labeling on the unit and these instructions.

WARNING. Use this device only for its intended use as described in this manual. If the device is not used in the manner specified, the protection provided by the equipment may be compromised. Always place device on a flux, smooth surface, in a horizontal position for operational use.

WARNING - KEEP OUT OF REACH OF CHILDREN. This device is not a toy and is not intended to be used by children.

ATTENTION: Use only the supplied power adapter.
This product must only be supplied at safety extra low voltage con
to the making on the appliance.

ATTENTION: Prolonged or excessive exposure to UV-C light may degral discolor fabrics, plastics and other non-metallic materials. Keep operation away from strong magnetic fields.

- Service was a service and other conversities production.

 The control basis desired a low-control of the control basis desired as for the control basis desired and low-control of the control of the control basis desired and low-control of the control of the control basis desired and low-control of the control of the con

- wing droppies.

 Do not use if changing cable/cord is damaged.

 Keep the cable/cords and device away from heated surfaces.

 Close supervision is necessary when any appliance device is used by or near children and people with special needs.
- Do not operate in the presence of explosives and/or flammable furnes or liquids.

1 Year Limited Warranty
For warranty and full instructions, visit ihome.com/sup

© 2020 SDI Technologies, Inc. All rights reserved. Questions? Visit www.ihome.com

FCC Information

FCC Information
The experient complies with FCC RF radiation exposure limits set from for an unconclosed environment. This divides complies with Part 15 of the FCC Rules, complies with Part 15 of the FCC Rules, complies with Part 15 of the FCC Rules, complied to the part of cause in aeroth limited reference, and (2) this device must accept any interference received, including interference other may cause undesided operation.

Warring Change or modifications to this unit not expressly approved by the party reports with for complience caused used the sure's surchy to operate their party responsible for complience caused used the sure's surchy to operate the responsible complience caused used to the sure's surchy to operate the responsibility.

Printed in China