

WS-10 15W用户手册（产品说明书）
尺寸：490*100mm 单面印刷 材质：157克铜版纸

User Manual 15W Fast Wireless Charger UV Sterilizer 	Product Features Wireless Charging 1. Please plug the provided USB-C cable into product USB port and connect to the power supply, the product defaults to the wireless charging mode, and the standby indicator is red. 2. Wireless charging indicator light: red light on standby and green light on charging. 3. FOD foreign object detection: When a metal foreign object is detected, the red and green light flashes six times and the power supply is stopped. Disinfection 1. Put the mobile phone or other articles to be sterilized into the box and close the top cover, and press the button get into the disinfection mode. 2. 5 minutes disinfection mode: press the round button once, the built-in buzzer will beep one time and the blue breathing light on, the inside UV-C/UVA light on starts for disinfection. When The buzzer continuously beeps three times means the disinfection is completed. 3. 10 minutes disinfection mode: after the 5 minutes disinfection mode is turned on, press the button again automatically switch to the 10 minutes disinfection mode. The round breathing light changes from blue to purple and the built-in buzzer beeps once again. The inside UV-C/UVA light on starts for disinfection. When the buzzer continuously beeps three times means the disinfection is completed. 4. If you want to stop it during the disinfection mode, please press the round button again, the round indicator light turns to blue, the box can be open to safely remove inside articles. 5. When open the top cover of box, the UV disinfection light will automatically turn off after 3 seconds.
--	---