




MANUAL DE USUARIO BMOBILE K370

Referencia Técnica

Teléfono	
Modelo	Bmobile K370
Dimensiones(LxAnxAI)	113.8 x 48.5 x 13.85 mm
Peso	71.2g
Li-ion	
Modelo	Bmobile CM186
Voltaje estándar	3.7V
Capacidad nominal	600mAh
Cargador de batería	
Modelo	Bmobile
Entrada	100-240V 0.15A
Salida	5V 500mA
Cable USB	
Tipo de conector	Micro 5 pines
Auricular	
Tipo de conector	3.5mm

Partes del Teléfono



Introducción

Seguridad

Con el fin de garantizar que el teléfono es usado de manera segura y correcta, lea las siguientes precauciones antes de utilizarlo.

1.1 Precauciones generales

- El teléfono es adecuado solo para la batería y el cargador aprobados por el fabricante, usar otros accesorios puede provocar que la batería presente mal funcionamiento como fugas, sobrecalentamiento, explosiones o incendiar.
- No golpee, haga vibrar o tire el teléfono para evitar daños en la unidad.
- Si hay fenómenos anormales, como aumento de la temperatura, cambio de color o deformación durante el uso, la carga o el almacenamiento de la batería, por favor, deje de usarlo y sustituir la batería por una nueva lo antes posible.
- El líquido de la batería puede ocasionar quemaduras en la ropa y piel en caso de que se presenten fugas. Si esto sucede, por favor, lavar con abundante agua limpia inmediatamente y vaya al hospital más cercano.
- Por favor, mantenga la batería lejos del fuego para evitar incendios o explosión ya que puede provocar fugas o emitir un olor extraño.
- No coloque o exponga el teléfono a la humedad o puede provocar sobrecalentamiento, humo y corrosión.
- No utilice ni coloque la batería bajo la luz solar directa o en lugares calientes, puede causar fugas o sobrecalentamiento, lo que reduce el rendimiento y acorta la vida útil de la misma.
- No cargue la batería durante más de 24 horas seguidas.
- Use con cuidado el auricular, el uso del mismo con excesivo volumen puede causar pérdida auditiva.

1.2 Precauciones en el uso del cargador

- No provoque ningún tipo de cortocircuito en el cargador, o puede causar una descarga eléctrica, humo y corrosión.
- No utilice el cargador si el cable de alimentación está roto o dañado, o puede provocar incendios y descargas eléctricas.
- Elimine el polvo acumulado en la clavija de alimentación.
- No ponga contenedores de agua al lado de la fuente de alimentación para evitar el sobrecalentamiento, incendios, descargas eléctricas y mal funcionamiento.
- No desmonte ni fuerce el cargador o puede provocar lesiones personales, descarga eléctrica, fuego y daños en el cargador.
- No utilice el cargador en lugares de alta humedad, como cuartos de baño, o puede causar una descarga eléctrica, fuego y daños en el cargador.
- No utilice el cargador si el cable de alimentación está roto o dañado, o puede provocar incendios y descargas eléctricas.
- Elimine el polvo acumulado en la clavija de alimentación.

- No ponga contenedores de agua al lado de la fuente de alimentación para evitar el sobrecalentamiento, incendios, descargas eléctricas y mal funcionamiento.
- No desmonte ni fuerce el cargador o puede provocar lesiones personales, descarga eléctrica, fuego y daños en el cargador.
- No utilice el cargador en lugares de alta humedad, como cuartos de baño, o puede causar una descarga eléctrica, fuego y daños en el cargador.
- No toque el cargador, el cable o el tomacorriente de alimentación con las manos mojadas ya que esto puede causar una descarga eléctrica.
- No coloque objetos pesados sobre el cable de alimentación o puede dañar el cable y provocar un mal funcionamiento.
- Por favor desconecte el cargador del tomacorriente antes de su limpieza y mantenimiento.
- Por favor, mantenga el cargador desconectado del tomacorriente y no tire del cable de alimentación ya que puede dañar el cable de alimentación y provocar una descarga eléctrica.

1.3 Limpieza y mantenimiento

- Dado que el teléfono, la batería y el cargador no son resistentes al agua, no los utilice en lugares de alta humedad y evite que se mojen debido a la lluvia.
- Por favor, limpie la batería y el cargador con un paño suave y seco.
- Nunca utilice alcohol, solventes y/o soluciones corrosivas, como el benceno, para limpiar el teléfono.
- Los tomacorrientes sucios pueden causar un mal contacto y una baja en la fuente de alimentación, o incluso puede hacer que la carga de la batería no se realice correctamente. Así que, por favor, límpielos periódicamente.

1.4 Precauciones Comunes

Teléfono móvil:

- Utilice el teléfono en un ambiente con temperatura entre 20 a 40 ° y la humedad menor a 75 %.
- Utilice el teléfono lejos de los teléfonos fijos, televisores, radios y equipos de automatización de oficina, para no afectar el normal funcionamiento de estos equipos y del teléfono móvil.

Batería:

- Almacene la batería en un lugar fresco, ventilado y sin luz solar directa.
- La batería tiene una vida útil limitada. El uso de la batería se reducirá progresivamente debido a la carga frecuente. Una vez que la batería ya no se recargue, significa que su vida útil ha terminado, y usted tendrá que reemplazarla con una nueva batería aprobada por el fabricante.
- No tire las baterías gastadas a la basura doméstica. Deposítalas en los lugares de reciclaje específicos y siga las instrucciones estipuladas para su eliminación.

PRECAUCIÓN: SE CORRE EL RIESGO DE EXPLOSIÓN SI SE SUSTITUYE LA BATERÍA POR UNA DE TIPO INCORRECTA. ELIMINE LAS BATERÍAS USADAS DE ACUERDO CON LAS REGULACIONES DE SU PAÍS.

Cargador:

- No cargue el teléfono en las siguientes condiciones:
 - Lugares con luz solar directa.
 - Lugares con temperatura ambiente inferior a 0° o superior a 40°, lugares húmedos o polvorientos con fuertes vibraciones (Esto pueden provocar un mal funcionamiento)
 - Lugares cerca de electrodomésticos (Esto puede afectar las imágenes y el sonido) como aparato de TV, radio, etc.
 - El adaptador debe estar conectado cerca del equipo y debe ser de fácil acceso.


Introducción a tu teléfono

Como retirar la cubierta posterior:

- Asegúrese de que el dispositivo esté apagado.
- Sujete firmemente el aparato con la parte frontal hacia abajo.
- La tapa se encuentra cerrada a presión, utilice la ranura que se encuentra en la parte inferior para levantarla, y para cerrarla presione con cuidado hasta que quede completamente cerrada.

Como insertar la tarjeta SIM:

- Ubique la ranura para tarjeta SIM e inserte la SIM tal como se muestra en la figura. Adicional usted tendrá una ayuda visual, como referencia, de donde se inserta la tarjeta SIM.
- Deslice la tarjeta SIM en la ranura hasta que esta llegue al tope de la misma.




Encendido / Apagado

Para apagar el teléfono, presione y mantenga presionada la tecla de Apagar. Para encender el teléfono, pulse y mantenga presionado el botón de Encender hasta que la pantalla se encienda o vibre el teléfono.

Como instalar una tarjeta de memoria

Para tener un almacenamiento adicional para sus imágenes, videos, música y archivos, puede comprar una tarjeta de memoria e instalarla en su dispositivo. Localice la ranura de la tarjeta de memoria donde se indica en la imagen e inserte la tarjeta de memoria en la ranura con los contactos dorados hacia abajo hasta que encaje correctamente.



Carga de la batería

Las baterías nuevas se envían parcialmente cargadas. Antes de comenzar a utilizar el dispositivo, se recomienda hacer una carga completa de la batería. Algunas baterías tienen mejor rendimiento después de varios ciclos de carga / descarga.

1. Funciones del Menú

1.1 Agenda

Puede almacenar el nombre y número de teléfono en la memoria del teléfono o en la tarjeta SIM. Hasta 500 registros de números y nombres pueden ser almacenados en la memoria del teléfono. La capacidad de almacenamiento de la tarjeta SIM se determina por el tipo de la tarjeta SIM.

1.2 Llamadas

1.2.1 Historial de llamadas

Usted puede ver las llamadas perdidas, llamadas hechas, las llamadas recibidas a través de esta función, así como eliminar todo registro.

1.2.2 Llamadas perdidas

Ver las llamadas que no pudieron ser contestadas o fueron ignoradas.

1.2.3 Números marcados

Ver todos los números que fueron marcados por el dispositivo.

1.2.4 Llamadas recibidas

Ver las llamadas que se recibieron

1.2.5 Llamadas rechazadas

Ver los números telefónicos que llamaron y fueron rechazados.

1.2.6 Contador de tiempo de las llamadas

Muestra el tiempo de todas las llamadas, dividiéndolas por llamadas recibidas y números marcados, también muestra el conteo total de los minutos en llamada.

1.3 Alarma

Alerta en una hora exacta, se puede programar para que solo alarme en un día de la semana, todos los días o solo para una hora.

- Para programar 3 alarmas distintas: Ver opción de programación de alarmas

bmobile
bconnected

 www.bmobile.eu.com

1.4 Ajustes

1.4.1 Ajustes de llamada

Permite personalizar el funcionamiento al recibir y realizar llamadas.

- Selección de SIM principal

Convierte a la SIM 1 como SIM principal del teléfono y la utilizará automáticamente para realizar llamadas o enviar mensajes.

- o SIM 1 para llamadas
- o SIM 1 para mensajes

- **Modo avión:** Este modo bloquea todas las conexiones del teléfono, no podrá enviar y recibir llamadas ni mensajes, no podrá utilizar la red FM ni conectarse por medio de bluetooth a otro dispositivo. Es necesario activar el modo avión cuando está por despegar o aterrizar par evitar que el dispositivo haga interferencia con los sistemas de comunicación del avión.

- **Renombrar las tarjetas SIM:** Permite renombrar a las tarjetas SIM a gusto del usuario

- **Desvío de llamadas:** esta función de red le permite desviar las llamadas entrantes a otro número que haya especificado previamente.

- **Llamada en espera:** Después de elegir Activar, el teléfono móvil se comunicará con la red. Un momento después, la red hará una respuesta y enviará un mensaje para confirmar la activación de la operación. Si se activa la función de llamada en espera, la red le avisará y la pantalla del teléfono móvil se mostrará el número de la llamada entrante mientras está en una conversación.

- **Llamadas restringidas:** La llamada a la función de restricción le permite bloquear las llamadas, según sea necesario. Al configurar esta función, es necesario utilizar un código de red de restricción, que se puede obtener del operador de red. Si el código es incorrecto, aparecerá un mensaje de error y se le solicitará en la pantalla ingresar nuevamente. Después de seleccionar una opción de restricción de llamadas, continúe para seleccionar Activar o Desactivar. El teléfono móvil le pedirá que introduzca el código de bloqueo de llamadas y luego se pondrá en contacto con la red. Un momento después, la red dará una respuesta y enviará los resultados de la operación al teléfono móvil.

- **Ocultar ID:** Esconde tu número al realizar llamadas.

- **Grabación de llamadas:** Guarda las conversaciones de las llamadas, depende de cuanto espacio de almacenamiento esté disponible.

1.4.2 Ajustes de teléfono

- **Selección de idioma:** Elección del idioma principal del teléfono, se puede elegir entre: español o inglés.

- **Hora-fecha:** Editar la hora y fecha que muestra el teléfono, también permite definir el formato en que se quiere ver la hora y fecha.

- **Modificación de los Accesos directos:** Modifica los accesos directos predeterminados del dispositivo.

- **Encendido y apagado automático:** Permite definir cuando se enciende y cuando se apaga el teléfono automáticamente.

- **Ajustes de ahorro de energía:** Editar las opciones de ahorro de energía como quitar animaciones, desactivar datos, desactivar bluetooth.

Y también permite definir cuando se quiere activar el ahorro de energía.

1.4.3 Pantalla

- **Elegir fondo de pantalla:** Permite elegir entre fondos predeterminados o imágenes y fotos agregadas por el usuario.

- **Tiempo de iluminación de pantalla:** Definir cuanto tiempo la luz de la pantalla permanecerá encendida después de que se deje de usar el dispositivo

- **Información a mostrar:** Seleccionar la información que se mostrará en la pantalla principal como, hora, fecha, estado de las tarjetas SIM, tareas, música o radio FM.

- **Luz del teclado:** Cambia el tiempo en que el teclado permanece iluminado después de su uso.

1.4.4 Seguridad

- PIN y PIN 2 de SIM

Usted puede activar, desactivar o modificar el código PIN. Ingrese el Código PIN correcto para poder desbloquear o desactivar el código PIN. Si se activa la verificación del código PIN, cada vez que encienda el teléfono, tendrá que ingresar el código PIN correcto. Si ingresa 3 veces códigos PIN no válidos se bloqueará la tarjeta SIM. Usted tendrá que introducir el código de PUK1 para desbloquearlo. Por favor, póngase en contacto con el operador de red para obtener el código PUK1.

- **Activar código para desbloqueo de teléfono al encender:** Puede activar o desactivar la contraseña del teléfono. Cuando se activa la contraseña del teléfono, debe introducir la contraseña cada vez que se enciende el teléfono. La contraseña del teléfono por defecto es 0000.

- **Auto bloqueo de tecla:** Una vez que se deja usar el dispositivo, se bloquea para evitar que active en su bolsillo por error.

- **Números de marcación fija:** Activa o desactiva la marcación fija. Cuando la marcación fija está activada, el teléfono sólo puede llamar a determinados números y realizar llamadas de emergencia. Las llamadas entrantes se siguen recibiendo, aunque la marcación fija esté activada.

1.4.5 Conexiones

- **Cuentas de red:** Permite observar, editar y agregar cuenta de red. Esto dependerá de su tarjeta SIM.

- **Selección de red:** Permite elegir a que red se desea conectar. Esto dependerá de su tarjeta SIM.

1.5 Mensajes

Permite crear y enviar mensajes SMS también permite visualizar los mensajes recibidos.

- Escribir mensajes.

- Bandeja de entrada.

- Borrador.

- Bandeja de salida

- Mensajes de difusión

Permite observar y editar las configuraciones de los mensajes de difusión.

1.6 Multimedia

1.6.1 Cámara

Esta función le permite tomar imágenes. Puede pulsar la tecla de dirección arriba o abajo para acercar o alejar la imagen; Tecla OK para tomar la foto o capturar videos; Tecla de función izquierda para acceder a los ajustes de la cámara de video; tecla de función derecha para salir de la interfaz de captura.

1.6.2 Grabadora de video

Permite capturar videos, utilice la tecla OK para empezar a grabar, opción izquierda para detener y opción derecha para descartar; antes de empezar a grabar use tecla de función izquierda para acceder a los ajustes de la cámara de video; tecla de función derecha para salir de la interfaz de captura.

1.6.3 Radio FM

El teléfono está equipado con una radio FM. Puede utilizar la aplicación como una radio FM tradicional con sintonización automática y emisoras guardadas. Puede escuchar la radio mientras ejecuta otras aplicaciones.

1.6.4 Galería

Usted puede ver la imagen o las imágenes a través de esta función.

1.6.5 Reproductor de audio

Reproduce archivos de audio. Puede ordenar en listas de reproducción personalizadas o escuchar su lista completa. Puede seguir escuchando sus archivos de audio mientras ejecuta otras aplicaciones.

1.6.6 Reproductor de video

Esta función reproduce archivos de video. Pulsando las teclas de dirección se puede controlar el proceso de reproducción del reproductor de video: reproducción / pausa (tecla de dirección arriba), avance rápido (presione y sostenga la tecla de dirección derecha) y rebobinar (presione y sostenga la tecla de dirección izquierda). En la interfaz de reproductor de video, pulse la tecla " para cambiar al modo pantalla completa; puede presionar 2 u 8 para el subir y bajar el volumen respectivamente.

1.7 Perfiles de sonido

El usuario puede cambiar de un modo a otro de acuerdo a diferentes ocasiones. Modos disponibles: Modo general, el modo silencioso, Modo de reuniones, Modo al aire libre y Modo Mi estilo. El usuario también puede restablecer los modos individualizados pulsando la tecla de función izquierda para entrar en la interfaz opción. Puede personalizar las siguientes opciones para nuevos perfiles.

- **Normal:** Volumen de llamadas, mensajes y demás alertas en un 50%

- **Silencioso:** Volumen de llamadas, mensajes y demás alertas en 0%

- **Interior:** Volumen de llamadas, alertas y mensajes a un 40%

- **Exterior:** Volumen a 100% para mensajes, alertas y llamadas.

- **Creados por el usuario:** El usuario puede personalizar los perfiles de sonido según su preferencia.

1.8 Organizador

- **Explorador de archivos:** Permite administrar los archivos en la memoria del teléfono o tarjeta de memoria.

- **Calculadora:** Realiza operaciones aritméticas (suma, resta, multiplicación y división)

- **Reloj mundial:** Permite agregar tiempos de otras países.

- **Conversión de unidades:** Convierte unidades comunes de peso o longitud

- **Menú de SIM:** Muestra las opciones del menú de la tarjeta SIM, varía dependiendo del proveedor.

- **Bluetooth:** Permite vincular con otros dispositivos para la transferencia de archivos por medio de bluetooth o conectar a audífonos bluetooth para escuchar música.

- **Linterna:** Activa / desactiva la linterna del dispositivo

- **Luz ultravioleta:** Activa / desactiva la luz ultravioleta del dispositivo

1.9 Cámara/ Grabadora de video

Esta función le permite tomar imágenes. Puede pulsar la tecla de dirección arriba o abajo para acercar o alejar la imagen; Tecla OK para tomar la foto o capturar videos; Tecla de función izquierda para acceder a los ajustes de la cámara de video; tecla de función derecha para salir de la interfaz de captura.

2. Aviso importante sobre FCC

15.19 Requerimientos de etiquetado

Cualquier cambio o modificación no aprobados expresamente por la parte responsable del cumplimiento podrían anular la autoridad del usuario para operar el equipo. Este dispositivo cumple con la parte 15 de las normas FCC. La operación está sujeta a las siguientes dos condiciones: (1) Este dispositivo no debe causar interferencias perjudiciales. (2) Este dispositivo debe aceptar cualquier interferencia recibida, incluyendo interferencias que puedan causar un funcionamiento no deseado.

15.21 Información para el usuario

Cualquier cambio o modificación no aprobada expresamente por la entidad certificadora puede anular la autoridad del usuario a usar el equipo.

15.105 Información para el usuario

Nota: Este equipo ha sido probado y cumple con los límites para un dispositivo digital de Clase B, según la Parte 15 de la normativa FCC. Estos límites están diseñados para proporcionar una protección razonable contra las interferencias perjudiciales en una instalación residencial. Este equipo genera, utiliza y puede irradiar energía de radiofrecuencia si no se instala y utiliza de acuerdo con las instrucciones, puede causar interferencias perjudiciales en las comunicaciones de radio. Sin embargo, no hay garantía de que no se produzcan interferencias en una instalación en particular. Si este equipo causa interferencias perjudiciales en la recepción de radio o televisión, lo cual puede determinarse apagándolo y encendiéndolo, se recomienda al usuario que intente corregir la interferencia mediante una o más de las siguientes medidas:

- Reorientar o reubicar la antena receptora.

- Aumente la separación entre el equipo y el receptor.

- Conecte el equipo a un tomacorriente en un circuito diferente de aquel al que está conectado el receptor.

- Consulte a su distribuidor o a un técnico de radio / televisión para obtener ayuda.

Información de Tasa de Absorción específica (SAR)

Este dispositivo cumple con los requisitos del gobierno para exposición a las ondas de radio. Las directrices están basadas en estándares que fueron desarrollados por organizaciones científicas independientes a través de la evaluación y el estudio periódico de las pruebas.

Los estándares incluyen un margen sustancial de seguridad diseñado para asegurar la seguridad de cualquier persona independientemente de su edad.

La declaración de FCC para exposición al RF indica que el límite para EEUU (FCC) es 1.6 W/Kg promedio por cada gramo de tejido. Este dispositivo fue probado bajo condiciones normales de uso con la parte trasera del mismo a 1.0 cm del cuerpo. Para mantener la validez con FCC y la exposición a RF, use accesorios que mantengan una separación de 1.0 cm entre el cuerpo y la parte trasera del equipo. El uso de clips para cinchos, detenedores y accesorios similares no deben contener partes metálicas en su ensamblaje. El uso de accesorios que no cumplan con lo mencionado anteriormente pueden no cumplir con la normas FCC y deben ser evitados. **Uso en el cuerpo:** Este dispositivo fue probado para usos típicos en el cuerpo. Para cumplir con los requerimientos de exposición a RF, una separación mínima de 1.0 cm debe ser mantenida entre el cuerpo del usuario y el dispositivo, incluyendo la antena. El uso de clips para cinchos, detenedores y accesorios similares no deben contener partes metálicas en su ensamblaje. El uso de accesorios que no cumplan con lo mencionado anteriormente pueden no cumplir con la normas FCC y deben ser evitados. Use únicamente la antena de fábrica o en su defecto cualquier antena aprobada.

3. Garantía limitada Bmobile

Bmobile, provee esta Garantía Limitada para su teléfono celular junto con sus accesorios. (En adelante denominado "Producto"). Si su Producto requiere servicio de garantía, por favor entréguelo al Distribuidor a quien se lo haya comprado; o visite www.bmobile.eu.com para mayor información.

NUESTRA GARANTÍA Sujeto a las condiciones de esta Garantía Limitada, Bmobile otorga una garantía comercial por un periodo de doce meses desde la fecha de entrega del producto al operador o por un periodo de un (1) año contado a partir de la fecha de adquisición del Producto por parte del usuario, por los defectos del mismo. Los accesorios, cuentan con una Garantía comercial de seis (6) meses, contados a partir de la fecha de compra por parte del usuario. La garantía incluye mano de obra y los gastos de transportación son cubiertos únicamente desde el establecimiento de compra. Para adquirir partes, componentes, consumibles y accesorios acórcase al taller de servicio autorizado, para más información visita nuestra página web www.bmobile.com

QUE HAREMOS Si, durante el periodo de garantía, este producto falla en operar bajo uso y servicio normal, debido a defectos de diseño, materiales o mano de obra, los distribuidores y Centros de Servicio autorizados por Bmobile, en el país / región donde el Producto fue adquirido, repararán o reemplazarán el mismo, a su criterio, sin que ello de derecho a reclamación alguna, de acuerdo con los términos y condiciones estipulados en adelante.

Bmobile y sus Centros de Servicio, se reservan el derecho de recargar un costo a la reparación si el Producto recibido se encontrara fuera de las condiciones de garantía que se presentan a continuación. Por favor, tenga en cuenta que sus configuraciones personales o descargas, podrían perderse cuando el producto es reparado o reemplazado.

CONDICIONES

Garantía proporcionada por Bmobile, no cubre:

1. Daños debidos al uso normal del producto, incluyendo carcassas, teclado, lentes, pantallas y otros componentes;
2. Cuando el producto se hubiese utilizado en condiciones distintas a las normales.
3. Cuando el producto no hubiese sido operado de acuerdo con el instructivo de uso que se le acompaña.
4. Cuando el producto hubiese sido alterado o reparado por personas no autorizadas por el fabricante nacional, importador o comercializador responsable respectivo.
5. Los daños causados por el mal uso se entiende como, pero no limitada a, dirección confundida, analizados, caídas, accidentes, derrames y / o alimentos, la exposición a la humedad o condiciones climáticas extremas, la corrosión y la oxidación en el producto o sus componentes.
6. Productos cuyo número de serie ilegible, raspadas, dañados, borrados y / o eliminados.
7. Alteraciones, modificaciones y / o reparaciones realizadas por terceros que no estén acreditadas oficialmente por Bmobile como distribuidor.
8. Los productos que no tienen partes y / o componentes originales de la marca Bmobile.
9. Los productos y componentes que hayan sido dañados por abuso, o han sido dañados por el mal uso de piezas y componentes no originales Bmobile.
10. Desfiguración o daño al producto causado por el envío de productos no autorizados, causada por virus de acceso a sitios de Internet, entre otros.

VALIDEZ DE GARANTIA

1. Para hacer efectiva la garantía no deben exigirse mayores requisitos que la presentación del producto, acompañado de la póliza correspondiente, debidamente sellada por el establecimiento que lo vendió, o la factura, o recibo o comprobante, en el que consten los datos específicos del producto objeto de

la compraventa. Bmobile se reserva el derecho de rechazar los servicios de garantía si no cumplen estos requisitos básicos

2. Si Bmobile repara o reemplaza el Producto, el Producto reparado o reemplazado será garantizado por el tiempo restante al de la garantía original o por noventa (90) días desde la fecha de reparación o reemplazo, el que fuera más largo. La reparación o el reemplazo pueden involucrar la utilización de unidades reacondicionadas equivalentes al Producto original. Las partes o componentes reemplazados, pasarán a ser propiedad de Bmobile.

3. Esta garantía no cubre ninguna falla del Producto ocasionada por el desuso o cualquier otro tipo de uso diferente a aquel indicado por las instrucciones de uso y mantenimiento del Producto de Bmobile (Manual de Usuario). Esta garantía tampoco cubre cualquier falla.

ATENCIÓN

Bmobile recomienda encarecidamente que, antes de la actualización del software o el mantenimiento del producto, se haga una copia de seguridad de los datos, enlaces y otros contenidos que se ha enviado a través de descarga y se almacena en la memoria, ya que se pueden perder durante el procedimiento de actualización. En caso de sustitución, se recomienda el mismo procedimiento. Bmobile no será responsable en ningún caso por pérdida, daño y / o corrupción de datos sobre producto entregado para su reparación, actualización de software o un reemplazo.



CERTIFICADO DE GARANTIA

No. ESN / IMEI: _____

MODELO: _____

CONSUMIDOR:

NOMBRE: _____

DIRECCIÓN _____

CIUDAD: _____

ESTADO: _____

CÓDIGO POSTAL: _____

TELÉFONO: _____

TELÉFONO: _____

DISTRIBUIDOR:

NOMBRE: _____

N ° DE FACTURA: _____

DATOS DE EDICIÓN: _____

CIUDAD: _____

ESTADO: _____

ESTADO: _____

Nombre del producto: Teléfono Celular INFORMACIÓN PARA MÉXICO

Nombre del Importador: B TELECOMUNICACIONES MÉXICO S.A DE C.V.
Avenida Vasco de Quiroga No. 3900 Torre A Piso 10-B Colonia Santa Fe Cuajimalpa, Delegación Cuajimalpa de Morelos, Ciudad de México, México. CP 05348 R.F.C.: BTM 150819 AS8

Producto: Teléfono Celular, Marca Bmobile, Modelo: K370

Características Nominales: 3.7V 600 mAh

Adaptador De Corriente: Bmobile Adaptador

Entrada: AC 100-240V~50/60HZ 0.2A

Salida: DC 5.0V 500mA

Batería: Bmobile Li-Ion Battery

Modelo: CM186

Voltaje: 3.7Vcc Capacidad 600mAh

2.22 Wh.

HECHO EN CHINA

INCLUDE: Teléfono celular, marca Bmobile K370, Adaptador ca/cc marca Bmobile, sin modelo, Batería Recargable marca Bmobile CM186, Manos Libres sin marca y sin modelo, Manual de Usuario, Protector de pantalla.



Content

1	General Information	4
1.1	Profile	4
1.2	Safety Information	4
1.3	Safety warning and Attentions	4
2	Your phone	7
2.1	Phone overview	7
2.2	Functions of Keys	8
2.3	Technical specifications	9
3	Getting started	9
3.1	Installing the SIM Cards and the Battery	9
3.2	Installing T-Flash Card	12

3.3	Charging the Battery	12
3.4	Powering On/Off the Mobile Phone	15
3.5	Linking to the Network.....	15
3.6	Dialing Calls	15
3.7	Using the Headset	15
4	Input method	16
4.1	Key for Input Methods.....	16
4.2	To Shift Entry Methods.....	16
4.3	Numeric Input	16
4.4	English input and numeric input:	16
4.5	Inserting a Symbol	18
5	Using the Menus	19
5.1	Tplus	19
5.2	Call logs	19
5.3	Multimedia.....	20
5.4	Contacts	22
5.5	Audio	22

5.6	Message	22
5.7	File manager	24
5.8	Application	24
5.9	Settings	25
5.10	Profiles	28
5.11	Games.....	28
5.12	Services	29
6	Appendix	29

1General Information

1.1 Profile

Please read this pamphlet carefully in order to make your phone in perfect condition.

Our company may change this mobile phone without prior written notice and reserves the final right to interpret the performance of this mobile phone.

Due to different software and network operators, display on your phone may be different, refer to your phone for details.

1.2 Safety Information

If your phone has lost or been stolen, notify the telecommunication office the SIM card is disabled (network support is required). This can avoid economic loss caused by unauthorized use.

Please take measures as following to avoid your phone being unauthorized used:

- Set PIN code of SIM card
- Set phone password

1.3 Safety warning and Attentions

Safety warning

- **ROAD SAFETY COMES FIRST**

Do not use a hand-held phone while driving. Use hands-free fittings when calls are unavoidable while driving. In some countries, dialing or receiving calls while driving is illegal!

➤ **SWITCH OFF IN AIRCRAFT**

Wireless devices can cause interference in aircraft. Using a mobile phone in flight is illegal and risky. Please make sure that your mobile phone is powered off in flight.

➤ **SWITCH OFF BEFORE ENTERING RISKY AREAS**

Strictly observe the relevant laws, codes, and regulations on the use of mobile phones in risky areas. Turn off your mobile phone before entering a place susceptible to explosion, such as an oil station, oil tank, chemical plant or a place where a blasting process is under way.

➤ **OBSERVE ALL SPECIAL REGULATIONS**

Follow any special regulations in force in any area such as hospitals and always switch off your phone whenever it is forbidden to use it or, when it may cause interference or danger. Properly use your mobile phone near medical apparatuses, such as pacemakers, hearing aids and some other electronic medical devices, as it may cause interference to such apparatus.

Follow any special regulation in force in any area such as hospital and always switch off your phone whenever it is forbidden to use it or, when it may cause interference or danger. Properly use your mobile phone near medial apparatuses, such as pacemakers, hearing-aids and some other electronic medical devices, as or may cause interference to such apparatuses.

➤ **INTERFERENCE**

The conversation quality of any mobile phone may be affected by radio interference. An antenna is built inside the mobile phone and located below the microphone. Do not touch the antenna area during a

conversation, lest that the conversation quality deteriorate.

➤ **QUALIFIED SERVICE**

Only qualified personnel may install or repair phone equipment. Installing or repairing the mobile phone on your own may bring great danger and violate the warranty rules.

➤ **ACCESSORIES AND BATTERIES**

Use only approved accessories and batteries.

➤ **USE SENSIBLY**

Use only in a normal and proper manner.

➤ **EMERGENCY CALLS**

Ensure the phone is switched on and in service, enter the emergency number, e.g. 112, then press the Dial key. Give your location and state your situation briefly. Do not end the call until told to do so.

***Note:** Just like all other mobile phones, this mobile phone does not necessarily support all the features described in this manual due to network or radio transmission problems. Some networks even do not support the emergency call service. Therefore, do not rely solely on the mobile phone for critical communications such as first aid. Please consult the local network operator. Just like all other mobile phones, this mobile phone does not necessarily support all the features described in this manual due to network or radio transmission problems. Some network even do not support the emergency call service*

Precaution

This mobile phone is well designed with fine art. Please exercise special care when using it. The following suggestions will help your mobile phone survive the warranty period and extend its service life:

- Keep the mobile phone and all its fittings beyond children's reach.
- Keep the mobile phone dry. Keep away from rain, moisture, liquid or other substances that may corrode electronic circuits.
- Do not use or store the mobile phone in dusty place, lest that active parts of the mobile phone be damaged.
- Do not store the mobile phone in a high-temperature place. High temperature will shorten the life of electronic circuits and damage the battery and some plastic parts.
- Do not store the mobile phone in a chilly place. Otherwise, moisture will be formed inside the mobile phone to damage electronic circuits when the mobile phone is moved to a constant temperature place.
- Do not throw, knock or shock the mobile phone, as that will destroy the internal circuit and high precision components of the mobile phone.

2Your phone

2.1 Phone overview

The phone has many powerful function and good appearance.

2.2 Functions of Keys

◆ Dial1 key

Press dial 1 to originate a call by entering the called number or selecting a contact from the phonebook; or press dial 1 to receive an incoming call; or press it in standby state to show the latest call records.

◆ End key

Press it to end a call being dialed or end an ongoing call; or press it to exit the menu and return to the standby state. You can hold it for two or three seconds can power on/off the mobile phone

◆ Direction key

Press them to scroll the options when browsing a function list. In edit state, press direction keys to navigate.

◆ Dial 1 key and Right soft key

The bottom line on the screen displays the functions of the dial 1 key and Right soft key.

◆ OK key

Press it to confirm a selection.

◆ **Number keys, * key and # key**

Press number keys 0 through 9 to input or edit state to input numbers and characters;

In idle screen, you can press left soft key then press * to lock/unlock keypad.

Press two times the key * to input "+" in standby interface. When the symbol "+" appears, Press the * key quickly to input "P" or "W" starting the second word, "P" and "W" are used for calling the extension; "+" are used for dialing an international call.

2.3 Technical specifications

Phone

Dimensions (W×D×H):

Weight:

Lithium battery

Rated capacity:

Continuous standby duration: (Relates to network status)

Continuous conversation duration: (Relates to network status)

Please refer to their labels for other data related to the battery and the charger.

3Getting started

3.1 Installing the SIM Cards and the Battery

A SIM card carries useful information, including your mobile phone number, PIN (Personal Identification Number), PIN2, PUK (PIN Unlocking Key), PUK2 (PIN2 Unlocking Key), IMSI (International Mobile Subscriber Identity), network information, contacts data, and short messages data.

Note:

After powering off your mobile phone, wait for a few seconds before removing or inserting a SIM card. Exercise caution when operating a SIM card, as friction or bending will damage the SIM card. Properly keep the mobile phone and its fittings such as the SIM cards beyond children's reach.

Installation

- ◆ Hold the End key for a while to power off the mobile phone.
- ◆ Take the back cover above the battery away.
- ◆ Take the battery away.
- ◆ Insert the SIM card into the SIM card slot lightly with the corner cutting of the card aligning to the notch of the slot and the gold plate of the card facing down, till the SIM card cannot be further pushed in.
- ◆ With the metallic contacts of the battery facing the metallic contacts in the battery slot, press the battery down until it locks into place.

Using code

The mobile phone and the SIM cards support sorts of passwords, in order to prevent the phone and the SIM cards from being misused. When you are prompted to input any of the codes mentioned below, just input the correct code and then press the OK key. If you input a wrong code, clear it and then input the correct code.

◆ Phone lock code

The phone lock code may be set to prevent your mobile phone from being misused. In general, this code is provided along with the mobile phone by the manufacturer. The initial phone lock code is set to 1234 by the manufacturer. If the phone lock code is set, you need to input the phone lock code when powering on the

mobile phone.

◆ PIN

The PIN (Personal identification number, 4 to 8 digits) code prevents your SIM card from being used by unauthorized people. In general, the PIN is supplied with SIM card by the network operator. If PIN check is enabled, you need to input the PIN each time when you power on your mobile phone. The SIM card will be locked if you input wrong PIN code for three times.

Unlocking methods as follows:

- Input the correct PUK according to the screen tips to unlock the SIM card.

- Then input the new PIN and press the OK key.

- Input the new PIN again and then press the OK key.

- If the input PUK is correct, the SIM card will be unlocked and the PIN will be reset.

Note: *The SIM card will be locked if you input wrong PIN code for three times. To unlock the SIM card, you need to input the PUK. In general, the PUK can be obtained from the network operator.*

◆ PUK

The PUK code (Personal Unlocking Key) is required to change a blocked PIN. It is supplied with SIM card. If not, contact your network operator. If you input wrong PUK code for 10 times, SIM card will be invalid. Please contact the network operator to replace the SIM card.

◆ Barring code

A barring code is required for setting the call barring function. You can obtain this code from the network operator to set the call barring function.

3.2 Installing T-Flash Card

The T-Flash card is a pluggable mobile storage card inside the mobile phone.

Insert the T-Flash card into the T-Flash card slot lightly with the corner cutting of the card aligning to the notch of the slot and the gold plate of the card facing down, till the T-Flash card cannot be further pushed in.

Note:

- 1. The mobile phone cannot automatically identify the T-flash card being inserted when the mobile phone is powered on. You must power off the mobile phone and then power it on, so that the phone can identify the T-Flash card.*
- 2. The T-Flash card is a miniature object. Keep it out of the reach of children for fear that children swallow it!*

3.3 Charging the Battery

The lithium battery delivered with the mobile phone can be put into use immediately after being unpacked.

Battery level indication:

- ◆ Your mobile phone can monitor and display the battery state.
- ◆ Normally the remaining energy of the battery is indicated by the battery level icon at the upper right corner of the display screen.
- ◆ When the battery energy is insufficient, the mobile phone prompts "Battery low". If you have set an alert tone, an alert tone will be given off when the battery level is too low.

- ◆ A charging animation appears when the battery is being charged. When the charging is complete, the animation disappears.

Using a travel adapter:

- ◆ Install the battery into the mobile phone before charging the battery.
- ◆ Connect the adapter of the travel charger with the charging slot in the mobile phone. Ensure that the adapter is fully inserted.
- ◆ Insert the plug of the travel charger to an appropriate power outlet.
- ◆ During the charging, the battery level grid in the battery icon keep flickering till the battery is fully charged.
- ◆ It is normal when the battery becomes hot during the charging period.
- ◆ The battery icon does no longer flicker when the charging process ends.

Note:

Ensure that the plug of the charger, the plug of the earphone, and the plug of the USB cable are inserted in the right direction. Inserting them in a wrong direction may cause charging failure or other problems.

Before the charging, ensure that the standard voltage and frequency of the local mains supply match the rated voltage and power of the travel charger.

Using the Battery

The performance of a battery is subject to multiple factors: radio network configuration, signal strength, ambient temperature, chosen functions or settings, phone fittings, and the voice, data or other application mode you choose to use.

To guarantee the optimal performance of your battery, please stick to the following rules:

- ◆ Use only the battery provided by the vendor. Otherwise, damages or even injuries could be caused during the charging.

- ◆ Power off the mobile phone before removing the battery.

- ◆ The charging process lasts a longer time for a new battery or a battery not in use for long. If the battery voltage is too low to enable the mobile phone to be powered on, charge the battery for a longer time. In this case, the battery icon does not flicker until a long time after the battery enters the charge status.

- ◆ During the charging, ensure the battery is placed in a room temperature environment or in an environment close to room temperature.

- ◆ Immediately stop using the battery if the battery produces odor, overheat, cracks, distort or has other damage, or if the electrolyte leaks.

- ◆ The battery wears out with use. A longer charging time is required as the battery is put into use for a long time. If the total conversation duration decreases but the charging time increases even though the battery is properly charged, purchase a standard battery from the OEM or use a battery approved by our company. Using any poor-quality fittings will cause harm to your mobile phone or even incur danger!

Note: To guarantee your personal safety and protect the environment, do not litter the battery! Return the old battery to the mobile phone manufacturer or place it in specified battery reclamation areas. Do not litter any battery with other rubbish.

Warning: Short-circuits of the battery may cause explosion, fire, personal injury or other severe consequences!

3.4 Powering On/Off the Mobile Phone

Hold the End key for a while to power on the mobile phone. A power-on animation appears on the display screen.

Input the phone lock code and press the OK key if the mobile phone prompts you to input the phone lock code. The original code is 1234.

Input the PIN and press the OK key if the mobile phone prompts you to input the PIN. The PIN is provided by the network operator for new opening SIM card.

Enter the standby interface.

To power off the mobile phone, hold the End key for a while.

3.5 Linking to the Network

After the SIM card and the mobile phone are successfully unlocked, the mobile phone automatically searches for an available network. After finding a network, the mobile phone enters the standby state. When the mobile phone is registered in the network, the name of the network operator is displayed on the screen. Then you can dial or receive a call.

3.6 Dialing Calls

In the standby interface, press Dial-pad enter virtual dial pad, press number keys to input the area code and the telephone number, and then press the dial key to dial a call.

3.7 Using the Headset

It would enter headset mode automatically when you insert headset to the slot. Make sure of inserting it

at the bottom of the slot, or you can't use it normally.

4 Input method

This mobile phone provides English input, smart English input and numeric input method. You can use these input methods when editing the contacts, short messages, files and greeting text.

4.1 Key for Input Methods

After you enter an edit window such as a window for editing the contacts, short messages or the memorandum, an icon is displayed to indicate the current input method:

Numeric input: “123”

English input: “ABC, abc, Abc”

4.2 To Shift Entry Methods

Press the # key to switch between input methods.

4.3 Numeric Input

You can input numbers with the numeric input method. Press a number key to input the corresponding number.

4.4 English input and numeric input:

The keyboards for English input and numeric input are defined in the following table:

Key	Character or Function	Remarks
Number key 1	. , - ? ! ' @ : # \$ / _ 1	
Number key 2	ABCabc2	
Number key 3	DEFdef3	
Number key 4	GHIghi4	
Number key 5	JKLjkl5	
Number key 6	MNOmno6	
Number key 7	PQRSpqrs7	
Number key 8	TUVtuv8	
Number key 9	WXYZwxyz9	
Number key 0	0	
# key	Press it to switch between input methods	
Left direction key	Press it to move to the left	
Right direction key	Press it to move to the right	
Left soft key	Equivalent to OK or Options	
Right soft key	Equivalent to Back or Clear	

End key	Press it to return to the standby interface	
---------	---	--

English input:

- Each key is used to represent multiple characters. Quickly and continuously press a key till the character you want appears. Input the next character after the cursor moves.
- Press the # key to switch between input methods
- To input a blank, switch to the English input mode (in upper or lower case) and then press number key **0**.
- To clear wrong inputs, press the **Right soft** key.

4.5 Inserting a Symbol

Press * key to enter the **Select symbol** interface, use direction keys or number keys to select a symbol you want.

5Using the Menus

5.1 Tplus

5.2 Call logs

All calls

All calls will be in the list.

Missed Calls

You can view a list of the latest missed calls.

Note: When the mobile phone indicates that some calls are missed, you can select **Read** to enter the missed calls list. Navigate to a missed call and then press the **Dial** key to dial the number that originated that call.

Dialed Calls

You can view the latest dialed calls. Choose **dialed calls** and then select a dialed call to delete, save, dial, or edit (or send a short message to it).

Received Calls

You can view the latest received calls. Choose **received calls** and then select a received call to delete, save, dial, or edit (or send a short message to it).

Rejected Calls

You can view the latest rejected calls. Choose **rejected calls** and then select a rejected call to delete, save, dial, or edit (or send a short message to it).

Delete All

You can delete all the latest call records.

Call Timers

Choose Call timers to view the last call time, the total time of all dialed calls, the total time of all received calls and the total time of call history or to reset all the time.

5.3 Multimedia

Camera

The phone is provided with a camera, which supports the photographing functions. In the capture interface, roll the phone to align the camera to the picture and then press OK key to capture photos. Pictures will be saved in the file system of the memory card or the phone.

Image Viewer

You can view the pictures in the T-card by this function. Press the direction key to choose them and left soft key edit the pictures. Press right soft key to return last interface.

Video recorder

This function enables you to record dynamic pictures. In the capture interface, press OK key to capture videos clip.

Video Player

Use this function to play video files. By pressing the direction key can you control the playing process of video player: play/pause (OK key), fast forward (press and hold right direction key) and rewind (press and hold left direction key). In video player interface, you can press * and # key to control volume.

Audio Player

You can use this function to play audio files. By pressing the direction key you can control the playing process of audio player: play/pause (OK key), switch to last song/next song (press left or right direction key), fast forward (press and hold right direction key) and rewind (press and hold left direction key). In audio player interface, you can press * and # key to control volume.

Recorder

The phone support WAV and AMR. The AMR takes the compression algorithm. So in the same memory condition, it has longer recording time than WAV.

FM radio

You can use the application as a traditional FM radio with automatic tuning and saved channels. Before using it, you should insert the earphone as antenna. In FM radio interface, left or right direction key to search

channels manually, OK key to play/pause the playing process of the current channel.

5.4 Contacts

The mobile phone can store up to 500 telephone numbers. The telephone numbers that a SIM card can store depends on the storage capacity of the SIM card. The telephone numbers stored in the mobile phone and in the SIM cards form a phonebook. The phonebook search function enables you to view contacts. You can search a contact as required from the phonebook. Select this option, in the **edit** interface, input the name of the contact you want to search or the first letter(s) of the name. All the contacts meeting the search condition are listed. Press the Up and Down direction keys to browse the contacts and select contact. Press right direction key to view other groups: SIM1/2, family, friends, business, classmates and so on.

This function enables you to view the internet. Your phone will ask you with existed way. You can start to view only by starting corresponding way.

Note: Consulting the local network operator for related fee and specific setup.

5.5 Audio

You can use this function to play audio files. By pressing the direction key you can control the playing process of audio player: play/pause (OK key), switch to last song/next song (press left or right direction key), fast forward (press and hold right direction key) and rewind (press and hold left direction key). In audio player interface, you can press * and # key to control volume.

5.6 Message

If the short message memory is full, a blinking message icon appears on the top of the screen. To

normally receive short messages, you need to delete some of the existing short messages.

If the destination user has received the short message you sent and the short message delivery report function is activated, the phone will give off a message report alert tone.

Write message

Access this menu to create a text message.

Inbox

Received Messages are listed in this menu.

Outbox

The messages which are sent failed are stored in the Outbox.

Drafts

Draft messages are listed in this menu.

Sent

Sent messages are listed in this menu.

Templates

You can create pre-defined messages in this interface.

5.7 File manager

The phone supports the memory card. The capacity of the memory card is selectable. You can use the file manager to conveniently manage various directories and files on the memory card or the phone.

Choose this option to enter the root directory of the memory. The root directory will list the default folders, new folders and user files. When the mobile phone is powered on for the first time or when you have not changed the directory, the root directory contains the default folders only.

5.8 Application

Bluetooth

You can transfer data, such as music to other device using Bluetooth. Search the device and receive/transfer data. The received data is automatically stored in the directory.

Alarm

You can set three alarms through this function.

Calendar

Once you enter this menu, there is a monthly-view calendar for you to keep track of important appointments, etc. Days with events entered will be marked.

Calculator

The calculator can add, subtract, multiply and divide.

World time

You can view and set your phone time by choose different time zones.

Stopwatch

You can use this function to record the time.

Unit conversion

You can switch the different units through this function in weight and length.

Torch

You can turn on/off the flashlight by this function.

5.9 Settings

Phone settings

- ◆ **Date & time:** Set the time, set the date, time format, date format and detail time of the location.

Note:** If you remove the battery from the mobile phone or if the battery energy was exhausted a long time ago, you may need to reset the date and time when re-inserting the battery or powering **on the mobile phone after recharging.

- ◆ **Language settings:** Select the display language and writing language for the mobile phone.
- ◆ **Shortcut settings:** Select preferred function as shortcut on screen direction key as needed.
- ◆ **Auto power on/off:** Set the time when the mobile phone will be automatically powered on or

off.

- ◆ **Power management:** you can view your battery status through this function.
- ◆ **Restore factory settings:** You can cancel the setting you set. The original code is 1234.

Display

Users can access this item to set Wallpaper, Idle display settings, Contrast, Backlight and Keypad backlight time etc.

Call Settings

- ◆ **Dual-SIM:** You can set standby mode, reply by original SIM, set SIM name and Set Dual Sys Call Forward through this function
- ◆ **Call Divert:** this network function enables you to forward incoming calls to another number you have previously specified.
- ◆ **Call Waiting:** After you choose Activate, the mobile phone will contact the network. A moment later, the network will make a response and send a message to acknowledge your operation. If the call waiting function is activated, the network will alert you and the mobile phone screen will display the incoming call number if others are calling you while you are already in a conversation.
- ◆ **Call Barring:** The call barring function enables you to bar calls as needed. When setting this function, you need to use a network barring code, which can be obtained from the network operator. If the code is wrong, an error message will be prompted on the screen. After selecting a call barring option, continue to select Activate or Deactivate. The mobile phone will prompt you to input the call barring

code and then contact the network. A moment later, the network will make a response and send the operation results to the mobile phone.

- ◆ **Hide ID:** You can select hide ID, display own ID and or display ID by network.
- ◆ **Others:** You can set blacklist, auto record, auto redial, call reminder, vibration when connected and reply SMS after reject through this function.

Security Settings

This function provides you with related settings about safety use

- ◆ **PIN:** To activate PIN lock, you need to input the correct PIN code. If you set PIN lock to On, you need to input the PIN each time you power on the mobile phone. In the case you input a wrong PIN for three consecutive times; you need to input the PIN Unblocking Key (PUK). The PUK is used to unlock and change the locked PIN. To obtain the PUK, contact the network operator.
- ◆ **Modify PIN2:** To change PIN2 code of PIN code.
- ◆ **Phone locked:** The function enables you to lock/unlock the phone. Entering password to switch on or off the phone. Password is required when the phone is locked. The initial password is 1234.
- ◆ **Modify the cell phone password:** to change phone password.
- ◆ **Privacy :** You can set password to protect your data security, the initial password is 1234.
- ◆ **Auto keypad lock:** The function enables you to lock/unlock the keypad. Set the auto locking time, 5s, 15s, 30s, 1min and 5mins are available.
- ◆ **Lock screen by end-key:** You can select to turn on/off this function.
- ◆ **Theftproof:** You can set password to protect your cell phone.

- ◆ **Fixed dialing:** you can only dial the number in the list.

Connections

Contact the network operator to obtain the following network services:

- ◆ **Network account:** You can manage network account through this function.
- ◆ **GPRS Service:** You can select to turn on/off this function.
- ◆ **Data connection settings:** The default setting is connecting when needed.
- ◆ **Network selection:** Set Network selection mode to Automatic or Manual. Automatic is recommended. When Network selection mode is set to Automatic, the mobile phone will prefer the network where the SIM card is registered. When Network selection mode is set to Manual, you need to select the network operator's network where the SIM card is registered.

5.10 Profiles

The mobile phone provides multiple user profiles, so that you can customize some settings to adapt to the specific events and environments.

Customize the user profiles according to your preference and then activate the user profiles. The user profiles fall into five scenarios: **Normal, Silent, meeting, Indoor, outdoor**. you can also save the Profiles if you like. In the standby mode long press # can switch scenarios.

5.11 Games

There is a game named snake, you can press direction keys to control the snake in the game.

5.12 Services

Internet

You can use the function to view web pages and search for information on the web before you connecting to the internet. When you open Internet, your home page opens. The web address (URL) of the current page is displayed at the top of the window.

STK

STK service is the tool kit of SIM card. This phone supports the service function .The specific items are depended by SIM card and network. Service menu will be auto added to the phone menu when supported by network and SIM card.

6Appendix

Appendix 1: Troubleshooting

If you find exceptions when operating the mobile phone, restore the factory settings and then refer to the following table to solve the problem. If the problem persists, contact the distributor or service provider.

Fault	Cause	Solution
SIM card error	The SIM card is damaged.	Contact your network service provider

	The SIM card is not in position.	Check the SIM card
	The metal face of the SIM card is polluted.	Clean the SIM card with a clean cloth
Poor received signal quality	Signals are obstructed. For instance, radio waves cannot be effectively transmitted nearby a high building or in a basement.	Move to a place where signals can be effectively transmitted

	Line congestions occur when you use the mobile phone in high-traffic hours	Avoid using the mobile phone in high-traffic hours
The mobile phone cannot be powered on	The battery energy is exhausted.	Charge the battery
Calls cannot be dialed	Call barring is activated	Cancel call barring

The mobile phone cannot connect the network	The SIM card is invalid	Contact your network service provider
	The mobile phone is not in a service area of the GSM network	Move to the network operator's service area
	The signal is weak	Move to a place where the signal quality is high
The battery cannot be charged	The charging voltage does not match the voltage range indicated on the charger	Ensure the charging voltage matches the voltage range indicated on the charger

	An improper charger is used	Use the charger specially designed for the mobile phone
	Poor contact	Ensure the charger plug is in good contact with the mobile phone

FCC Caution.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

§ 15.19 Labelling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

§ 15.21 Information to user.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Specific Absorption Rate (SAR) information:

This Mobile Phone meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health.

FCC RF Exposure Information and Statement The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. This device was tested for typical body-worn operations with the back of the handset kept 10mm for body worn. To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 10mm for body worn. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.

Body-worn Operation

This device was tested for typical body-worn operations. To comply with RF exposure requirements, a minimum separation distance of 10mm for body worn must be maintained between the user's body and the handset, including the antenna. Third-party belt-clips, holsters, and similar accessories used by this device should not contain any metallic components. Body-worn accessories that do not meet these requirements may not comply with RF exposure requirements and should be avoided. Use only the supplied or an approved antenna.