, P

Connect your AI Recorder using this WiFi SSID and password, making sure to keep them in a safe place for future reference.

Al Recorder (AIR-I, AIR-II)

Installation Guide 🕨





Al Recorder Overview



Road Facing Camera					
			DFC Bloc	ker Holder	*

★ AIR-II only

	SD Card Slot	Click x 1	Force power on
		Click x 3	Flip on WiFi Dire
	Pood Enging Comora	Press for 2s	Mark an Event
:= 0 = ;	Adjuster	Press for 8s	Restart the Carr
	Camera LED Network LED	Camera LED	
		Solid BLUE	
	Expansion LED ×	Solid RED	
	\	Blink BLUE	
Driver Facing Camera ★	IR Lights ★	Solid GREEN 5s to Restart	
		Solid RED	5s to Restart
		Blink BLUE a	nd RED

Network LED

Magic Button

Force power on

Restart the Camera

Flip on WiFi Direct Mode

Power On/Idle Recording Firmware Updating

Update Success

Update Fail

Error

Solid Green	Connected to the Server
Solid Blue	Connected to 4G but not the Server
Off	No network connections

Expansion LED

Solid Green	Expansions (Aux Cam) in working		
Off	No Expansions		

Install Waylens Fleet App to verify the AI Recorder installation

The Waylens Fleet App is the companion to the Al Recorder, providing the fleet administrator with an easy way to install, maintain, and diagnose the AI Recorder.



Do not use mobile devices to access the AI Recorder while operating the vehicle. Park your vehicle in a safe location before accessing the App. Simply connect to the wifi network broadcasted by the AI recorder and then open the Waylens Fleet App. The wifi network name and password can be located on the camera label, or on the back of this installation guide.

Installing your AI Recorder

Park the car in a safe and convenient place for the installation

1 Insert the microSD card (if not already installed)

Remove the Security Panel, if needed unlock it using L-Shaped Torx Flat Screwdriver provided. A microSD card will be automatically formatted the first time it was inserted into an AI Recorder.



Waylens requires a high endurance micro SD card (class 10 or higher MLC microSD card 32-512 GB), designed for continuous recording applications. While other cards will technically work with the AI Recorder, they are much more prone to card errors and failures.

2 Install power in the vehicle

Direct Wire Power Cord

1. Make sure the vehicle is off.

2. Find the location and layout of your fuse box as well as the appropriate fuse type from the vehicle's user manual.

IMPORTANT NOTE:

The recorder should only be wired on a fuse circuit which is non-essential. The users should never install the recorder on any safety system such as airbag, anti-lock braking systems, vehicle lights, driver assistance systems.

NOTE:

Professional installation assistance is recommended, if you are not familiar with identifying fuses in a vehicle and installing power system related items.

3. Connect the white ACC wire to a switched fuse via Fuse Tap Cable:

- a. A switched fuse is used to monitor the accessory power such as cigarette lighter, car radio, etc. They will be switched off after you turn off the car. Identify them by referring to the vehicle user manual or consulting a qualified professional.
- b. Verify the fuse is a switched fuse by using a multimeter to track voltage within the circuit across ignitions ON and OFF positions.





c. If confirmed as a switched power fuse, remove the identified switched fuse from the fuse panel. Use the fuse puller tool if available.

d. Select the right Fuse Tap Cable for your vehicle.



e. Insert the supplied 5 Amp fuse to the socket 2 if it's not inserted yet.

f. Insert the identified vehicle fuse into slot 3 on the Fuse Tap Cable.

NOTE:

7

The supplied 5Amp fuse MUST be placed in the uppermost socket, as shown below. Inline with the red cable. The original vehicle fuse is to be placed in the lower socket.



g. Insert the Fuse Tap Cable into the fuse panel carefully.

h. Insert the exposed ACC wire from the camera harness into the Fuse Tap Cable connector and crimp to secure the connection.



4. Connect the red B+ wire to a constant power fuse via Fuse Tap Cable.

- a. The constant power fuses are used to monitor constant power within a vehicle. They will not be switched off after you turn off the car. Identify them by referring to the vehicle manual or consulting a professional.
- b. Verify the fuse is a constant fuse by a multimeter to track voltage within the circuit across ignitions ON and OFF positions.
- c. If confirmed as a constant power fuse, remove the identified constant fuse from the fuse panel. Use the fuse puller tool if available.
- d. Refer steps 3.d to 3.h for the Fuse Tap Cable usage and connection. Ensure working on the yellow B+ wire and the right constant power fuse.
- 5. Connect the black GND wire to a chassis ground point, such as a bolt, that is directly touching a bare metal surface of the vehicle's chassis.
- 6. Route the wire with USB Type-C plug of the Direct Wire Power Cord to the expected camera mounting location on the windshield.



IMPORTANT NOTE:

If your vehicle has side impact airbags, make sure the harness does not interfere with its ability to deploy. **NOTE:**

Leave an extra few inches of cord length near the camera to insert the Type-C plug into the AI Recorder's Power socket, and also to make mounting and dismounting the AI Recorder easie

7. Secure any excess wire after the recorder is mounted.

OBD-II Power Cord (Optional)



1. Locate the OBD-II socket in your vehicle, the upper figure shows some popular places.

2. Insert the OBD-II plug into the OBD-II socket firmly.

NOTE:

The OBD-II connector fits only one way into the vehicle's OBD-II socket, do not force the fit; observe correct orientation before applying force.

9

3. Route the wire with USB Type-C plug of the OBD-II Power Cord to the expected recorder mounting location on the windshield.

NOTE:

Leave an extra few inches of cord length near the recorder to insert the Type-C plug into the AI Recorder, and also to make mounting and dismounting the recorder easier.

4. Secure any excess wire after the recorder is mounted.

If your vehicle is also using an OBD Telematics Unit, you may also need to add an in-line Y Adapter Cable for both devices to connect to the vehicle BUS system.

J1939 Power Cord



1. Locate the J1939 socket in your vehicle, normally it's in the left knee place.

2. Insert the J1939 Plug into the socket firmly.

NOTE:

The J1939 connector fits only one way to the vehicle's J1939 socket, do not force the fit; observe correct orientation before applying force.

3. Route the wire with USB Type-C plug of the J1939 Power Cord to the expected recorder mounting location on the windshield.

NOTE:

Leave an extra few inches of cord length near the recorder to insert the Type-C plug into the AI Recorder, and also to make mounting and dismounting the recorder easier.

4. Secure any excess wire after the recorder is mounted.

If your vehicle is also using a J1939 Telematics Unit, you may also need to add an in-line Y Adapter Cable for both devices to connect to the vehicle BUS system.

③ Connect power to the AI Recorder

For optimal performance, please ensure the power cord is firmly and securely fitted into the recorder Power Socket.

- 1. Insert the Type-C plug into the AI Recorder Power Socket.
- 3. Turn on the vehicle, the camera LED will illuminate blue and then turn red if a SD card is inserted.
- 4. Using Waylens Fleet APP do a Power Test.
- If Camera LED do not turn red or there's SD error message shown on the Waylens Fleet App screen, try to change a good SD card or pull-out/reinsert SD card.
- 6. Put the Security Panel in the place if Power Test is past and no SD card error in Waylens Fleet App.
- 7. Lock the Security Panel with the torx screws provided.



4 Mount the AI Recorder Mount Plate/Wedge Mount Plate

- 1. Find a suitable location: the common location is near rearview mirror on the windshield. To ensure enough room around location the AI Recorder can be attached (following step 5) before mounting the plate.
- 2. Clean the windshield surface first with a wet wipe and then a dry wipe.
- 3. Choose the right mount plate based on the vehicle windshield's inclination: for those vertical windshield such as the one on those heavy duty vehicles, please use the flat AI Recorder Mount Plate, for those sloped windshield please choose the AI Recorder Wedge Mount Plate.
- 4. Remove 3M stickers to expose AI Recorder Mount Plate's adhesive.
- 5. Attach AI Recorder Mount Plate to windshield.
- 6. Press firmly on top and bottom to adhere it securely.

IMPORTANT NOTE:

The installation location of your camera needs to comply with state and federal regulations. Please contact your supplier for details if you are unsure.

NOTE:

1.The flat Mount Plate is already on the Al Recorder and need to remove it if want to use the wedge Mount

2.To Remove the Mount Plate, place two thumbs on the mount plate and applying downward pressure to detach it from the the AI Recorder"



S Attach the AI Recorder to the Mount Plate/the Wedge Mount Plate

Please choose the right mount plate based on the rake of the windshield.



With the Mount Plate/the Wedge Mount Plate attached to the windshield and the power cord connected to the Al Recorder, position the Al Recorder on the upside of the Mount Plate/the Wedge Mount Plate. Next, ensure the Mount Plate. Next, ensure the Mount Plate/the Wedge Mount Plate locking tabs are aligned with their fittings on the recorder.

6 Adjust Road Facing Camera orientation



To operate properly, the Road Facing Camera (RFC) should point horizontally. To do that, adjust the RFC Adjuster and make the dial slot horizontal while the small camera icon facing front.



Slide the recorder down to secure it firmly onto the Mount Plate/the Wedge Mount Plate.

Please ensure the AI Recorder is installed properly and firmly attached to the windshield prior to operating the vehicle. Be sure to make any adjustments to the angle or position of the recorder prior to operating the vehicle. Verify the view by the Waylens Fleet App.



O Adjust Driver Facing Camera orientation



The Driver Facing Camera's pitch and yaw can be adjusted directly. Remove the Driver Privacy Cover, using finger directly adjust the Driver Facing Camera. Adjust the camera angle so that its horizontally parallel to the vehicle cabin.

Verify the view by the Waylens Fleet App.





Inserting the Driver Privacy Cover top edge into the slot, press it into the place, and then secure it with screws provided.

FCC Statement

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment .This equipment should be installed and operated with minimum distance 20cm between the radiator& your body.

Note : This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.

—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.