


Size: 210x125mm



Button Description

⏻ On/off: Press and hold the on/off button for a few seconds to switch the unit on or off.

LED light: The LED flashes white when it is searching for a Bluetooth connection. The LED lights up when the music is playing. The LED pulses when the music is paused. Double press on/off button, white LED light flashing, double press on/off button again turns the white light off.

Charging: The red LED is on when charging and turns off when fully charged.

Bluetooth Pairing

Press and hold the On/Off switch for 4 seconds until the light is flashing white.

Search for "MINI SPEAKER" in the bluetooth menu on your device.

Pair your device with "MINI SPEAKER"

502030 250mAh battery

Recharge Voltage: 3.7V

Playback Time: approximately 2 hours

Loudspeaker: 4Ω3W

Frequency Response: 280Hz-16Hz

Connection Distance: 25ft

Recharge Time: 1hr

Product Dimensions: 49 x 49 x (h) 51 mm

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

MADE IN CHINA