onn.

Compact Wireless Keyboard

Model: TAAKYB100042338

USER MANUAL

Important Safety Instructions



This keyboard is not a toy. Keep away from children. Read and follow all instructions and warnings before use.

- Check the keyboard and lead-zinc batteries before use. If any parts are damaged, contact Technical Support before resuming
- Do not open, disassemble, modify, drop, crush, puncture. incinerate, or shred the Bluetooth® keyboard.
- The keyboard is not serviceable. Do not attempt to open,
- To prevent a short circuit or other potential hazards, do not insert foreign metal objects into the keyboard or its ports.
- Keen the keyboard away from moisture and do not use it with wet hands. Moisture in or on the keyboard may lead to electrical shock. If exposed to moisture during use, turn off and unplug the charging cable immediately. Contact Technical Support before resuming use.
- The keyboard contains two lead-zinc batteries. Keep away from heat sources and open flames.
- It is normal for the keyboard to become warm during operation. To prevent overheating, keep the area around the keyboard ventilated. Do not place anything on or around the keyboard during operation.
- Do not operate the keyboard near a heat source or in direct sunlight. Recommended for use in temperatures between -5°C and 50°C. NEVER use in temperatures outside the range
- If the keyboard begins to emit a strong odor, becomes hot to the touch, swells or expands, turn it off and unplug the

keyboard immediately and contact Technical Support.

- If the battery inside the keyboard leaks for any reason, turn off and unplug the keyboard immediately.
- Do not allow the contents of the battery to contact your skin of eves. In the event of contact, wash the affected area with large amounts of water and seek medical attention immediately
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable (ni-cad, ni-mh, etc.) batteries.

CARE AND STORAGE

- Do not store your keyboard in areas of high temperatures (such as in your car) or high humidity.
- Do not place heavy objects on top of the keyboard.
- Keep the keyboard away from oil, chemicals, and
- Clean the keyboard with a damp clean cloth.

DISPOSAL

- Do not burn or dispose of your keyboard in a fire or incinerator.
- · Do not throw your keyboard away in the trash. The keyboard contains two lead-zinc batteries. Contact your local electronics recycler to recycle the kevboard.

What's in the Box

- Compact Wireless Keyboard
- AAA Battery x 2




At a Glance

4. Stand



- Bluetooth Status Indicators
- 2. Power / Caps Lock Indicator
- 3. Power Switch
- 5. Battery Compartment

Keys and Functions



Note: Some applications or operating systems may have different key bindings.

Functionality | Functionality | Functionality on Windows

> Next Track Next Track

> > Volume -

Volume+

Screenshot

Kevs and Functions

Play/Pause Play/Pause Play/Pause


Volume +

LED Indicator Guide

LED Status Description Indicator Solid green Powered on Caps function Lock Indicator Low battery Flashes red Ready for Flashes blue Bluetooth1/2/3 Indicator successfully

Powering On Your Keyboard

1. Insert the provided AAA batteries into the battery compartment on the back panel of the keyboard.



2. Slide the power switch down to power on the keyboard. The power indicator will turn solid green and turn off after 3 seconds.

Note: The keyboard will enter sleep mode after being idle for 30 minutes.

March 16,2021_V1

Pairing Your Wireless Keyboard with Your Devices

Pair your keyboard with the first device

1.Power on your keyboard. The Bluetooth channel (191 indicator will flash blue quickly, indicating that the keyboard is ready for pairing automatically.

2. Enable your device's Bluetooth function. A list of available Bluetooth devices will display.

Select "Compact Wireless Keyboard" to pair.

The indicator will turn solid blue after the first device is successfully paired with your keyboard.

TAAKYB100042338



We're here for you every day from 7 a.m. - 9 p.m. CST.

We'd love to hear from you. Scan with your Walmart app

Give us a call at 1-888-516-2630

and let us know what you think

Need help?

Pairing Your Wireless Keyboard with Your Devices

Pair your keyboard with a second or third device

To pair your keyboard with a second device:

1. Press Fn + W. The indicator <a>2 will flash blue, indicating the keyboard is ready for pairing.

2. Repeat the Step 3 in the "Pair your keyboard with the first device" section to pair your keyboard with the second device.

To pair your keyboard with a third device:


- 1. Press Fn + F. The indicator §3 will flash blue. indicating the keyboard is ready for pairing.
- 2. Repeat the Step 3 in the "Pair your keyboard with the first device" section to pair your keyboard with the third device.


Note:To switch between the first / second / third paired device, press Fn + Q ((31) / W ((32) / E ((33) simultaneously. Your paired device will automatically connect to the corresponding channel.

To remove the paired memory and pair a new device. press Fn + Q ($\S1$) / W($\S2$) / E ($\S3$). Then press Fn + C to enter pairing status again.

Using the Stand

Open the cover and pull the stand out until it sits on vour desk.





Specifications 2.0V - 3.2V Operating Voltage 30 mA (Max) Operating Current Battery Type 2 x AAA LRO3 1.5V < 7.3 m Operating Range Operating -5°C to 50°C Temperature BT 5.1 (BDR) Bluetooth Version

Notice

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (This device may not cause harmful interference, and (2) this device must accept any interference received. including interference that may cause undesired

approved by the party responsible for compliance could

Warning: Changes or modifications not expressly

void the user's authority to operate the equipment. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against

harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures

Notice

- (1) Reorient or relocate the receiving antenna.
- (2) Increase the separation between the equipment and receiver. (3) Connect the equipment into an outlet on a circuit
- different from that to which the receiver is connected. (4) Consult the dealer or an experienced radio / TV
- Radiation Exposure Statement

technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

CAUTION

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS

Changes or modifications not expressly approved by the manufacturer responsible for compliance could void the user's authority to operate the equipment.



The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth

SIG. Inc. and any use of such marks by Walmart Inc. is under license.