


# U25 说明书五折页

总尺寸:325\*100mm 折后尺寸:65\*100mm

材质:105g铜版纸










Thank you for choosing PAMBEE's portable, wireless, fast charging power bank! We are confident in our product's reliability and quality. Please carefully read through this manual before attempting to use the product and keep it handy for further reference.

#### **Product Description**



#### **Package Contents**









#### **Specifications**

Model	U25
USB-C Input	5V=3A, 9V=2A , 12V=1.5A
USB-C Output	5V=3A, 9V=3A, 12V=2.5A, 15V=2A
Wireless Output	5W / 7.5W/ 10W / 15W
Battery Type	Lithium Polymer
Battery Capacity	10000mAh / 3.7V/37Wh
Rated Capacity	5800mAh (5V=2.4A)
Size	4.27x2.78x0.82in / 108.5x70.6x20.8mm
Weight	7.76 oz / 220g


#### **Operating Instructions**

Note: When USB-C port and wireless charge output at the same time, wireless charge output automatically off mode, priority support for C port output.


#### 1. Charging the Power Bank

Connect the USB-C connector of the supplied cable to the Power Bank device.

The two possibilities for the Power Bank device are: an AC charger as seen in picture (1), or a computer USB-C port as seen in picture (2). The other end of the supplied charging cable should be plugged into the USB-C port of the Power




Picture (1)



 $\textcircled{\scriptsize 1}.$  Auto positioning: Powered on. The mobile and the power bank are magnetically adsorbed and automatically positioned, then wireless charging is turned on with a snap.
②. Short-press: Power on (the light displays), then wireless

Model: U25





#### 3. Power off

① Double-click the button and wait for 5-8 seconds. ② When the mobile Power Bank is in the no-load state (without charging any external devices), the digital tube power indicator automatically shuts down after 40 seconds.

#### 4. Low-current mode

- ① Enter/exit low current mode: To enter / exit low-current mode hold down the power button for 5 seconds.
- 2 Low current mode indicator: to show that it has entered the low current mode the power display screen will show a turning circle for 5 seconds.
- 3 Low current mode function: the low current mode is suitable for charging Bluetooth headsets and other small current using devices.

#### 5. Description of power display

 $\ \, \textcircled{1}$  Digital tube charging indicator: When the digital tube is charging, the digital power display flashes. When the power level is 100%, the digital power display instress. When the power level is 100%, the digital power display is steady on.

② Digital tube discharge indicator: When the power is greater than 0%, the digital tube remains lit. When the power level is 0%, the digital power display turns off.



- This wireless charger is not compatible with non-MagSafe phone cases, such as Otterbox Defender cases.
- Wireless chargers make charging more convenient than wired chargers, but confined by current wireless technology. their charging speed is slower than that of wired chargers.
- Do not use an adapter with an output of 20W or less.
- High temperatures will reduce charging speed and restrict power, which is something that happens to all wireless chargers. It is recommended that you charge your device in environments with temperatures be between 0°C to
- Both the protective phone case and the position of your device on the wireless charger will affect the charging speed. The farther it is placed from the center of the wireless charger, the slower the charging speed will be.

### **Important Safety Instructions**

When using this product, basic precautions should always

- be followed, including the following:

  1) Store the product in a cool, dry place.
- 2) Do not store the product in a hot or humid env.
  3) Do not dispose of the product in heat or fire.
- 4) Do not clean the product with harmful chemicals or
- detergents. 5) Operating temperature should be between 0°C to 45°C /
- 32°F to 113°F. 6) Do not disassemble the product. Take it to a qualified
- service person when service or repair is required Incorrect reassembly may result in a risk of fire or injury to
- 7) If the product is not used for long periods of time, you should charge and discharge it once every three months. 8) When charging a device, the product may feel warm. This is a normal operating condition and should not be a
- cause for concern.

  9) In normal conditions, the battery performance will decline
- 10) Misuse, dropping, or excessive force may cause product
- 11) When disposing of secondary cells or batteries, keep cells or batteries of different electrochemical systems
- 12) Be aware that a discharged battery may cause fire or smoke. Tape the terminals to insulate them

#### **FAQs**

#### Q: Can this be used with any phone other than an iPhone?

A: This magnetic power bank is designed specifically to charge the iPhone series phones. Only iPhone series phones support magnetic charging. Nevertheless, you can only use the USB-C port to charge other USB-C devices, or use the magnetic attraction ring to attach to other phone models that have wireless charging, however the charging speed

#### Q: What is the wattage of this power bank?

A: This wireless power bank charges the iPhone series phones with a maximum output of 15W.

## Q: Will the wireless magnetism work if the phone has a

A: This magnetic wireless charging mobile power can work well with the magsafe iPhone series phone case. If you use a normal case, the magnetic force will be very weak. For that reason, it is generally advised that it will not be effective

#### Q: Is it normal for the battery to heat up when charging? A: Compared to conventional charging devices, wireless technology charging devices tend to cause slight heat generation. However, this temperature is within the normal operating temperature range of the phone, so please feel

free to use it despite it being slightly hotter.

#### **FCC Statement**

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

• Reorient or relocate the receiving antenna.

• Increase the separation between the equipment and receiver.

• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

• Consult the dealer or an experienced radio/TV technician for help. This equipment generates uses and can radiate radio frequency

RF exposure compliance statement:

1.The device has been evaluated to meet general RF exposure

The device has been evaluated to meet general Hr exposure requirement.
The device can be used in portable exposure ontition without restriction. Equipment system maintenance is simple, please refer to the manual.
The user can take simple measures to correct the interference.
Such as stayling away from interference sources, turing off interference sources, etc









