

2 Maximum power spectral density

Condition	Mode	Frequency (MHz)	Antenna	Conducted PSD (dBm)	Duty Factor (dB)	Total PSD (dBm)	Limit (dBm)	Verdict
NVNT	a	5180	Ant1	1	0.58	1.58	11-1.19=9.81	Pass
NVNT	a	5200	Ant1	1.1	0.59	1.69	11-1.19=9.81	Pass
NVNT	a	5240	Ant1	1.27	0.58	1.85	11-1.19=9.81	Pass
NVNT	a	5260	Ant1	1.45	0.58	2.03	11-1.19=9.81	Pass
NVNT	a	5280	Ant1	1.52	0.59	2.11	11-1.19=9.81	Pass
NVNT	a	5320	Ant1	1.51	0.59	2.1	11-1.19=9.81	Pass
NVNT	a	5500	Ant1	3.32	0.59	3.91	11-1.19=9.81	Pass
NVNT	a	5600	Ant1	2.68	0.58	3.26	11-1.19=9.81	Pass
NVNT	a	5700	Ant1	2.53	0.58	3.11	11-1.19=9.81	Pass
NVNT	a	5720	Ant1	2.06	0.59	2.65	11-1.19=9.81	Pass
NVNT	a	5745	Ant1	-1.21	0.59	-0.62	28.81	Pass
NVNT	a	5785	Ant1	-1.7	0.59	-1.11	28.81	Pass
NVNT	a	5825	Ant1	-1.72	0.59	-1.13	28.81	Pass
NVNT	n20	5180	Ant1	0.87	0.62	1.49	11-1.19=9.81	Pass
NVNT	n20	5200	Ant1	0.65	0.62	1.27	11-1.19=9.81	Pass
NVNT	n20	5240	Ant1	1.25	0.62	1.87	11-1.19=9.81	Pass
NVNT	n20	5260	Ant1	1.45	0.62	2.07	11-1.19=9.81	Pass
NVNT	n20	5280	Ant1	1.49	0.62	2.11	11-1.19=9.81	Pass
NVNT	n20	5320	Ant1	1.11	0.62	1.73	11-1.19=9.81	Pass
NVNT	n20	5500	Ant1	2.88	0.62	3.5	11-1.19=9.81	Pass
NVNT	n20	5600	Ant1	3.13	0.62	3.75	11-1.19=9.81	Pass
NVNT	n20	5700	Ant1	2.07	0.62	2.69	11-1.19=9.81	Pass
NVNT	n20	5720	Ant1	1.78	0.62	2.4	11-1.19=9.81	Pass
NVNT	n20	5745	Ant1	-1.18	0.62	-0.56	28.81	Pass
NVNT	n20	5785	Ant1	-2.08	0.63	-1.45	28.81	Pass
NVNT	n20	5825	Ant1	-1.74	0.63	-1.11	28.81	Pass
NVNT	n40	5190	Ant1	-1.9	1.47	-0.43	11-1.19=9.81	Pass
NVNT	n40	5230	Ant1	-0.8	1.46	0.66	11-1.19=9.81	Pass
NVNT	n40	5270	Ant1	-0.79	1.17	0.38	11-1.19=9.81	Pass
NVNT	n40	5310	Ant1	-0.98	1.17	0.19	11-1.19=9.81	Pass
NVNT	n40	5510	Ant1	0.62	1.17	1.79	11-1.19=9.81	Pass
NVNT	n40	5590	Ant1	0.76	1.16	1.92	11-1.19=9.81	Pass
NVNT	n40	5670	Ant1	-0.3	1.17	0.87	11-1.19=9.81	Pass
NVNT	n40	5710	Ant1	-0.35	1.17	0.82	11-1.19=9.81	Pass
NVNT	n40	5755	Ant1	-4.01	1.18	-2.83	28.81	Pass
NVNT	n40	5795	Ant1	-4.52	1.18	-3.34	28.81	Pass
NVNT	ac20	5180	Ant1	0.42	0.79	1.21	11-1.19=9.81	Pass
NVNT	ac20	5200	Ant1	0.62	0.8	1.42	11-1.19=9.81	Pass
NVNT	ac20	5240	Ant1	1.16	0.79	1.95	11-1.19=9.81	Pass
NVNT	ac20	5260	Ant1	1.18	0.79	1.97	11-1.19=9.81	Pass
NVNT	ac20	5280	Ant1	1.05	0.79	1.84	11-1.19=9.81	Pass
NVNT	ac20	5320	Ant1	1.37	0.8	2.17	11-1.19=9.81	Pass
NVNT	ac20	5500	Ant1	3.04	0.8	3.84	11-1.19=9.81	Pass
NVNT	ac20	5600	Ant1	2.63	0.79	3.42	11-1.19=9.81	Pass
NVNT	ac20	5700	Ant1	2.43	0.79	3.22	11-1.19=9.81	Pass
NVNT	ac20	5720	Ant1	1.94	0.79	2.73	11-1.19=9.81	Pass
NVNT	ac20	5745	Ant1	-1.45	0.8	-0.65	28.81	Pass
NVNT	ac20	5785	Ant1	-1.86	0.8	-1.06	28.81	Pass
NVNT	ac20	5825	Ant1	-2.08	0.8	-1.28	28.81	Pass
NVNT	ac40	5190	Ant1	-1.47	1.45	-0.02	11-1.19=9.81	Pass
NVNT	ac40	5230	Ant1	-0.74	1.46	0.72	11-1.19=9.81	Pass



NVNT	ac40	5270	Ant1	-0.53	1.46	0.93	11-1.19=9.81	Pass
NVNT	ac40	5310	Ant1	-1.27	1.46	0.19	11-1.19=9.81	Pass
NVNT	ac40	5510	Ant1	0.48	1.46	1.94	11-1.19=9.81	Pass
NVNT	ac40	5590	Ant1	0.6	1.46	2.06	11-1.19=9.81	Pass
NVNT	ac40	5670	Ant1	-0.59	1.45	0.86	11-1.19=9.81	Pass
NVNT	ac40	5710	Ant1	-0.46	1.45	0.99	11-1.19=9.81	Pass
NVNT	ac40	5755	Ant1	-4.06	1.46	-2.6	28.81	Pass
NVNT	ac40	5795	Ant1	-4.52	1.47	-3.05	28.81	Pass
NVNT	ac80	5210	Ant1	-4.86	2.53	-2.33	11-1.19=9.81	Pass
NVNT	ac80	5290	Ant1	-4.8	2.53	-2.27	11-1.19=9.81	Pass
NVNT	ac80	5530	Ant1	-2.93	2.52	-0.41	11-1.19=9.81	Pass
NVNT	ac80	5610	Ant1	-3.68	2.53	-1.15	11-1.19=9.81	Pass
NVNT	ac80	5690	Ant1	-4.36	2.52	-1.84	11-1.19=9.81	Pass
NVNT	ac80	5775	Ant1	-7.72	2.55	-5.17	28.81	Pass











































