



# rPODU

## WIRELESS WALL SWITCH

### FAMILY INSTRUCTIONS



Expanding the boundaries of lighting™



TITLE 20/24

Full warranty terms located at: [www.acuitybrands.com/CustomerResources/Terms\\_and\\_conditions.aspx](http://www.acuitybrands.com/CustomerResources/Terms_and_conditions.aspx)

Note: Specifications subject to change without notice.

Actual performance may differ as a result of end-user environment and application.

#### WARRANTY

5-year limited warranty.

- To reduce the risk of death, personal injury or property damage from fire, electric shock, falling parts, cuts/abrasions, and other hazards please read all warnings and instructions included with and on the fixture box and all fixture labels.
- Before installing, servicing, or performing routine maintenance upon this equipment, follow these general precautions.
- Installation and service should be performed by a qualified licensed electrician.
- Maintenance should be performed by qualified person(s) familiar with the products' construction & operation & any hazards involved. Regular maintenance programs recommended.
- To be installed to a circuit with overvoltage control to Overvoltage category Cat.III or less, minimum suppression rating 6.0 kV for a 600 V ac rms system voltage
- **DO NOT INSTALL DAMAGED PRODUCT!** This product has been properly packed so that no parts should have been damaged during transit. Inspect to confirm. Any part damaged or broken during or after assembly should be replaced.

<b>CAUTION - RISK OF PRODUCT DAMAGE</b> <ul style="list-style-type: none"><li>✓ Electrostatic Discharge (ESD): ESD can damage product(s). Personal grounding equipment should be worn during all installation or servicing of the unit.</li><li>✓ Do not touch individual electrical components, as this can cause ESD and affect product performance.</li><li>✓ Do not stretch or use cable sets that are too short or are of insufficient length.</li><li>✓ Do not tamper with contacts.</li><li>✓ Do not modify the product.</li><li>✓ Do not change or alter internal wiring or installation circuitry.</li><li>✓ Do not use product for anything other than its intended use.</li></ul>	<b>WARNING - RISK OF ELECTRIC SHOCK</b> <ul style="list-style-type: none"><li>✓ Disconnect or turn off power before installation or servicing.</li><li>✓ Verify that supply voltage is correct by comparing it with the product information.</li><li>✓ Make all electrical and grounded connections in accordance with the National Electrical Code (NEC) and any applicable local code requirements.</li><li>✓ All wiring connections should be capped with UL approved recognized wire connectors.</li><li>✓ All unused connector openings must be capped.</li></ul>	<b>WARNING - RISK OF BURN or FIRE</b> <ul style="list-style-type: none"><li>✓ Do not exceed maximum wattage, ratings, or published operation conditions of product.</li><li>✓ Do not overload.</li><li>✓ Follow all manufacturer's warnings, recommendations and restrictions to ensure proper operation of product.</li></ul> <b>CAUTION - RISK OF INJURY</b> <ul style="list-style-type: none"><li>✓ Wear gloves and safety glasses at all times when installing, servicing or performing maintenance.</li></ul>
--	--	---

FCC ID: 2ADCB-RPODU

IC: 6715C-RPODU

Acuity Brands Lighting Inc. RPODU

In order to avoid the possibility of exceeding the FCC radio frequency exposure limits, human proximity to the radiator shall not be less than 20cm during normal operation.

NOTE: THE GRANTEE IS NOT RESPONSIBLE FOR ANY CHANGES OR MODIFICATIONS NOT EXPRESSLY APPROVED BY THE PARTY RESPONSIBLE FOR COMPLIANCE. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

1. This device may not cause interference.
2. This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

1. L'appareil ne doit pas produire de brouillage, et
2. L'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

La operación de este equipo está sujeta a las siguientes dos condiciones: (1) es posible que este equipo o dispositivo no cause interferencia perjudicial y (2) este equipo o dispositivo debe aceptar cualquier interferencia, incluyendo la que pueda causar su operación no deseada.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

1. Reorient or relocate the receiving antenna.
2. Increase the separation between the equipment and receiver.
3. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
4. Consult the dealer or an experienced radio/TV technician for help.

**IMPORTANT SAFEGUARDS**  
WHEN USING ELECTRICAL EQUIPMENT, BASIC SAFETY PRECAUTIONS SHOULD ALWAYS BE FOLLOWED INCLUDING THE FOLLOWING:

- **DO NOT USE OUTDOORS.**
- **DO NOT MOUNT NEAR GAS OR ELECTRIC HEATERS.**
- **EQUIPMENT SHOULD BE MOUNTED IN LOCATIONS AND AT HEIGHTS WHERE IT WILL NOT READILY BE SUBJECTED TO TAMPERING BY UNAUTHORIZED PERSONNEL.**
- **THE USE OF ACCESSORY EQUIPMENT NOT RECOMMENDED BY THE MANUFACTURER MAY CAUSE AN UNSAFE CONDITION.**

**READ AND FOLLOW ALL SAFETY INSTRUCTIONS!**  
**SAVE THESE INSTRUCTIONS AND DELIVER TO OWNER AFTER INSTALLATION**

### Wall Surface Installation (NMO Option)

1. Remove the adhesive liner.
2. Press and hold device in desired location for 30 seconds.

### Wall Surface Removal (NMO Option)

1. Slide rPODU wall switch upward to release from the backplate.
2. Grasp exposed pull tab and pull upward along wall surface, not away from wall surface, until the adhesive releases fully. Adhesive may stretch up to 8 inches before releasing.