Ai Box3.0 S User Manual





catalogue

	Z
1. Product introduction	4
1.1 Product features	5
1.2 Product specification	7
1.3 Screen Dimension Figure (mm)	8
1.4 standard packaging	9
2. Product Installation	10
2.1 Installation guide	10
2.2 Installation method of moving	10
2.3 Installation method of wall-mounted	16
3. Power on and off Guidance	22
3.1 Power-on steps	22
3.2 Power-off steps	23
3.3 Standby steps	24
4. Description of Remote Control	24
4.1Remote control button description	24
4.2 Remote control matching guide	25
5. Initial Setup	26
6. Novice Guide	
6.1 Remote control guide	
6.2 Wireless display adapter guide	
6.3 IOS/MAC display guide	
6.4 Software display guide	
7. Display Guide	
7.1 Wireless display	
7.2 Signal source access	46
8. Signal Source Switching	46
8.1 Presentation	46
	10
8.2 Remote control menu	46
8.2 Remote control menu 8.3 Remote Control Signal Source Switching	46
8.2 Remote control menu8.3 Remote Control Signal Source Switching9. Display Effect Settings	46 47 48
 8.2 Remote control menu 8.3 Remote Control Signal Source Switching 9. Display Effect Settings 9.1 Scene mode 	
 8.2 Remote control menu 8.3 Remote Control Signal Source Switching 9. Display Effect Settings 9.1 Scene mode 9.2 Custom display effect 	46 47 48 48 48
 8.2 Remote control menu	
 8.2 Remote control menu	46 47 48 48 48 49 50 50 51 52 57 57 59 59
 8.2 Remote control menu	46 47 48 48 48 49 50 50 51 52 57 57 59 59 68
 8.2 Remote control menu	46 47 48 48 49 50 51 52 57 57 59 59 68 75
 8.2 Remote control menu	46 47 48 48 49 50 50 51 52 57 59 59 68 75 75 77
 8.2 Remote control menu	46 47 48 48 49 50 51 52 57 59 59 59 68 75 77 77
 8.2 Remote control menu	46 47 48 48 49 50 51 51 52 57 59 59 59 68 75 77 77 77 77



Safety Information



WARNING!

Please read the safety measures listed in this section carefully before installing, powering on, operating, or doing maintenance on this product.

The following marks on the product and in this manual indicate important safety measures.





Safety rak! Might cause equipment damage or safety risk.

WARNING/ Please read the manual before operating.

WARNING Dangerous voltage! Might cause equipment damage or elector shock



WARNINGI WARNING Pot surfacel Flammable Do not louch



fo eyes.



WARNING: Be sure to understand and follow all safety guidelines, safety instructions, warnings and precautions listed in this manual.

This product is for professional use only!

This product may result in serious injury or death due to fire hazard, electric shock, and crushing hazard.



Please read this manual carefully before installing, powering up, operating and maintenance of this product.

Follow safety instructions in this manual and on the product. If you have any questions, please seek help from Absen.



Beware of Electric Shock!

• To prevent electric shock the device must be properly grounded during installation. Do not ignore using the grounding plug, or else there is a risk of electric shock.

• During a lightning storm, please disconnect the device's power supply, or provide other suitable lightning protection. If the equipment is not in use for a long time, please unplug the power cord.

• When performing any installation or maintenance work (e.g. removing the fuses, etc.,) make sure to turn off the master switch.

• Disconnect AC power when the product is not in use, or before disassembling, or installing the product.

• The AC power used in this product must comply with local building and electric codes, and should be equipped with overload and ground fault protection.

• The main power switch should be installed at a location near the product and should be clearly visible and easily reached. This way in case of any failure the power can be promptly disconnected.

• Before using this product check all electrical distribution equipment, cables and all connected devices, and make sure all meet current requirements.

• Use appropriate power cords. Please select the appropriate power cord according to the required power and current capacity, and ensure the power cord is not damaged, aged or wet. If any overheating occurs, replace power cord immediately.

• For any other questions, please consult a professional.





Beware of Fire!

- Use a circuit breaker or fuse protection to avoid fire caused by power supply cables overloading.
- Maintain good ventilation around the display screen, controller, power supply and other
- devices, and keep a minimum 0.1 meter gap with other objects.
- Do not stick or hang anything on the screen.



 \triangle





- Do not modify the product, do not add or remove parts.
- Do not use the product in case ambient temperature is over 55 $\,\,^{\circ}\!\mathrm{C}.$

Beware of Injury!

- Warning: Wear a helmet to avoid injury.
- Ensure any structures used to support, fix and connect the equipment can withstand at least 10 times the weight of all the equipment.
- When stacking products, please hold products firmly to prevent tipping or falling.
- Ensure all components and steel frames are securely installed.
- When installing, repairing, or moving the product, ensure the working area is free of obstacles,
- and ensure the working platform is securely and stably fixed.
- In the absence of proper eye protection, please do not look directly at the lit screen from within a 1 meter distance.
- Do not use any optical devices that have converging functions to look at the screen to avoid burning the eyes.



Product Disposal

- Any component that has a recycling bin label can be recycled.
- For more information on collecting, reusing and recycling, please contact the local or regional waste management unit.
- Please contact us directly for detailed environmental performance information.



WARNING: Beware of suspended loads.



LED lamps used in the module are sensitive and can be damaged by ESD (electrostatic discharge). To prevent damage to LED lamps, do not touch when the device is running or switched off.



WARNING: The manufacturer shall not bear any responsibility for any incorrect, inappropriate, irresponsible or unsafe system installation.



1. Product introduction

Absenicon3.0 series standard conference screen is an LED intelligent conference terminal product developed by Absen, which integrates document display, high-definition display and video conference application, and can meet the multi-scene requirements of enterprise high-end conference rooms, lecture halls, lecture room, exhibitions and so on.

Absenicon3.0 series conference screen solutions will create a bright, open, efficient and intelligent conference environment, enhance audience's attention, strengthen speech influence and improve conference efficiency.

Absenicon3.0 series conference screens bring a brand-new large-screen visual experience for the conference room, which can share the speaker's intelligent terminal content to the conference screen at any time, without complicated cable connection, and easily realize wireless projection of multi-platform terminals of Windows, Mac OS, iOS and Android. At the same time, according to different conference application scenarios, four scene modes are provided, so that document presentation, video playback and remote conference can match the best display effect. The fast wireless display of up to four screens and switching function can meet various meeting scenarios, and is widely used in commercial meeting scenarios of government, enterprise, design, medical care, education and other industries.





1.1 Product features

1. The front of the screen adopts an integrated minimalist design, and the ultra-high percentage of display area for 94%. The front of the screen has no redundant design except for the switch button and the commonly used USB*2 interface. The giant screen interacts, breaking the space boundary, and immersing the experience ;

2. The back design of the screen is derived from lightning, blurring the concept of single-cabinet splicing, improving the integrated minimalist design, adding textures to improve heat dissipation performance, every detail is a display of art, shocking the eyes;

3. Minimalist hidden cable design, complete the connection of the screen and various external devices with one cable, bid farewell to the messy power signal wiring;

4. Adjustable brightness range 0~350nit by software, optional low blue light mode for eye protection, bring comfortable experience;

5. Ultra-high contrast ratio of 5000:1, 110% NTSC large color space, showing colorful colors, and the smallest visible details are in front of you;

6. 160° ultra-wide display viewing angle, everyone is the protagonist;

7. 28.5mm ultra-thin thickness, 5mm ultra-narrow frame;

8. Built-in audio, dividable frequency processing treble and bass, ultra-wide audio range, shocking sound effects;

9. Built-in Android 8.0 system, 4G+16G running storage memory, support optional Windows10, superb experience of intelligent system;

10. Support multiple device such as computer, mobile phone, PAD wireless display, support four screens simultaneously display, adjustable screen layout;

11. Support scan code to wireless display, no need to set up WIFI connection and other complicated steps to realize one-click wireless display;

12. Support one-key wireless display, access to the transmitter without driver installation, one-key projection;

13. Unlimited internet, wireless display does not affect work, Browsing web information at any time;

14. Provide 4 scene modes, whether it is document presentation, video playback, remote meeting, can match the best display effect, so that every moment can enjoy comfort, built-in a variety of VIP welcome templates, quickly and efficiently improve the welcome atmosphere;

15. Support remote control, can adjust brightness, switch signal source, adjust color temperature and

6



other operations, one hand can control various functions;

16.All kinds of interfaces are available, and peripheral devices can access ;

17. A variety of installation methods to meet your installation needs, 2 people 2 hours rapid installation,

All modules support full front maintenance



1.2 Product specification

项目		Ai Box3.0 S
	Product size (Inch)	138
	Display area (mm)	3050*1715
Display Parameter s	Screen size (mm)	3060*1830*28.5
	Pixel Per Panel (Dots)	1920x1080
	Brightness (nit)	350nit
	Contrast Ratio	5000:1
	colour space NTSC	110%
	power supply	AC 100-240V
Power Parameters	average power consumption(w)	500
	Maximum power consumption(w)	1500
	Android system	Android8.0
	System configuration	1.7G 64-bit quad-core processor, Mail T820 GPU
System	System memory	DDR4-4GB
Parameters	Storage capacity	16GB eMMC5.1
	control interface	MiniUSB*1 , RJ45*1
	I/O interface	HDMI2.0 IN*3,USB2.0*1,USB3.0*3,Audio OUT*1,SPDIF OUT*1,RJ45*1(Automatic sharing of network and control)
OPS	Optional	Support
	Operating Temperature ($^{\circ}\!$	-10℃~40℃
Environmental	Operating Humidity (RH)	10~80%RH
Parameters	Storage Temperature (°C)	-40°C ~ 60°C
	Storage Humidity (RH)	10% ~ 85%

Remark : Power consumption tolerance: ±15%, according to the actual situation.



1.3 Screen Dimension Figure (mm)







Rear view



1.4 standard packaging

The product packaging of the all-in-one machine is mainly composed of 4 parts: cabinet packaging (1*5 modular packaging), module packaging, installation structure packaging (movable bracket or wall-mounted), edging installation.

Cabinet packaging:

honeycomb carton 1870*760*500;

Module packaging: honeycomb carton 950*810*680;

edging packaging: honeycomb carton 1950x440x380;

mobile bracket packaging: honeycomb carton 2010*870*400.

Schematic diagram of honeycomb carton :



Schematic diagram of module packaging :





2. Product Installation

This product can realize wall-mounted installation and movable bracket installation.

2.1 Installation guide

This product is calibrated by the whole machine. In order to ensure the best display effect, it is recommended to install it according to the identification sequence number of our company.

Diagram of installation number (front view)

	The second se	CORP. March 1999 March 1999	A DECOMPTENDED FOR THE PARTY OF
1-1-2	1-1-3	1-1-4	1-1-5
24 1222 1223 1224	1001100210081004	3041104212431244	10-51 10-50 10-50 10-5-
1-2-2	1-2-3	1-2-4	1-2-5
21 1-7-22 1-7-29 1-7-24	53-3-1 5-3-2 1-3-3-1 5-3-4	5341 5342 1943 1944	53-5-1 5-2-5-2-5-2-5-2-5-2-5-2-5-2-5-2-5-2-5-2
1-3-2	1-3-3	1-3-4	1-3-5
21 1422 1433 1434	1437143214381434	1441144214431444	14521453145
1-4-2	1-4-3	1-4-4	1-4-5
24 16-24 16-24 16-24	53-3-7 1-5-3-2 1-5-3-4	9541 9 5 42 9543 9544	9954 9552 9553 955
1-5-2	1-5-3	1-5-4	1-5-5
	1-1-2 21 1-2-2: 1-2-2: 21 1-2-2: 21 1-3-2: 21 1-4-2: 1-4-2: 21 1-5-2: 21 1-5-2:	1-1-2 1-1-3 pri 1-2-2: 1-1-3 1-2-2: 1-2-3 pri 1-2-2: 1-2-3 pri 1-3-2: 1-3-3 pri 1-3-2: 1-3-3 pri 1-4-2: 1-4-3 pri 1-4-2: 1-4-3 pri 1-4-2: 1-4-3 pri 1-4-2: 1-5-3	1-1-2 1-1-3 1-1-4 21 1-2-2: 1-2-3 1-2-4 1-2-2: 1-2-3 1-2-4 21 5-2: 1-2-3 1-2-4 21 5-2: 1-3-3 1-3-4 21 5-2: 1-3-3 1-3-4 21 5-2: 1-3-3 1-3-4 21 5-2: 1-3-3 1-3-4 21 5-2: 1-4-3 1-4-4 21 5-2: 1-5-3 1-5-4

Number description:

The first digit is the screen number, the second digit is the cabinet number, from top to bottom, the top is the first row; The third place is the cabinet column number: For example, 1-1-2 is the first row and the second column at the top of the first

screen. For example, 3-4-5 is the fourth row and fifth column of the third screen.

2.2 Installation method of moving

2.2.1 Install frame

Take out the frame from the packing box, including the cross beam and vertical beam. Place it on the ground with the front facing upwards (the side with the silk-printed logo on the beam is the front); Assemble the four sides of the frame, including two beams, two vertical beams and 8 M8 screws.





The vertical beam has a gap on the side facing inward

2.2.2 Install support legs

(1) Confirm the the front and back of the support leg and height of the bottom of the screen from the ground.

Note: There are 3 heights to choose for the height of the bottom of the screen surface from the ground:

800mm, 880mm and 960mm, corresponding to different installation holes of the vertical beam.

The default position of the bottom of the screen is 800mm from the ground, the height of the screen is

2522mm, the highest position is 960mm, and the height of the screen is 2682mm.





(2) The front of the frame is in the same direction as the front of the support leg, and a total of 6 M8 screws on both sides are installed.



2.2.3 Install cabinet

Hang the middle row of cabinet first, and hook connecting plate on the back of the cabinet into the notch of the cross beam of the frame. Move the cabinet to the center and align the marking line on the beam;



(1) Install 4 M4 safety screws after the cabinet is installed;



Ai Box3.0 S User Manual



Cabinet	\rightarrow
M4 safety screws	
Hook connecting	
plate cross beam	→

Note: The internal structure is subject to the actual product.

(2) Hang the cabinets on the left and right sides in turn, and lock the left and right connecting bolts on the cabinet. The four-corner hook connecting plate of the screen are flat connecting plate.





Note: The internal structure is subject to the actual product.

2.2.4 Install edging

(1) Install the edging under the screen, and tighten the fixing screws of the left and right connecting plates of the bottom edging (16 M3 flat head screws);





(2) Fix the lower edging to the bottom row of cabinets, tighten 6 M6 screws, and connect the power and signal wires of the lower edging and the bottom cabinet;



Note: The internal structure is subject to the actual product.

(3) Install the left, right and top edging using M3 flat head screws;



Note: The internal structure is subject to the actual product.



Ai Box3.0 S User Manual

2.2.5 Install module

Install the modules in order of number.





2.3 Installation method of wall-mounted

2.3.1 Assemble frame

Take out the frame from the packing box, including the cross beam and vertical beam. Place it on the ground with the front facing upwards (the side with the silk-printed logo on the beam is the front); Assemble the four sides of the frame, including two beams, two vertical beams and 8 M8 screws.



The vertical beam has a gap on the side facing inward

2.3.2 Install frame fixed connecting plate

(1) Install the frame fixed connecting plate;







Ai Box3.0 S User Manual

Frame fixed connecting plate (Each is fixed with 3 M8 expansion screws)





(2) After confirming the installation position of the frame fixed connecting plate and the position of the screen, Holes in the wall to install frame fixed connecting plate (only 4 connecting plate on four sides can be installed when the wall bearing capacity is good);



2.3.3 Fixed the frame

After the frame fixed connecting plate is installed, install the frame, fix it with 2 M6*16 screws at each position, and clamp it up and down.







2.2.4 Install cabinet

Hang the middle row of cabinet first, and hook connecting plate on the back of the cabinet into the notch of the cross beam of the frame. Move the cabinet to the center and align the marking line on the beam;



(1) Install 4 M4 safety screws after the cabinet is installed;



Note: The internal structure is subject to the actual product.



(2) Hang the cabinets on the left and right sides in turn, and lock the left and right connecting bolts on the cabinet. The four-corner hook connecting plate of the screen are flat connecting plate.

Left and right connecting bolts



Note: The internal structure is subject to the actual product.

2.2.5 Install edging

(1) Install the edging under the screen, and tighten the fixing screws of the left and right connecting plates of the bottom edging (16 M3 flat head screws);



(2) Fix the lower edging to the bottom row of cabinets, tighten 6 M6 screws, and connect the power and signal wires of the lower edging and the bottom cabinet;



Ai Box3.0 S User Manual



Note: The internal structure is subject to the actual product.

(3) Install the left, right and top edging using M3 flat head screws;



Note: The internal structure is subject to the actual product.

2.2.6 Install module

Install the modules in order of number.



Ai Box3.0 S User Manual





3. Power on and off Guidance

3.1 Power-on steps

Use 100 ~ 240V 50/60Hz alternating current as the power supply of Absenicon3.0 conference screen. 1. Turn the power switch at the bottom of the Absenicon3.0 conference screen (next to the power interface) to the "ON" position (the switch button indicator lights up in red);

2. Press the power button on the lower right corner of the Absenicon3.0 conference screen or the power button on the remote control to turn on the screen (the power button indicator lights up in blue);



	Absen <mark>icon</mark>	

Ai Box3.0 S User Manual





3.2 Power-off steps

When the Absenicon3.0 conference screen is turned on and working normally: Method 1: Press the switch button on the lower right corner of the panel, the screen will display "Shutdown countdown (5S)" and "Press the shutdown button again to cancel" (the switch button status indicator lights up in red);



Method 2: Press the power button on the remote control, the screen displays "Standby (5S)" and "Shutdown". After selecting "Shutdown", it will count down to 5S to shut down (the power button status indicator lights up in red);





Completely power off: Turn the power switch at the bottom of the conference screen (next to the power interface) to the "OFF" position;

3.3 Standby steps

When the Absenicon3.0 conference screen is turned on and working normally: Press the power button on the remote control, the screen displays "Standby (5S)" and "Shutdown". After selecting "Standby", it will count down to 5S standby (the switch button status indicator lights up in blue);



4. Description of Remote Control

4.1Remote control button description





4.2 Remote control matching guide

4.2.1 Method one







4.2.2 Method two

1. On the main interface of the conference screen system, select "More Applications" to enter the APP application interface;

2. Click "Settings" to open the menu interface, select "Network-Bluetooth" to enter the Bluetooth settings interface;

3. When the blue indicator light on the top of the remote control flashes, select "Scan Device" in the Bluetooth settings

4. In the device list, select the device name of "Storm Bluetooth Remote Control" and perform matching.

5. Initial Setup

When using the Absenicon3.0 conference screen for the first time, please follow the novice guide to complete the initial settings.

Step 1: Select the language of the Absenicon3.0 conference screen system, Chinese, English and Japanese can be selected;





Step 2: Match the remote control with Bluetooth, press "Menu button" and "Home button" on the remote control at the same time to match;





Ai Box3.0 S User Manual



Step 3: Select the Wi-Fi to be connected, and input the corresponding password;







Step 4: Customize the device name to be conveniently searched by other devices;



Step 5: The wireless display adapter is matched. Insert the wireless display adapter into the USB port on the screen to automatically match;





After the initial settings are completed, you can view the novice guide or directly start using the Absenicon conference screen system.



6. Novice Guide

6.1 Remote control guide



6.2 Wireless display adapter guide

	Plag and play minung drough	
	Absenicon	
Over a far		
	When you use the manning Bangle for the first time, pages into the CDB port of the LED screen for paring which the faithput marke or provent to the legitle of the paring signet.	

6.3 IOS/MAC display guide



	iOS/macOS	
	Connect to W-71 Datagets Connect year residents for the W-F1 (Instagent) That Reserves in according to	
Permise .	Petit the screen minoring several derive. 2015 in Correct Control, tax Screen Minoring medicide the Minori Son, shall (2)	
	Select a screen name to share your abrees.	

6.4 Software display guide

	Screen Sharing via App	
	ocicen onaring the App	
	Dear Tw Of make to described Absorber age State that QPI code or shell the reducte In Houristical configure	
i nin i	Comment to WI-Fi (hortsport).	
	Quan the app to share your screen interediency.	

7. Display Guide

7.1 Wireless display

7.1.1 Wireless display by adapter

Foreign customers recommend purchasing Barco's "Click Share" as wireless display adapter. For specific steps, please refer to Barco's equipment operating instructions.



7.1.2 PC display

Use the PC open the browser, enter "https://www.absen.com/absenicon/", and download the corresponding client according to different operating platforms.



7.1.2.1 Windows system display

Connect to the Absenicon conference screen hotspot on the PC (the default name is: Absenicon_XXXX, and the default password is: 12345678);

Run the downloaded client to detect the name of the connected device, click "Start projection";




7.1.2.2 MAC OS system display

- (1) Use screen mirroring directly.
- (2) Connect to the Absenicon conference screen hotspot on the PC (the default name is: Absenicon_XXXX, and the default password is: 12345678);
- (3) Click the "Screen mirroring" icon in the upper right corner and select the corresponding device name to complete the screen display;

7.1.3 Mobile phone display

7.1.3.1 Android system

- (1) First use the mobile phone to scan the QR code of "Quick Sharing" in the main interface to download the "Transcreen" APP, and successfully install it on the mobile phone;
- (2) The mobile phone is connected to the hotspot of the Absenicon conference screen (the default name is: Absenicon_XXXX, and the default password is: 12345678);
- (3) Run "Transcreen" and select the corresponding device name;
- (4) Select "Screen mirroring" to complete the mobile phone screen projection.





7.1.3.2 Transcreen of android features

- 1. Steps to connect the conference screen
- (1) Open the Transcreen software, the first page of the screen is as follows, indicating that it is not connected to an authorized device;



(2) Open the phone "Settings" to connect to the conference screen wifi, enter Transcreen and click "Connect Device" to select the conference screen to be connected;



2. Screen Mirroring

Click "Screen Mirroring", the following prompt appears, click "Start now" to upload the displayed signal on the phone to the conference screen;



Sector anness	tureta sencena
And and the fermion of the second sec	And and Address of the Owner, or other
0- 0-	0-0-
0- 0	0-0-
0== 0	Parre with the server preparities before using other functions
	1.
Course and address	

1. Photos Display / Audio and Video Display/Files Display

Click " Photos Display" to upload the stored photos in the phone to the conference screen; Click "Video Display" to upload the stored video and audio in the phone to the conference screen; Click "Submit File" to upload the stored files in the phone to the conference screen;

2. Mirror Control

Speakers can move freely in the lecture hall, and use Android phones or PAD to reversely control the computer playing PPT;

Click "Mirror control" to realize the function of mirror control;

3. Wireless Speaking

Support wireless speaking function, listeners can use the mobile phone as a microphone to speak directly, and the audio will be wirelessly transmitted to the built-in speaker of the conference screen. (1) On the conference system interface, click "Display the main control ball" to enter the wireless central control interface, and turn on the "wireless speaking" permission;

(2) Long press the "wireless speaking" button to speak directly;

0	
(April Speed)	
	0



4.Wireless Screenshot

Support wireless screenshot function, listeners can take a complete screenshot of the content of the speaker through the mobile phone, and transfer it back to their mobile phone and store it in a designated location.

(1) On the conference system interface, click "Display Master Control Ball" to enter the wireless Screenshot control interface and enable the "Wireless Screenshot" permission;

(2) Long press the "Wireless Screenshot" button to take a screenshot of the conference screen;



5. Remote control

Support remote control function, you can control the conference screen through the mobile phone for menu selection and page turning, etc.;





7.1.3.3 IOS system display

(1) Use iphone to connect to the Absenicon conference screen hotspot (the default name is: Absenicon_XXXX, and the default password is: 12345678);

- (2) Slide from top of the screen to open the control center;
- (3) Click "Screen Mirroring" and select Absenicon_XXXX to complete the mobile phone screen projection;



7.1.3.4 Transcreen of iphone features

- 1. Steps to connect the conference screen
- (1) Open the Transcreen software, the first page of the screen is as follows, indicating that it is not connected to an authorized device;



		-
	-	1.100
0.00	-	
	-	

(2) Open the phone "Settings" to connect to the conference screen wifi, enter Transcreen and click "Connect Device" to select the conference screen to be connected;



2. Screen Mirroring

Click "Screen Mirroring", the following prompt appears, click "Start now" to upload the displayed signal on the phone to the conference screen;



0		-	
0	0-		
0	0 0	0	0 0

3. Photos Display / Audio and Video Display/Files Display

Click " Photos Display" to upload the stored photos in the phone to the conference screen; Click "Video Display" to upload the stored video and audio in the phone to the conference screen; Click "Submit File" to upload the stored files in the phone to the conference screen;

4. Wireless Speaking

Support wireless speaking function, listeners can use the mobile phone as a microphone to speak directly, and the audio will be wirelessly transmitted to the built-in speaker of the conference screen.

(1) On the conference system interface, click "Display the main control ball" to enter the wireless central control interface, and turn on the "wireless speaking" permission;

(2) Long press the "wireless speaking" button to speak directly;





5. Wireless Screenshot

Support wireless screenshot function, listeners can take a complete screenshot of the content of the speaker through the mobile phone, and transfer it back to their mobile phone and store it in a designated location.



7.1.4 Multi-split display

The Absenicon conference system supports multi-split display function, which can set multi-split screen freely, and supports up to four screens. Users can follow the steps below to set up multi-split display .

(1) On the main interface of the conference screen system, select "Quick Sharing" to enter the wireless display guide interface, as shown in the figure below;





mice Name: Absenson_6663		Préss CK to enter settings
	Password: 12345678 Hoteet Name Adversort_56(1	
Share Screen with Apps		Share Screen with Device
Step 1	an PC and the database in the same With Incomes	Share Your Server News
Step 2		11/
The Distance Management and the		R Tips 1. Notice ages (1. Tips) 1. Notice ages (1. Tips)
Without States		2.17 No. 175 consist manageness for more and denois, should whether for drives in pictures by performing additional to picture 16, programs for dama and additional to particular

(2) Press the confirm key on the remote control or select the icon in the upper right corner of the interface, and slide in the pop-up menu to select "Set the quantity of split-screen";



(3	Service Nam	e Abeerscon			Press OK to enter sett	195)
			Mirror Setting			
			Version Information	VSB1.8 3		
			Activation information	>	•••••	
	• Sha	re Screen wit	Device name	REAMINETIN	creen with Device	
		Step 1	Convert unde type	Antation 3	Concerns Constitution	
	100		Curimoct Code Setting)		
		Step 2	Full access of horizontal image Redit following of horizontal image	avre formet die		
			Display PPT slide change icon	-	-Teta	
		== **	Display control laar under malti spill-screen mode	0	A surgerie for surgerie	
		6	The third split screen will be displayed on bottom-center		and the second s	
				-	3	

Devis	e Name: Abami	con	c	ode: 133993 Mirror Setting		Press OK to enter sett	inge
			Convert Code Setting		>		
			Full screen of horizontal image	a fast similar of hast same integri microsoft serves, the most had a se	dage fine divises dat any set		
	Share Scre	en wit	Disalwy PPT slide change scon			creen with Device	
. 6	Step	1	Display control bar under multi split ac	men mode	-	and Your Design New!	
			The third split screen will be displayed	on hottom center	-	117	
1	Step	2 10	Disalay matter control ball				
			Master controller mode	no comunica realizada e a construição Artes Artes Artes Artes	Na maine anno inna 🧼	-Tex 	
		1	Revenue control devices writer multi sp	pit-acroes made	-	d reaction in the measure of the series of t	
			Set the quartity of split screen		(inc ===)		

- (3) Select the split screen display mode in the "Mirror Setting" window, and you can choose "single split screen",
 "dual split screen" and "four split screen";
- (4) Click "Display main control ball" on the interface to enter the wireless central control interface, and click to select the connected device to complete multi-split display;

Description:

• The remote control cannot select the the main control ball, it needs to be connected to a mouse or use the touch screen for control.



- iOS system devices can only click "Screen Mirroring" on the client to complete screen sharing.
- In multi-split screen mode, only one split screen can play sound, but each split screen can independently switch the sound.
- Split screens can exchange positions with each other, and double-click to display in full screen.

7.1.5 Connection code type

On the wireless display guide interface, press the confirm key on the remote control or select the icon in the upper right corner of the interface, and slide in the pop-up menu to select "Connection code type".

Device	Name: Abainicon	(1997)		Press OK to uniter settin	195
		Version information	via ta 🔉		
		Activation Information	,		
•	Share Screen wil	Device name	REAMINGON	creen with Device	
à	S Step 1	Context tode type	to digit cashe 💊	alia Tané Diném Nowé	
ш. ¹⁰⁸		Connect Code Setting	>	11/	
G	Step 2	Full access of horizontal image Earlier I discount of hereint Instantial access its an	ar seage, which the develop formers the .		
		Display PWT slide change icon.		Tipa extreme leave per	
	==	Display control fair under malti spill-acreen mode	-	A strange to the summary street the sum is shown	
		The third split-across will be displayed on bothom center	· · · · · ·	and the second s	

Optional 6-digit digital connection code, 6-digit universal connection code, 8-digit universal connection code.



		Mirror Getting	
		Magina Anarahin (1977	
	nt Screen wi	Generating Mode Of Connect Code	> - Treen with Device -
œ.		6-digit universal code	 S de bio finalité S de bio finalité M

7.1.6 Connection code setting

On the wireless display guide interface, press the confirm key on the remote control or select the icon in the upper right corner of the interface, and slide in the pop-up menu to select "Connection code setting".

Device N	ame: Absenicon	Code: 133993 Minur Setting		Press CK to enter entropy
		Versen Information	viete 🔰	
		Addivation Information	>	
• S	hare Screen wit	Levice name	Abernatur	treen with Device
	Step 1	Connect code type	s digitinate 🗦	are Your Streen Now!
n a		Garment Gode Setting	>	a *
Ø	Step 2	Full screen of horizontal image	mininin (min 🌕	
		Display PPT slide change icon		Tipe whether the second second
	== ~	Diaplay control lar under multi spill screen mode		d Instantia Par Second
	10	The third split screen will be displayed on bottom center	-	and of print the Designer's



7.2 Signal source access

Connect one end of the HDMI cable to the HDMI port of the Absenicon conference screen and the other end to the PC.

8. Signal Source Switching

Users can switch between multiple signal sources in the following 3 ways.

8.1 Presentation

On the main interface of the conference screen system, click "Presentation" to enter the presentation interface.



Select the source that needs to be displayed and press the confirm button on the remote control to switch successfully.

8.2 Remote control menu

Short press the menu button on the remote control to enter the menu.





(1) Click "Source", the source switching interface will pop up at the bottom of the screen;(2) Select the source that needs to be displayed and press the confirm button on the remote control to switch successfully.

8.3 Remote Control Signal Source Switching

(1) Short press the "source switch" button on the remote control, the source switch interface will pop up at the bottom of the screen; (please refer to 5.1 button description for remote control button distribution)(2) Select the input source that needs to be displayed and press the confirm button on the remote control to successfully switch the input source.





9. Display Effect Settings

If you need to adjust the display effect to obtain a more comfortable viewing effect, you can do the following operations.

9.1 Scene mode

Absenicon conference screens are specially designed for different meeting application scenarios, providing 4 scene modes, whether it is document presentation, video playback, or remote meeting, it can match the best display effect.

- (1) Standard mode: The default mode, which can cover most usage scenarios.
- (2) Soft mode: Suitable for scenes such as document presentation and PPT playback.
- (3) Cinema mode: suitable for scenes such as video and movie playback.
- (4) Meeting mode: suitable for scenes such as remote meetings.
- 1. Short press the menu button on the remote control to enter the menu;





2. Click "Effect Adjustment" to enter the effect adjustment interface;

The gall		8s.	
	0		
	•	- 214)	
-		- 185)	
The second of		0	

3. Choose the corresponding mode according to your actual needs.



9.2 Custom display effect

The user can make fine adjustments after selecting the scene mode to meet individual requirements.

- (1) Short press the menu button on the remote control to enter the menu;
- (2) Click "Effect Adjustment" to enter the effect adjustment interface;

		-
10gen	- 251	K
3000 and 1		
Look manufacture		K
		\sim
The conduct	-	

- (3) Customize the display effect by adjusting "brightness", "saturation", "contrast", "color temperature" and "hue";
- (4) If you are not satisfied with the current effect after the adjustment is completed, click the "Restore Default" button to restore the default parameters of the current mode.

9.3 Eye protection mode

The Absenicon conference system supports one-key opening of the eye protection mode.

(1) Press the menu button on the remote control to enter the menu.





(2) Click the "eye protection mode" button to turn on/off the effect of eye protection mode Note: When the eye protection mode is turned on, the screen display will be slightlyyellow.

10. Settings

On the main interface of the conference screen system, select "More Applications" to enter the "Settings" application interface.





10.1 Network settings

In the setting interface, select "Network" to enter the "Network Settings" interface.

			, and a second se	Settings			
	Network	3				>	
		>				5	
	Toont.	2					
15	E Ormal	2				5	
		>					

10.1.1 Wired network



Select "Wired Network" to enter the wired network setting interface, and select "Auto" for "Wired Setting" to automatically obtain the IP address. When the 🔄 icon is displayed in the upper right corner of the main interface, it indicates that the network connection is successful.

	9	ettings	
	S	ter Deminister 🔪	
	> management		
AND TOOM	> timie)	~ >	
6 level	• instant	- >	
	\$		
	9	ettings	
en : Nationts	S	ettings Adomtor	
e National.	S Network > Wired network Wired Network Wired Network	ettings Automatic	
e Internet - Process - Process	S Network > Wred network Wred hetwork Wred hetwork	ettings Automatic	
e Internet - Proces De Torret Di Torret	S Notwork > Wired network Notwork > Wired network Note helpersk	ettings Automatic Ed.A.C Ed.A.C Ed.A.C Ed.A.C Ed.A.C Ed.A.C	
 Molandi Petas Rout Rout Rout Rout Rout Rout 	Notwork > Wired network Wired hertwork Wired hertwork	ettings Automatic	

10.1.2 Wireless network

Select "Wireless Network" to enter the wireless network setting interface, select "On" for "Wireless LAN",



automatically search for surrounding wireless networks, select an available Wi-Fi network, and a password input window will pop up.

	_			Settings		
	Network.	5	Network > Wireless Net	work:		
			21 (Marriel)		. 82.	
्म		2				
6	Amenal	•				
		>				

			Settings		
 Antonett Petuse Petuse Petuse Petuse Petuse Petuse 	3 3 3 3	Notwark > Wireless Network	Enter The password for Alleen	· · · · ·	
				• 🗢	
				* *	
				÷	
		(Additional)		1.2	

10.1.3 Local hotspot

After entering the password, click "OK" to connect to Wi-Fi.



Select "Hotspot" to enter the local hotspot setting interface.

	Security	
- Notronti 5	Network > Hotspot	
an Annie 🛛 💰	#kmpot	
	Password	
Carl Control Carl	Chairmed	36 (5.1804s) >
15 Amanal ?		
E System >		

- (1) The hotspot switch is turned on;
- (2) Set the password of the wireless hotspot, click "OK" to turn on the hotspot;

	(Hermood)	
- Tourit	Password	
(S. German	Channel	36 (K186Hd) >
	Bet a new hetapot password (0-16 charac	oeu

Note: After modifying the hotspot name or password of the machine, you need to connect the wireless display adapter to the USB port of the conference card and re-pair.

(3) Channel switching



-	Network > Hotspot	
a man	Phrapot,	
4 Tourit	Password	· · · · · · · · · · · · · · · · · · ·
C Union	>	as (a terrer) =
		en in Sections Carl (1) reasons ann (1) reasons

10.1.4 Bluetooth

Select "Bluetooth" to enter the local hotspot setting interface.

			Settings	
	et mout	5	Network + Bluetooth	
			Ramath.	
		5	Scalining for devices	
	El Ormu	- 20	Device Name: Absencen	
10		3		<u>.</u>
			Other Devices	
				5



			Settings				
	Call Manhamath	3	Network > Bluetooth				
		5	Bluetouth		14		
	· Toost	3	Scanning for devices Device Name: Absention				
081	E Syden	3	My De Remove De you want to remove this device?			>	
			Other E	tanca en			
						2.	
						>	
			I ARRAND WATCHOUT II AFR			>	

- (1) Turn on the Bluetooth switch to automatically scan for devices;
- (2) Select the device to be paired;
- (3) According to the pop-up "Bluetooth Pairing Request", enter the corresponding number and click "Pair".

10.2 Effect settings

In the setting interface, select "Picture" to enter the "Effect Settings" interface.

10.2.1 Mode selection

"Standard Mode", "Soft Mode", "Movie Mode" and "Conference Mode" can be selected respectively; It can be individually set from brightness, saturation, contrast, color temperature, and hue.





10.2.2 Eye protection mode

The bottom button (Eye Comfort) can turn on the eye protection mode.

			Settings		
	> >	S. Standard Mode	O Latroday	B Marrie Maria	R Contention blane
🛱 Ommil)					
	3			•	
		Section 10	-		
				•	



10.3 Sound settings

In the setting interface, select "Sound" to enter the "Sound Settings" interface.

Set the sound of the Absenicon conference screen, including adjusting the volume and turning on/off the system sound.



10.4 General settings

In the main setting interface, select "General" to enter the "General Settings" interface.

There are signal source settings, apps, time and date, language and keyboard, wallpaper, and assistive touch.



			Settings	
	en Salaratio	- 36		>
		3		•
			Decklose	
	E Geteral		Company & Andrews	•
		3		3
8				C

10.4.1 Source settings

In the main interface of general settings, select "Signal" to enter the signal source settings interface. Perform the following settings and management of the connected signal source.

						Settings				
		. Notembe	3	General > Signal Romember Signal	Settings					
			•	(Although a	-	inger (and the	1011	W-22	
		Toont	2			ä				
	5		3							
			3	Aspect Ratio						
181				HOWE					Nerri Di	
				HOME					Harry >	
				HOME					ann an	
				Windows					America)	

- (1) Remember signal: Set the power-on signal source, select "Last Used", "Home" (default), "HDMI1", "HDMI2", "HDMI3" and "Windows".
- (2) Aspect Ratio: set aspect ratio for the selected HDMI source, and you can choose "Auto fit" (default), "4:3",



"16:9" and "pixel-to-pixel".

						Settings				
		(Materia)	3	General > Signal Remember Signal	Settings					
			•	antina (-	-	HERE	-	Sec. 22	
		Toont	3			3				
	5		3							
				Aspect Ratio						
(8)				HOME					A1279 3.	
				HOME						
				(HOMA)						
				Windows					Partie Peel	

10.4.2 Application management

In the main interface of general settings, select "APP" to enter the app settings interface.

				Settings	
		3	General I Appa		
		3	Churse	Chrome	
	·····	3	Serate/Powel		
	E General	3	TERMESINE	Улици Шир Сринскарр	United and a second sec
ar -		:2) 	B Mittalieves		
			🧿 Seleça	them we want	Dear Date
			O website		
			(a) Webburg		
			WPILIPELE		
			Come.		

Perform the following management for the installed APP.

(1) Force stop: Force the APP to be stopped.



- (2) Open app: run the selected APP.
- (3) Uninstall: uninstall the selected APP.
- (4) Clear data: Clear the data cache of the selected APP.

10.4.3 Data&Time

On the main interface of general settings, select "Time and Date" to enter the time and date setting interface. Set the time and date of the Absenicon conference screen as follows.

announe creatio	STATISTICS.	
Neture 🗲	a station and a	1
toont 5		imirdi. >
internal (Sec.		anarida 👌
		DMT-datast these masters liese 🌖
	24Haar Time	-
	Date Finimat	inniidi 🖌

(1) Automatically obtain network time: Turn on "Set Automatically", the time and date will be synchronized with the network time.

You can also turn off the automatic setting to set the time of the Absenicon meeting screen by yourself.

- (2) 24-hour system: Turn on the "24-hour time" switch, the time is displayed in the 24-hour format; if it is not turned on, the time is displayed in the 12-hour format.
- (3) Date format: "Year-Month-Day" (default), "Month-Day-Year" and "Day-Month-Year" can be selected.



			Settings	
			General + Date & Time	
	+ Matematic	120	Set Automatically	
	C. Now	3	Curta	attriction)
	- Toont	3	100	market St.
	(5 United	3	NAME OF THE OWNER OF	
		- 2 3	Tarta Zona	TOTO DATA CANA DAMAN TOS
(M)			24Hour Time	HERS. 1047+8.00
			Curre Firmmal	Visural GMT+8:00
				North GM7+8.00
				Perth GMT+8:03
				Tesper GMT+82.02
				Senal Children
				Adeia. GMT+1038
			Settings	
			7/290-441	
			General > Date & Tame	
		3	Bet Automatically	
		5.	Dete	100 (1994 - 🗲)
	E Orinital		- Time	ing siz 🔶
		51	Tirm Zone	SHIT-OLOC OVER THE DECT THE .
16			Marca 11 Iner 37 mm	
			24466/1	
			Date Farm	



		Settings	
		Oeneral > Date & Time	
	and then an	Set Automatically	
			att (ctob. 👂
	15 Owned	(194)	That Add
		5 Sec. 1	DAT-States, three mandem lines - 5
		Contraction of the Contraction o	
		Outer Farmat	• +++++++
			Day Mo.
			Charles and Charles an
105	-	Settings	
	C. Notes	Set Autometically	
	- 44 C Taonit	5 Date	HELICIAN >
	C Ones) Time	a the second sec
		2 Time Zanc	2011-00.000 Chrise Transform Trees
		2020 et 12 Mint.	34 Day
		Oute Fame	1125-114* >

10.4.4 Language & keyboard

In the main interface of general settings, select "Language and keyboard" to enter the language and keyboard setting interface.

Set the language of the Absenicon conference screen and the input method of the keyboard.

Abjen 艾比森

Ai Box3.0 S User Manual

_		Settin	gs		
Submit	- 3	General > Language & Keyboard			
	- 49	Language		Mayin 5	
4 Tourit	3 3	Kayboard	Income and	- Frield PD - 中立(時)体。 - 中立(第1第5	
	2			848	

- (1) Language: "Chinese (Simplified)" (default), "English", "Chinese (Traditional)" and "Japanese" can be selected.
- (2) Keyboard: Optional "Android keyboard (AOSP)", "remote control input method" (default).

6 EX 3	
	and the second s
	Andread Mills partners
	analos et

10.4.5 Wallpaper

In the main interface of general settings, select "Wallpaper" to enter the wallpaper setting interface. Set the desktop wallpaper of the Absenicon conference screen.





- (1) The system comes with wallpaper: select the target wallpaper and click "set as wallpaper".
- (2) Custom wallpaper: Click "Custom wallpaper", select the local picture that needs to be set as wallpaper in the ES file browser, and click.

	Settinge	
	General V Andream + +	
	Oue a different app Callery	





10.4.6 Assistive touch

On the main interface of general settings, select "Assisitive Touch" to enter the setting interface. Turn on "Assistive Touch " and click the small icons on both sides of the interface to open the sidebar.





Return key, click to return to the previous step.

 $\widehat{ extsf{m}}$: Home button, click to return to the main interface.

Let Paintbrush button, click to open the paintbrush tool.

🤗: Whiteboard button, click to open the whiteboard tool.

E: Menu key, click to open the menu bar.

Description:

The remote control cannot operate the assistive touch menu, it needs to be connected to a mouse or use the touch screen for control.

10.5 System settings

In the main setting interface, select "System" to enter the "System Settings" interface.

There are scheduled startup & shutdown, factory reset, system upgrade, about, begginner' s guide, and ethernet port switching.

Partor Partor Doubt Depend Radate Doubt Depend Radate Depend Depend Radate Depend Depend Radate Depend Depend Radate	 Melemitic Selection 	Scheduled Bartur & Shutdown	>
Denset Denses linkline Control Control	L Peter 🕻		>
Tenned > dear Tenne > dearcond	e toont 🤰	Speer lade	08
Chemes 🗡 Happenson	5 Omeni 🤇		>
	Tenters 🤌		>
Deskin Rosenet Port 1			10

10.5.1 scheduled startup & shutdown

On the main interface of the system settings, select "schedule startup and shutdown" to enter the timed switch setting interface.



Set the time for the Absenicon conference screen to switch on and off.

Set the startup time and shutdown time of the conference screen respectively.


Absen 艾比森

Ai Box3.0 S User Manual



10.5.2 Reset factory

In the main interface of the system settings, select "Factory Reset " to enter the factory settings interface. Click " Factory reset" to restore the Absenicon conference screen to the factory state.





Ai Box3.0 S User Manual

		Settings	
 Motorett Perture Perture Perture Perture Perture 	System + Factory Reset Factory Rese	Settings	

Description:

The local documents, photos, videos, applications and other data will be cleared after the factory settings are restored and cannot be restored.

10.5.3 Android system update

	\$		2
	5.1	Territorial State	3
	5	System Lipdate	à.
	- 30 T		>
	3		3
		Sector Distance Part	ler.

In the main interface of system settings, select "System Update" to enter the Android system update interface.

Ai Box3.0 S User Manual



An Mathematic System - System Update Annual Conference Mathematical Status		Settings
OF formed Image: Im	 Magnetti Arcore Arc	Settings System - 1 System Update System - 1 System Update Provide Concurrent Underst Status Detail Provide Concurrent Underst Status Details Provide Concurrent Undetails Provide Concurrent Undetails Provide Concure

- Insert the U disk containing the upgrade package into the USB port of the Android card. (The upgrade package file name is: update.zip, and the upgrade package must be placed in the root catalog of the mobile device).
- (2) When it displays "the U disk root catalog has the upgrade file and can be upgraded", click "Local Upgrade".
- (3) During the upgrade process, the Absenicon conference screen will be powered on without plugging and unplugging the U disk. The entire upgrade time will take about 3 to 5 minutes (power off and plugging and unplugging the U disk are dangerous actions, which may damage the conference screen systemcard)

10.5.4 About

On the main interface of system settings, select "About" to enter the About interface.

The user can view and modify the name of the Absenicon conference screen, as well as the following information.

Absen 艾比森

Ai Box3.0 S User Manual



- Android card version
- Sending card version
- Receiving card version
- Memory information
- Storage information
- The name of the machine can be modified

10.5.5 Novice guide



In the main interface of system settings, select "Beginner' s guide" to enter the novice guidance interface. See section 7 for details.



10.5.6 Network Port Switch

On the main interface of the system settings, select "Network Port Switch".

e , mouri :	\$		<u>e</u> .
	э.:		3
a hand	9	Terrethere	•
a ommu	•)
	3		3
		Switch Etheriset Part	iii iiii iiii iiii iiii iiii iiii iiii iiii



- Switch the status of the network port, select "LCT" (default), "wired network".
- When you need to connect to the host computer through the network port, please switch to the "LCT" state.
- When you need to connect to the wired network through the network port, please switch to the "wired network" state.

11. ES File Explorer

Users can follow the steps below to perform simple operations on files.

On the main interface of the conference screen system, select "More Applications" to enter the "ES File Explorer" interface.





Ai Box3.0 S User Manual





Absen 艾比森

Ai Box3.0 S User Manual



Select the folder where the target file is located, select the target file and confirm to open it. Long press the confirm button on the remote control or the left mouse button to perform operations such as "copy/cut/delete/rename" on the target file.

12 . Product Maintenance

12.1 Tool preparation

The preparation tools include: a maintenance tool before the module, a Phillips screwdriver, a multimeter, etc.





12.2 Cabinet accessories replacement guide

12.2.1 Module maintenance

Press the front module maintenance tool button, get close to the module, suck out the module, and then release the front module maintenance tool button after holding the module with your hand.



12.2.2 HUB maintenance

First remove the 4 modules on the cabinet with the front maintenance tools and put them away, then use a Phillips screwdriver to remove the fixing screws of the HUB, and the HUB can be removed from the cabinet.







12.2.3 Receiving card maintenance



12.2.4 Maintenance before power supply





12.3 Maintenance instructions

When you cannot determine the cause of the fault or do not understand the method of updating the accessories, please contact Absen!

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.

RF warning:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.



Shenzhen Absen Optoelectronic Co., Ltd.

18-20F Building 3A, Cloud Park, Bantian, Longgang District, Shenzhen 518129,

P.R.China

T: +86-755-89747399

E: absen@absen.com

W: www. absen.com