

M952 Wireless Mouse Quick Guide


Congratulations on your purchasing this exciting mouse. Your new Mouse is easy to install and offers you a host of useful features. The great features of this mouse are wheel for quick scrolling and wireless function for easy movement. With the wireless function, you can pass around the mouse during meetings without bothering from a cable or you can write e-mails and surf the Internet from the comfort of your living room couch. All those human-oriented characteristics make you feel more comfortable and efficient while surfing on the website or using applications. Please install the KeyMaestro Input Device driver to find more great functions!

System Requirements

- Microsoft® Windows®NT 4.0, Windows®95, Windows®98, Windows®ME, Windows®2000 or Windows®XP operating system

Hardware Installation

1. Turn off your PC system first. Plug in the receiver's PS/2 connector into the available PS/2 port.
2. Make sure that two AAA alkaline batteries are installed correctly. (Follow the polarity signs in the battery compartment.)
3. Turn on your PC system.




PS/2 Connector

ID Setting


This wireless optical mouse contains 255 sets ID. This ID-recognition function helps to protect against interference from other RF keyboards in the same environment. Remember to set the ID when you replace the batteries.

- The word CONNECT labels the ID button on each unit.
 - The LED under ID button of receiver shows connecting condition.
1. Press the ID button on the top of the receiver once.
 2. Press the ID button on the bottom of the mouse once.

ID Button(LED)




ID button of Receiver
(With LED under the ID button)




ID BUTTON
Bottom View of M952 Mouse

Software Installation

1. Insert the disk labelled "KeyMaestro Input Device Driver" into your disk drive.
2. Double-click on "**Setup.exe**" on the driver disk.
3. Then follow the instruction on the screen to install the driver. The default install path is set to **c:\MMaestro**. You have the option to change the install path during set-up.

-
-
4. Set up will indicate when installation has successfully completed. The driver is loaded when you see the driver icon  on Windows system tray. The operating system needs to restart.

Battery Low Alarm

After installing the KeyMaestro Input Device Driver, computer will display a battery low icon  on the upper-right corner of your screen and flash for 10 seconds to indicate low batteries when the batteries are low in the unit. After changing the batteries, please remember to set ID settings.

Important

1. This optical mouse uses light to sense movement. It cannot work on a glass, translucent or reflective surface.
2. Use the mouse only on a clean, flat, non-slippery, opaque surface in order to ensure smooth and accurate cursor action
3. You can adjust the double-click speed of mouse by opening up the Mouse Properties in the Windows Control Panel and changing the speed.


FCC GUIDELINES

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
- Use only shielded cables to connect I/O devices to this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference. (2) This device must accept any interference received, including interference that may cause undesired operation.

Information to User:

 Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. Shielded interface cable, if any, must be used in order to comply with emission limits.

IBM AT and PS/2 are registered trademarks of International Business Machines Corporation.



Microsoft and Windows are registered trademarks of Microsoft Corporation in the United States and/or other countries.
All other trademarks are trademarks of their respective holders.

3100505180

Version v1.0

Oct. 2003

Printed in China

