
# **10.1 Tablet** OC106


## **USER GUIDE**

Please read the manual before using this product, and save it for future use.





#### **FUNCTION OVERVIEW**



9. Mic 10. Rear camera

### **SPECIFICATIONS**

Tablet Specifications			
Tablet Size	10.1"	Connectivity	Wi-fi / Bluetooth
Chipset	A523	СРИ	Octa-core ARM CortexTM-A55
GPU	G57 MC01	RAM	4GB/6GB/8GB
ROM	128GB	Display	IPS/1280*800 HD
Front-facing Camera	5MP	Network	802.11b/g/n/ac/ax(Wi-Fi)
Rear-facing Camera	8MP	Power Supply	DC 5V 2A
Battery	5000mAh	Touchscreen	Multi-touch
Operating System	Android™ 13	Ports	USB Type-C / microSD Card Slot



#### **START**

#### Power On/Off

- 1. Hold down the power button for 2-3 seconds to turn on the tablet. Select the language and follow the start up quide to set up the tablet.
- 2. Hold down the power button for 2 seconds to display power off and restart options on the screen. Click power off to turn off the tablet.
- 3. When the device is on, press and hold the power button for 10 seconds to force shutdown.

#### Reset

When the device is on, use a pin to press down the reset button to force restart.

#### **Battery**

- 1. A rechargeable Li-ion battery is installed in the tablet.
- 2. We suggest you drain the battery completely once a month if you only use your tablet occasionally.
- 3. DO NOT dispose of tablet in fire.
- 4. Charge the device fully each time to increase the battery life.
- 5. You can charge the tablet, even if the tablet has some power left in it, as the lithium battery does not need to be fully drained to charge.
- 6. A full charge can be used for an average of 3 hours.
- 7. Use a 5V 2A charger for tablet charging.

#### Sleep Mode

Simply press the power button once to switch the tablet into Sleep Mode when the tablet is ON; press again to wake it up.

#### Tip:

Go to Settings > Display > Screen timeout to adjust automatic sleep settings.

#### **TROUBLESHOOTING**

#### Q1. The tablet doesn't power on

- · Reboot your tablet after charging for 30 minutes;
- · Press the power button to see if the tablet is in Sleep Mode;
- · Press and hold the power button for 5 seconds to turn off the tablet, then reboot it;
- · Press the reset button with a pin to reset the tablet.

#### Q2. The tablet doesn't charge

- · Charge the device for at least 30 minutes, in case the battery was completely drained;
- · Make sure the USB cable is properly plugged into the charging port;
- · Try another compatible USB cable and adapter.

#### Q3. Error message occurs during operation

- · Uninstall the app displaying the error message, then download and install again;
- · Press the reset button with a pin to reset the tablet.

#### Q4. The tablet cannot be detected by the computer

- · Make sure the tablet is powered on;
- · Try another USB cable;
- · Try another USB port on the computer;
- · Instead of Charge this device, choose Transfer files or Transfer photos (PTP) when connecting the tablet to the computer.

#### Q5. The tablet cannot connect to the Wi-Fi

- · Make sure the Wi-Fi on your tablet is ON;
- · Make sure you input the correct password;
- · Reboot the router;
- · Make sure there is no filter setting or device connection limitation in the settings of the router;
- · Forget the current Wi-Fi, reset the router and connect to the network again.

#### Q6. The storage space of the tablet is not enough

- · Delete the apps you don't use;
- · Clear the app cache regularly;
- · Insert a microSD card to expand the storage.

#### Android is a trademark of Google LLC

## **FCC** warning:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.

The 10.1 "tablet OC106 has been tested for body-worn Specific Absorption Rate (SAR) compliance. The FCC has established detailed SAR requirements and has established that these requirements. RF Exposure Information The radio module has been evaluated under FCC Bulletin C95.1 and IEEE 1528 and found to be compliant to RF Exposure from radio frequency devices. This model meets the applicable government requirements for exposure to radio frequency waves. The highest reported SAR level for usage near the body (0mm) is 1.320W/kg,

## **IC** warning

- English:

This device complies with Industry Canada licence-exempt RSS standard(s).

Operation is subject to the following two conditions: (1) This device may not cause interference, and (2) This device must accept any interference, including interference that may cause undesired operation of the device.

- French:

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- 1) L'appareil ne doit pas produire de brouillage;
- 2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Operations in the 5.15-5.25GHz band are restricted to indoor usage only Les opérations dans la bande 5.15-5.25GHz sont limitées à une utilisation en intérieur uniquement

# **MIC** warning

For products using frequencies within 5.15-5.35 GHz, please additionally print the following **warning text** "5GHz product for indoor use only" on your product:

電波法により5GHz帯は屋内使用に限ります。

## **CE Requirements:**

- (Simple EU declaration of conformity) declares that the radio equipment type is in compliance with the essential requirements and other relevant provisions of RED Directive 2014/53/EU and the ROHS Directive 2011/65/EU and the WEEE Directive 2012/19/EU.
- Restriction Information

This product can be used in EU countries and regions, including: Belgium (BE), Bulgaria (BG), Czech Republic (CZ), Denmark (DK), Germany (DE), Estonia (EE), Ireland (IE), Greece (EL), Spain (ES), France (FR), Croatia (HR), Italy(IT), Cyprus (CY), Latvia (LV), Lithuania (LT), Luxembourg (LU), Hungary (HU), Malta (MT), Netherlands (NL), Austria(AT), Poland (PL), Portugal (PT), Romania (RO), Slovenia (SI), Slovakia (SK), Finland (FI), Sweden (SE) and United Kingdom (UK). For the warning information of the frequency restriction, please refer to the package or manual section.

#### **RF Exposure Statement**

Operations in the 5.15-5.25GHz band are restricted to indoor usage only

#### **Contact Us**

For any inquiries, feel free to contact us. We'll be glad to help you out! E-mail: customservicare@outlook.com

Tel: 1-888-880-0815

Manufacturer: Shenzhen Ployer Electronics Co.,Ltd.