WIRELESS HEADPHONES

CHARGING THE HEADPHONE

- Charge the headphone before using it for the first
- Plua in the cable to the micro USB port and charge for at least 2 hours.

Connect the charging cable to charging port.



PAIRING YOUR HEADPHONE

Your headphone will work best if it is within 30 ft. of your smart device. You may experience sound briefly cutting off if you are out of range or if your wireless connection is weak. Make sure Bluetooth is enabled on your smart phone or tablet before starting the pairing process.

WIRELESS HEADPHONES

PAIRING YOUR HEADPHONE (continued)

Make sure the headphone is turned off before attempting to pair it with a smart phone or tablet.





Press and hold the " " button for From your smart phone or about 3 seconds to turn on the tablet, find a list of nearby headphone and you see the light devices and choose "HY-LTHR". flash red and blue. This indicates Enter "0000" if asked. The that your headphone is ready to pair. headphone will flash a blue light

when pairing is complete!

WIRELESS HEADPHONES

CONNECTION LOST?

- If pairing the headphone does not work turn off the headphone and repeat the steps again in "Pairing your Headphone."
- Make sure your headphone is within range of your smart device.
- If you hear a long beep, you need to recharge your headphone. Connection may be lost due to low battery.
- · When charging your headphones, only use the enclosed USB cable.

MULTIFUNCTION BUTTON



- C→ Press & Hold Turn device on/off
- Press & Hold Play/Pause music/Answer/ End Call/Reject Call Press Twice - Dial Last Call
- ►H/V+ Press & Hold Increase Volume Press Once - Next Track
- H4/V- Press & Hold Decrease Volume
- Press Once Previous Track
- M Press Once Switch from Micro SD card to

WIRELESS HEADPHONES

SPECIFICATIONS

Bluetooth: v 4.2

Wireless Distance: ~33ft (10m)

Play Time: Up to 4 hours

Talk Time: Up to 4 hours

Battery: 200 mAh

Charaing Time: Up to 2 hours

FCC ID: 2AANZEULTHR

BT ID: D038588

WARRANTY

This product is covered by a 3 month limited manufacturer's warranty. Contact us if you have any problems at support@dglusa.com.

WARNING

Keep away from water and moisture. Keep away from heat sources. Do not disassemble.

WIRELESS HEADPHONES

FCC STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Please note that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC INSTRUCTIONS FOR A CLASS B DIGITAL DEVICE OR PERIPHERAL

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in

WIRELESS HEADPHONES

accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception. which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and
- · Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure equirement. The device can be used in portable exposure condition without restriction.



