

Using Avaya Vantage[™] and Avaya Vantage[™] Basic

Release 2.0 Issue 1 June 2018

- © 2017-2018, Avaya Inc.
- 2 All Rights Reserved.

3 Note

- 4 Using a cell, mobile, or GSM phone, or a two-way radio in close
- 5 proximity to an Avaya IP telephone might cause interference.

6 Documentation disclaimer

"Documentation" means information published in varying mediums 8 which may include product information, operating instructions and

9 performance specifications that are generally made available to users 83 UNLESS OTHERWISE AGREED TO BY AVAYA IN WRITING

10 of products. Documentation does not include marketing materials.

11 Avaya shall not be responsible for any modifications, additions, or deletions to the original published version of Documentation unless

13 such modifications, additions, or deletions were performed by or on 14 the express behalf of Avaya. End User agrees to indemnify and hold

15 harmless Avaya, Avaya's agents, servants and employees against all 89 WITHOUT A LICENSE. BY INSTALLING, DOWNLOADING OR

16 claims, lawsuits, demands and judgments arising out of, or in

connection with, subsequent modifications, additions or deletions to

18 this documentation, to the extent made by End User.

19 Link disclaimer

20 Avaya is not responsible for the contents or reliability of any linked

websites referenced within this site or Documentation provided by

22 Avava. Avava is not responsible for the accuracy of any information.

23 statement or content provided on these sites and does not

necessarily endorse the products, services, or information described

25 or offered within them. Avaya does not guarantee that these links will

pages.

28 Warranty

29 Avava provides a limited warranty on Avava hardware and software.

30 Refer to your sales agreement to establish the terms of the limited

available to Avaya customers and other parties through the Avaya

Support website: https://support.avaya.com/helpcenter/

"Warranty & Product Lifecycle" or such successor site as designated

37 by Avaya. Please note that if You acquired the product(s) from an

authorized Avaya Channel Partner outside of the United States and

39 Canada, the warranty is provided to You by said Avaya Channel

40 Partner and not by Avaya.

"Hosted Service" means an Avaya hosted service subscription that

You acquire from either Avaya or an authorized Avaya Channel

Partner (as applicable) and which is described further in Hosted SAS 118 License types

45 hosted service. If You purchase a Hosted Service subscription, the

46 foregoing limited warranty may not apply but You may be entitled to

further in your service description documents for the applicable

49 Hosted Service. Contact Avaya or Avaya Channel Partner (as

50 applicable) for more information.

51 Hosted Service

THE FOLLOWING APPLIES ONLY IF YOU PURCHASE AN AVAYA

HOSTED SERVICE SUBSCRIPTION FROM AVAYA OR AN AVAYA

CHANNEL PARTNER (AS APPLICABLE), THE TERMS OF USE

WEBSITE, HTTPS://SUPPORT.AVAYA.COM/LICENSEINFO UNDER 131 accompanying or applicable to the Software ("Shrinkwrap License"). FOR HOSTED SERVICES ARE AVAILABLE ON THE AVAYA

THE LINK "Avaya Terms of Use for Hosted Services" OR SUCH

SUCCESSOR SITE AS DESIGNATED BY AVAYA, AND ARE

APPLICABLE TO ANYONE WHO ACCESSES OR USES THE

HOSTED SERVICE. BY ACCESSING OR USING THE HOSTED

63 DOING SO (HEREINAFTER REFERRED TO INTERCHANGEABLY 137

64 AS "YOU" AND "END USER"), AGREE TO THE TERMS OF USE. IF 138 Nortel Products" or such successor site as designated by Avaya. For 139 Heritage Nortel Software, Avaya grants Customer a license to use

COMPANY OR OTHER LEGAL ENTITY, YOU REPRESENT THAT

YOU HAVE THE AUTHORITY TO BIND SUCH ENTITY TO THESE

TERMS OF USE. IF YOU DO NOT HAVE SUCH AUTHORITY, OR IF 42 purpose specified in the Documentation, and solely as embedded in,

YOU DO NOT WISH TO ACCEPT THESE TERMS OF USE, YOU

70 MUST NOT ACCESS OR USE THE HOSTED SERVICE OR

71 AUTHORIZE ANYONE TO ACCESS OR USE THE HOSTED

72 SERVICE.

73 Licenses

74 THE SOFTWARE LICENSE TERMS AVAILABLE ON THE AVAYA

75 WEBSITE, HTTPS://SUPPORT.AVAYA.COM/LICENSEINFO

76 UNDER THE LINK "AVAYA SOFTWARE LICENSE TERMS (Avaya

Products)" OR SUCH SUCCESSOR SITE AS DESIGNATED BY

AVAYA, ÁRE APPLICABLE TO ANYONE WHO DOWNLOADS,

79 USES AND/OR INSTALLS AVAYA SOFTWARE, PURCHASED

80 FROM AVAYA INC., ANY AVAYA AFFILIATE, OR AN AVAYA

CHANNEL PARTNER (AS APPLICABLE) UNDER A COMMERCIAL

82 AGREEMENT WITH AVAYA OR AN AVAYA CHANNEL PARTNER.

AVAYA DOES NOT EXTEND THIS LICENSE IF THE SOFTWARE

85 WAS OBTAINED FROM ANYONE OTHER THAN AVAYA, AN AVAYA

86 AFFILIATE OR AN AVAYA CHANNEL PARTNER; AVAYA

RESERVES THE RIGHT TO TAKE LEGAL ACTION AGAINST YOU

88 AND ANYONE ELSE USING OR SELLING THE SOFTWARE

90 USING THE SOFTWARE, OR AUTHORIZING OTHERS TO DO SO,

91 YOU, ON BEHALF OF YOURSELF AND THE ENTITY FOR WHOM

YOU ARE INSTALLING, DOWNLOADING OR USING THE

SOFTWARE (HEREINAFTER REFERRED TO

94 INTERCHANGEABLY AS "YOU" AND "END USER"), AGREE TO

95 THESE TERMS AND CONDITIONS AND CREATE A BINDING

96 CONTRACT BETWEEN YOU AND AVAYA INC. OR THE

97 APPLICABLE AVAYA AFFILIATE ("AVAYA").

98 Avaya grants You a license within the scope of the license types 99 described below, with the exception of Heritage Nortel Software, for

26 work all the time and has no control over the availability of the linked 100 which the scope of the license is detailed below. Where the order

101 documentation does not expressly identify a license type, the

102 applicable license will be a Designated System License as set forth

103 below in the Designated System(s) License (DS) section as 104 applicable. The applicable number of licenses and units of capacity

for which the license is granted will be one (1), unless a different

warranty. In addition, Avaya's standard warranty language, as well as 106 number of licenses or units of capacity is specified in the information regarding support for this product while under warranty is 107 documentation or other materials available to You. "Software" means

information regarding support for this product while under warranty is 107 documentation or other materials available to 108 computer programs in object code, provided by Avaya or an Avaya

109 Channel Partner, whether as stand-alone products, pre-installed on

getGenericDetails?detailId=C20091120112456651010 under the link 110 hardware products, and any upgrades, updates, patches, bug fixes,

or modified versions thereto. "Designated Processor" means a single

112 stand-alone computing device. "Server" means a set of Designated

113 Processors that hosts (physically or virtually) a software application

114 to be accessed by multiple users. "Instance" means a single copy of

the Software executing at a particular time: (i) on one physical 116 machine; or (ii) on one deployed software virtual machine ("VM") or

117 similar deployment.

or other service description documentation regarding the applicable 119 Designated System(s) License (DS). End User may install and use

120 each copy or an Instance of the Software only: 1) on a number of

121 Designated Processors up to the number indicated in the order; or 2)

support services in connection with the Hosted Service as described 122 up to the number of Instances of the Software as indicated in the

123 order, Documentation, or as authorized by Avaya in writing. Avaya

124 may require the Designated Processor(s) to be identified in the order by type, serial number, feature key, Instance, location or other

126 specific designation, or to be provided by End User to Avaya through

127 electronic means established by Avaya specifically for this purpose.

Shrinkwrap License (SR). You may install and use the Software in

129 accordance with the terms and conditions of the applicable license 130 agreements, such as "shrinkwrap" or "clickthrough" license

132 Heritage Nortel Software

133 "Heritage Nortel Software" means the software that was acquired by

134 Avaya as part of its purchase of the Nortel Enterprise Solutions

135 Business in December 2009. The Heritage Nortel Software is the

SERVICE, OR AUTHORIZING OTHERS TO DO SO, YOU, ON
BEHALF OF YOURSELF AND THE ENTITY FOR WHOM YOU ARE 36 software contained within the list of Heritage Nortel Products located

at https://support.avaya.com/LicenseInfo under the link "Heritage

140 Heritage Nortel Software provided hereunder solely to the extent of

141 the authorized activation or authorized usage level, solely for the

143 for execution on, or for communication with Avaya equipment.

144 Charges for Heritage Nortel Software may be based on extent of

145 activation or use authorized as specified in an order or invoice.

1 Copyright

2 Except where expressly stated otherwise, no use should be made of materials on this site, the Documentation, Software, Hosted Service,

or hardware provided by Avaya. All content on this site, the

- documentation, Hosted Service, and the product provided by Avaya
- including the selection, arrangement and design of the content is owned either by Avaya or its licensors and is protected by copyright
- and other intellectual property laws including the sui generis rights
- relating to the protection of databases. You may not modify, copy,
- 10 reproduce, republish, upload, post, transmit or distribute in any way
- any content, in whole or in part, including any code and software
- unless expressly authorized by Avaya. Unauthorized reproduction, 13 transmission, dissemination, storage, and or use without the express
- 14 written consent of Avaya can be a criminal, as well as a civil offense
- 15 under the applicable law.

16 Virtualization

- The following applies if the product is deployed on a virtual machine. 92 Compliance with Laws
- Each product has its own ordering code and license types. Note,
- 19 unless otherwise stated, that each Instance of a product must be
- 20 separately licensed and ordered. For example, if the end user customer or Avaya Channel Partner would like to install two
- Instances of the same type of products, then two products of that
- 23 type must be ordered.

Third Party Components

"Third Party Components" mean certain software programs or

- portions thereof included in the Software or Hosted Service may
- contain software (including open source software) distributed under
- third party agreements ("Third Party Components"), which contain
- terms regarding the rights to use certain portions of the Software
- 30 ("Third Party Terms"). As required, information regarding distributed
- Linux OS source code (for those products that have distributed Linux OS source code) and identifying the code of t
- OS source code) and identifying the copyright holders of the Third
- 33 Party Components and the Third Party Terms that apply is available
- 34 in the products, Documentation or on Avaya's website at: https://
- support.avaya.com/Copyright or such successor site as designated
- by Avaya. The open source software license terms provided as Third 109
- Party Terms are consistent with the license rights granted in these
- Software License Terms, and may contain additional rights benefiting
- 39 You, such as modification and distribution of the open source 40 software. The Third Party Terms shall take precedence over these
- Software License Terms, solely with respect to the applicable Third 41
- Party Components to the extent that these Software License Terms
- 43 impose greater restrictions on You than the applicable Third Party
- The following applies only if the H.264 (AVC) codec is distributed with 17 Suspected Avaya product security vulnerabilities are handled per the
- 46 the product. THIS PRODUCT IS LICENSED UNDER THE AVC
- PATENT PORTFOLIO LICENSE FOR THE PERSONAL USE OF A
- 48 CONSUMER OR OTHER USES IN WHICH IT DOES NOT RECEIVE 20 Downloading Documentation
- 49 REMUNERATION TO (i) ENCODE VIDEO IN COMPLIANCE WITH
- 51
- PERSONAL ACTIVITY AND/OR WAS OBTAINED FROM A VIDEO
- PROVIDER LICENSED TO PROVIDE AVC VIDEO. NO LICENSE IS 124 Contact Avaya Support
- GRANTED OR SHALL BE IMPLIED FOR ANY OTHER USE
- 55 ADDITIONAL INFORMATION MAY BE OBTAINED FROM MPEG LA, 25 See the Avaya Support website: https://support.avaya.com for
- 56 L.L.C. SEE HTTP://WWW.MPEGLA.COM.

57 Service Provider

- THE FOLLOWING APPLIES TO AVAYA CHANNEL PARTNER'S
- 59 HOSTING OF AVAYA PRODUCTS OR SERVICES. THE PRODUCT 130 designated by Avaya), scroll to the bottom of the page, and select
- OR HOSTED SERVICE MAY USE THIRD PARTY COMPONENTS
- SUBJECT TO THIRD PARTY TERMS AND REQUIRE A SERVICE
- PROVIDER TO BE INDEPENDENTLY LICENSED DIRECTLY FROM
- THE THIRD PARTY SUPPLIER. AN AVAYA CHANNEL PARTNER'S 133 Australia Statements
- HOSTING OF AVAYA PRODUCTS MUST BE AUTHORIZED IN
- WRITING BY AVAYA AND IF THOSE HOSTED PRODUCTS USE
- OR EMBED CERTAIN THIRD PARTY SOFTWARE, INCLUDING
- BUT NOT LIMITED TO MICROSOFT SOFTWARE OR CODECS.
- THE AVAYA CHANNEL PARTNER IS REQUIRED TO
- 69 INDEPENDENTLY OBTAIN ANY APPLICABLE LICENSE
- 70 AGREEMENTS, AT THE AVAYA CHANNEL PARTNER'S EXPENSE,
- 71 DIRECTLY FROM THE APPLICABLE THIRD PARTY SUPPLIER.
- 72 WITH RESPECT TO CODECS, IF THE AVAYA CHANNEL
- 73 PARTNER IS HOSTING ANY PRODUCTS THAT USE OR EMBED
- 74 THE G.729 CODEC, H.264 CODEC, OR H.265 CODEC, THE

- 75 AVAYA CHANNEL PARTNER ACKNOWLEDGES AND AGREES
- 76 THE AVAYA CHANNEL PARTNER IS RESPONSIBLE FOR ANY
- AND ALL RELATED FEES AND/OR ROYALTIES. THE G.729
- CODEC IS LICENSED BY SIPRO LAB TELECOM INC. SEE
- 79 WWW.SIPRO.COM/CONTACT.HTML. THE H.264 (AVC) CODEC IS
- 80 LICENSED UNDER THE AVC PATENT PORTFOLIO LICENSE FOR
- THE PERSONAL USE OF A CONSUMER OR OTHER USES IN
- WHICH IT DOES NOT RECEIVE REMUNERATION TO: (I) ENCODE
- 83 VIDEO IN COMPLIANCE WITH THE AVC STANDARD ("AVC
- 84 VIDEO") AND/OR (II) DECODE AVC VIDEO THAT WAS ENCODED
- 85 BY A CONSUMER ENGAGED IN A PERSONAL ACTIVITY AND/OR
- 86 WAS OBTAINED FROM A VIDEO PROVIDER LICENSED TO
- 87 PROVIDE AVC VIDEO. NO LICENSE IS GRANTED OR SHALL BE
- 88 IMPLIED FOR ANY OTHER USE. ADDITIONAL INFORMATION
- 89 FOR H.264 (AVC) AND H.265 (HEVC) CODECS MAY BE
- 90 OBTAINED FROM MPEG LA, L.L.C. SEE HTTP://
- 91 WWW.MPEGLA.COM

- 93 You acknowledge and agree that it is Your responsibility for
- 94 complying with any applicable laws and regulations, including, but not
- limited to laws and regulations related to call recording, data privacy,
- 96 intellectual property, trade secret, fraud, and music performance
- 97 rights, in the country or territory where the Avaya product is used.

98 Preventing Toll Fraud

- 99 "Toll Fraud" is the unauthorized use of your telecommunications
- 100 system by an unauthorized party (for example, a person who is not a
- corporate employee, agent, subcontractor, or is not working on your
- 102 company's behalf). Be aware that there can be a risk of Toll Fraud 103 associated with your system and that, if Toll Fraud occurs, it can
- 104 result in substantial additional charges for your telecommunications

106 Avaya Toll Fraud intervention

- 107 If You suspect that You are being victimized by Toll Fraud and You
- 108 need technical assistance or support, call Technical Service Center
- Toll Fraud Intervention Hotline at +1-800-643-2353 for the United
- 110 States and Canada. For additional support telephone numbers, see
- the Avaya Support website: https://support.avaya.com or such
- 12 successor site as designated by Avaya.
- 114 Information about Avaya's security support policies can be found in
- 115 the Security Policies and Support section of https://
- 116 support.avaya.com/security.

113 Security Vulnerabilities

- 118 Avaya Product Security Support Flow (https://
- 119 support.avaya.com/css/P8/documents/100161515).

- 121 For the most current versions of Documentation, see the Avaya
- THE AVC STANDARD ("AVC VIDEO") AND/OR (ii) DECODE AVC VIDEO THAT WAS ENCODED BY A CONSUMER ENGAGED IN A 122 Support website: https://support.avaya.com, or such successor site
 - 123 as designated by Avaya.

- 126 product or Hosted Service notices and articles, or to report a problem
- 127 with your Avaya product or Hosted Service. For a list of support
- 128 telephone numbers and contact addresses, go to the Avaya Support
- 129 website: https://support.avaya.com (or such successor site as
- Contact Avaya Support.

132 Regulatory Statements

134 Handset Magnets Statement:

Danger:

- 135 The handset receiver contains magnetic devices that can
- 136 attract small metallic objects. Care should be taken to avoid
- 137 personal injury.

138 Industry Canada (IC) Statements

75 RSS Standards Statement

1 This device complies with Industry Canada licence-exempt RSS 2 standard(s). Operation is subject to the following two conditions:

- 1. This device may not cause interference, and
- This device must accept any interference, including interference that may cause undesired operation of the

Le présent appareil est conforme aux CNR d'Industrie Canada

- applicables aux appareils radio exempts de licence. L'exploitation est 65 66
- autorisée aux deux conditions suivantes:
 - 1. L'appareil ne doit pas produire de brouillage, et
 - 2. L'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

14 Radio Transmitter Statement

15 Under Industry Canada regulations, this radio transmitter may only

- 16 operate using an antenna of a type and maximum (or lesser) gain
- 17 approved for the transmitter by Industry Canada. To reduce potential
- radio interference to other users, the antenna type and its gain
- 19 should be so chosen that the equivalent isotropically radiated power
- 20 (EIRP) is not more than that necessary for successful
- 21 communication.

4

6

10

11

12

13

- 22 Conformément à la réglementation d'Industrie Canada, le présent
- émetteur radio peut fonctionner avec une antenne d'un type et d'un
- gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie
- Canada. Dans le but de réduire les risques de brouillage
- 26 radioélectrique à l'intention des autres utilisateurs, il faut choisir le
- 27 type d'antenne et son gain de sorte que la puissance isotrope
- rayonnée équivalente ne dépasse pas l'intensité nécessaire à
- 29 l'établissement d'une communication satisfaisante.
- This Class B digital apparatus complies with Canadian ICES-003.
- Cet appareil numérique de la classe B est conforme à la norme
- 32 NMB-003 du Canada.
- 33 Radiation Exposure Statement
- 34 This equipment complies with FCC & IC RSS102 radiation exposure
- limits set forth for an uncontrolled environment. This equipment 35
- 36 should be installed and operated with minimum distance 20cm
- between the radiator & your body. This transmitter must not be co-
- 38 located or operating in conjunction with any other antenna or
- 39 transmitter.
- 40 Cet équipement est conforme aux limites d'exposition aux
- 41 rayonnements ISEDétablies pour un environnement non contrôlé.
- 42 Cet équipement doit être installé et utilisé avec un minimum de 20
- 43 cm de distance entre la source de rayonnement et votre corps.

44 Japan Statements

- 45 Class B Statement
- 46 This is a Class B product based on the standard of the VCCI Council:100
- 47 If this is used near a radio or television receiver in a domestic
- 48 environment, it may cause radio interference. Install and use the
- 49 equipment according to the instruction manual.

この装置は、クラスB情報技術装置です。この装置は、家庭環境で使用 することを目的としていますが、この装置がラジオやテレビジョン受信機に 近接して使用されると、受信障害を引き起こすことがあります。

取扱説明書に従って正しい取り扱いをして下さい。 VCCI-B

51 Denan Power Cord Statement



55

56

60

Danger:

- 52 Please be careful of the following while installing the
- 53 equipment:
 - Please only use the connecting cables, power cord, and 115 AC adapters shipped with the equipment or specified by Avaya to be used with the equipment. If you use any other equipment, it may cause failures, malfunctioning, 117
- 57 58 59
 - Power cords shipped with this equipment must not be used with any other equipment. In case the above

guidelines are not followed, it may lead to death or 61 62 severe injury.



67

68

69

70

76

81

82

83

84 85

101

102

118

61

62

64 本製品を安全にご使用頂くため、以下のことにご注意ください。

- 接続ケーブル、電源コード、AC アダプタなどの部品は、必ず 製品に同梱されております添付品または指定品をご使用くだ さい。添付品指定品以外の部品をご使用になると故障や動作 不良、火災の原因となることがあります。
- 同梱されております付属の電源コードを他の機器には使用し ないでください。上記注意事項を守らないと、死亡や大怪我 など人身事故の原因となることがあります。

72 México Statement

- 73 The operation of this equipment is subject to the following two 74 conditions:
 - It is possible that this equipment or device may not cause harmful interference, and
- 77 2. This equipment or device must accept any interference, including interference that may cause undesired operation. 78
- 79 La operación de este equipo está sujeta a las siguientes dos 80 condiciones:
 - 1. Es posible que este equipo o dispositivo no cause interferencia perjudicial y
 - Este equipo o dispositivo debe aceptar cualquier interferencia, incluyendo la que pueda causar su operación no deseada.

86 Power over Ethernet (PoE) Statement

- 87 This equipment must be connected to PoE networks without routing
- 88 to the outside plant.

89 U.S. Federal Communications Commission (FCC) Statements

- 90 Compliance Statement
- 91 The changes or modifications not expressly approved by the party
- 92 responsible for compliance could void the user's authority to operate
- 93 the equipment.
- 94 To comply with the FCC RF exposure compliance requirements, this
- 95 device and its antenna must not be co-located or operating to
- 96 conjunction with any other antenna or transmitter.
- This device complies with part 15 of the FCC Rules. Operation is
- 98 subject to the following two conditions:
 - 1. This device may not cause harmful interference, and
 - 2. This device must accept any interference received, including interferences that may cause undesired operation.
- 103 This equipment has been tested and found to comply with the limits
- 104 for a Class B digital device, pursuant to Part 15 of the FCC Rules. 105 These limits are designated to provide reasonable protection against
- 106 harmful interferences in a residential installation. This equipment
- 107 generates, uses and can radiate radio frequency energy and, if not
- 108 installed and used in accordance with the instructions, may cause
- 109 harmful interference to radio communications. However, there is no
- 110 guarantee that interference will not occur in a particular installation. If
- 111 this equipment does cause harmful interferences to radio or
- 112 television reception, which can be determined by turning the
- equipment off and on, the user is encouraged to try to correct the
- 114 interference by one or more of the following measures:
 - · Reorient or relocate the receiving antenna.
 - · Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - · Consult the dealer or an experienced radio/TV technician for help.

- 1 Radiation Exposure Statement
- 2 This equipment complies with FCC radiation exposure limits set forth
- for an uncontrolled environment. This equipment should be installed
- 4 and operated with minimum distance of 8 in or 20 cm between the
- 5 radiator and your body. This transmitter must not be co-located or
- 6 operating in conjunction with any other antenna or transmitter.

7 EU Countries

15

- 8 This device when installed complies with the essential requirements
- 9 and other relevant provisions of the EMC Directive 2014/30/EU,
- 10 Safety LV Directive 2014/35/EU, and Radio Equipment Directive
- 11 2014/53/EU. A copy of the Declaration may be obtained from http://
- support.avaya.com or Avaya Inc., 4655 Great America Parkway,
- 13 Santa Clara, CA 95054-1233 USA.
- 14 WiFi and BT transmitter
 - Frequencies for 2412-2472 MHz, transmit power: 19.84 dBm
- Frequencies for 5180-5240 MHz, transmit power: 22.5 dBm 16

17 General Safety Warning

- · Use only the Avaya approved Limited Power Source power 18 supplies specified for this product. 19
- 20 · Ensure that you:
- Do not operate the device near water. 21
- 22 - Do not use the device during a lightning storm.
- Do not report a gas leak while in the vicinity of the leak. 23
- For Accessory Power Supply Use Only Limited Power 24 Supply Delta Electronics Inc. model:ADP-30HR B, output: 25 48Vdc, 0.66A. 26

27 Trademarks

- 28 The trademarks, logos and service marks ("Marks") displayed in this
- 29 site, the Documentation, Hosted Service(s), and product(s) provided
- 30 by Avaya are the registered or unregistered Marks of Avaya, its
- 31 affiliates, its licensors, its suppliers, or other third parties. Users are
- 32 not permitted to use such Marks without prior written consent from
- Avaya or such third party which may own the Mark. Nothingcontained in this site, the Documentation, Hosted Service(s) and
- 35 product(s) should be construed as granting, by implication, estoppel,
- 36 or otherwise, any license or right in and to the Marks without the
- 37 express written permission of Avaya or the applicable third party.
- 38 Avaya is a registered trademark of Avaya Inc.
- 39 All non-Avaya trademarks are the property of their respective owners.
- 40 Linux® is the registered trademark of Linus Torvalds in the U.S. and
- 41 other countries.
- 42 Android, Google and Google Play are trademarks of Google Inc.

Contents

Chapter 1: Introduction	8
Purpose	8
Change history	8
Chapter 2: Avaya Vantage [™] overview	9
Supported features	
Wireless handset features	
Third party applications	13
New in this release	13
Chapter 3: Getting started with Avaya Vantage [™]	14
Installing applications	14
Installing applicationsLogging in to and out of Avaya Vantage	15
Locking and unlocking Avaya Vantage	
Avaya Smart Lock	
Enabling Avaya Smart Lock	17
Removing or changing the trusted device	
Locking the device manually when Smart Lock is enabled	
Connecting a wireless handset	19
Turning the wireless handset on and off	20
Chapter 4: Navigation	22
Physical device layout	
Layout of Avaya Vantage [™] K165 and K175	
Layout of Avaya Vantage [™] K155	
Connectors and controls	
Wireless handset layout	28
Avaya Vantage Basic screen navigation	
Dial pad screen	
Contacts screen	30
Call screen	32
Chapter 5: Call management operations	35
Making audio or video calls	35
Making an emergency call	35
Making an audio or video call using the dial pad	
Making an audio or video call using contacts	36
Making an audio or video call from your Favorites list	36
Making an audio or video call using call history	37
Making a second call	37
Redialing a number	38
Managing calls	
Answering or declining an incoming call	

	Entering digits during a call	39
	Muting or unmuting a call	
	Placing a call on hold and resuming the call	40
	Toggling between calls	
	Transferring a call	
	Working with video functionality	
	Selecting an active audio device	. 41
	Ending a call	42
	Viewing call history	42
	Deleting all call information	. 43
	Working with conference calls	43
	Starting a conference call	. 43
	Merging calls to create a conference call	43
Ch	apter 6: Contact management operations	45
	Adding a contact	
	Editing a contact	. 46
	Deleting a contact	. 46
	Searching for a contact	47
	IP Office contact search options	47
	Setting contact display options	47
	Setting a contact as a favorite	48
	Synchronizing contacts and call history over Bluetooth	48
	Filtering contacts	
Ch	apter 7: Customization	51
	Modifying the ring tone	
	Disabling video using the privacy shutter	
	Changing the wallpaper	
Ch	apter 8: Resources	
	Documentation	
	Finding documents on the Avaya Support website	
	Viewing Avaya Mentor videos	
	Support	
	Using the Avaya InSite Knowledge Base	
	-	

Chapter 1: Introduction

₂ Purpose

- This document is intended for end users and describes how to use the Avaya Vantage[™] Basic
- application on an Avaya Vantage[™] device. This document also describes setup tasks performed
- by end users.
- Separate documentation is available for SDK developer applications. This document does not
- 7 provide information about SDK applications.

Change history

The following table describes the major changes made in this document:

Issue	Date	Summary of changes
Release 2.0, Issue 1	June 2018	Added information about the K155 device throughout the document.
		Updated <u>Supported features</u> on page 10.
		Updated New in this release on page 13.
		Added IP Office login information in <u>Logging in</u> to and out of <u>Avaya Vantage</u> on page 15.
		Updated the "Navigation" chapter.
		Minor rephrasing throughout the document.
		Added Editing a contact on page 46.
		Added Editing a contact on page 46.
		Updated <u>Filtering contacts</u> on page 49.

Chapter 2: Avaya Vantage[™] overview

- ² Avaya Vantage[™] is an Android[™] device that provides telephony and conferencing functionality.
- Avaya Vantage[™] combines the advantages of a customizable unified communications solution and a
- fully functional Android device. Use the Avaya Breeze[™] Client Software Development Kit (CSDK)
- and custom applications to integrate communications in business processes on your Avaya
- 6 Vantage[™] device.

9

10

11

12

13

14

15

17

18

22

24

26

27

- According to your business needs, you can choose from the following Avaya Vantage[™] device variants:
 - Avaya Vantage K175: Standard device with an 8-inch screen and an integrated camera for full access to video calls and conferences. You can cover the camera by using a mechanical camera shutter.
 - Avaya Vantage[™] K165: Standard device with an 8-inch screen that does not include an integrated camera. You can still receive video from other users.
 - Avaya Vantage[™] K155: Device with a small 5-inch screen. The device also includes a dial pad and an integrated camera.
- Avaya Vantage[™] supports the following communication applications:
 - Avaya Vantage[™] Basic
 - Avaya Equinox[®]
 - Avaya Vantage[™] Open
- This document is focused on Avaya Vantage[™] Basic usage. For more information about using other applications, see the following documents:
 - For more information about using Avaya Equinox® clients, see *Using Avaya Equinox®* for *Android, iOS, Mac, and Windows*.
 - Some features and services are not supported when an Avaya Equinox[®] client is deployed on Avaya Vantage[™]. These feature discrepancies are described in the Avaya Equinox[®] clients documentation.
 - For more information about using Avaya Vantage[™] Open, see *Using Avaya Vantage*[™] *Open*.
 - Note:
 - IP Office Release 11.0 only supports Avaya Vantage Basic. IP Office Release 11.0 does not support other clients, such as Avaya Equinox®, on Avaya Vantage not Support other clients, such as Avaya Equinox®.

In Release 2.0, the Avaya Vantage K155 device only supports Avaya Vantage Basic. It does not support Avaya Equinox or Avaya Vantage Open.

3 Supported features

Avaya Vantage [™] Basic feature	Supported with Avaya Aura®	Supported with IP Office
Make and receive audio calls	Yes	Yes
Caller ID and call information	Yes	Yes
Multiple line support	Yes	Yes ¹
Feature Access Codes (FACs) ²	Yes	Yes
Mute calls	Yes	Yes
Hold calls	Yes	Yes
Transfer calls	Yes	Yes
Forward calls	Yes, through FACs	Yes, through FACs or short codes
Toggle calls	Yes	Yes
Conferencing	Yes	Yes
Missed calls indication	Yes	Yes
Do Not Disturb mode	No	No
Message Waiting Indication (MWI)	Yes	Yes
Video calls	Yes	Yes
Emergency calls	Yes	Yes ³
Off Hook dialing	Yes	Yes
Call logs	Yes	Yes ⁴
Avaya Aura® Device Services contact services	Yes	No
PPM contacts	Yes	No
Local contacts, including Google [™] and Microsoft Exchange contacts	Yes	Yes

Table continues...

⁴ Call logs in IP Office are local to the device.

¹ For multiple line support to work on IP Office, you must enable the Call Waiting On feature for the user account. Otherwise the connection is treated as a single line.

Avaya Vantage[™] Basic does not have any UI representation for the FAC status. For example, if EC500 is enabled in the Avaya Aura[®] environment, then the UI of Avaya Vantage[™] Basic does not indicate that EC500 is enabled.

³ In the IP Office environment, you can make an emergency call only when you are logged in to Avaya Vantage[™]. You cannot make an emergency call from the Lock screen if the Lock mode is enabled and an administrator has configured emergency numbers in the 46xxspecial.txt file.

Avaya Vantage [™] Basic feature	Supported with Avaya Aura [®]	Supported with IP Office
Favorites	Yes	Yes
		Only local contacts can be added to the Favorites list
Presence	No	No
Instant Messaging	No	No

Important:

- ı IP Office Release 11.0 only supports Avaya Vantage[™] Basic. Other applications, such as
- ² Avava Equinox[®] on Avaya Vantage[™], are not supported.

4 Wireless handset features

A wired or wireless handset can optionally be used with Avaya Vantage[™]. The following section describes the wireless handset features.

Range

8

10

11

12

13

14

15

16

17

18

19

20

21

22

23

24

25

26

27

28

The handset uses Bluetooth technology. As a Class 2 device, the handset nominal range is 10 meters. In practical use this range might vary depending on the environment. If the handset was out of range, the connection is reestablished automatically when the handset is back in range. When the handset is not in range for more than 22 minutes, it turns off to prevent battery discharge. If the handset was turned off, the connection is reestablished automatically when the handset is turned on and back in range.

Battery service life

If used carefully, the expected service life of the battery is several years. Although the battery capacity is diminished over time, in general it does not affect normal handset use.

Battery talk time

When fully charged, the new battery provides approximately 12 hours of talk time. You might need to charge the battery before the first use to achieve the full talk time. To prevent damage to the battery, the protection system does not allow the battery to discharge below a certain point. Avaya Vantage[™] displays the battery charge level on the Notifications panel.

Battery standby time

When fully charged, the new battery provides approximately 60 hours of standby time. When the handset is not in range or Avaya Vantage[™] is turned off for approximately 22 minutes, the handset is turned off automatically to save battery. To turn on the handset again, press the **Power** button for approximately 2 seconds. The handset is not turned on automatically even if it is returned to the cradle.

Battery charging

The handset supports a contactless charging system. To charge the handset, place it in its cradle.

If the battery charge is low, the handset will notify you with warning tones. When you hear the warning tones, return the handset to its cradle to charge the battery.

- The handset uses a Lithium-lon battery with the battery management and protection system. The protection system allows to prevent the following situations:
 - Overcharging.
 - Over-discharging.
 - Charging if the ambient temperature is higher than 40 °C (102 °F).

6 Battery recharge time

- The battery fully recharges in less than 3 hours. You do not need to fully discharge the battery
- 8 before charging.

9 Battery disposal

At the end of the service life, remove the battery and deliver it to a battery recycling depot. Do not dispose of the battery in the normal waste stream.

12 Wireless handset LED indicator

The blue LED indicator shows the current state of the handset and is also used to indicate user actions.

Wireless handset state	LED indication	Notes
Wireless handset is in the Pairing mode.	LED flashes every 0.5 seconds.	Wireless handset exits the Pairing mode in 150 seconds.
Pairing completed successfully.	LED flashes 10 times at 0.1 seconds rate.	None
Wireless handset is used in a call	LED flashes 3 times every 3 seconds	None
Wireless handset is turned on and is connected to its base (Connected mode).	LED flashes 2 times every 5 seconds.	None
Wireless handset is trying to establish connection to its base (Linkback mode).	LED flashes every 0.5 seconds.	None
Wireless handset is out of range and is not trying to establish connection to its base (Standby mode).	LED flashes every 5 seconds.	Wireless handset is turned off after 22 minutes.
Incoming call.	LED flashes 3 times every 7 seconds.	None
Mute.	LED is on and flashes 3 times every 4 seconds.	None
Wireless handset has been turned on.	LED flashes 4 times.	None
Wireless handset has been turned off.	LED flashes 3 times.	None

Third party applications

- You can install third party applications on Google Play[™]. The system administrator determines the
- list of applications that you are allowed to install.

4 New in this release

- Avaya Vantage Release 2.0 introduces the K155 device. This device includes a 5-inch screen
- and a key pad. Currently, only Avaya Vantage[™] Basic is supported on the K155 device.

Chapter 3: Getting started with Avaya Vantage[™]

- This chapter describes general startup tasks, such as logging in or out, locking your Avaya
- Vantage[™] device, and enabling the Avaya Smart Lock feature. To enable the Avaya Smart Lock
- feature, you must first log in to your device manually.

6 Installing applications

- 7 About this task
- You can install applications from Google Play.
 - Note:

12

14

15

16

17

18

19

2.1

22

23

24

- You can use this procedure to install Avaya Vantage[™] Basic, Avaya Equinox[®], or Avaya Vantage[™] Open if these applications were not pre-installed by your administrator.
- Your installation policy might prevent you from installing certain applications.

Before you begin

- Ensure that you have a Google account to access Google Play.
- Work with your administrator to obtain permission to install applications on your Avaya Vantage[™] device.

Procedure

- 1. On your device open Google Play.
- In the Search bar, enter the appropriate search term and then tap Q.
 For example, to find Avaya Vantage™ Basic, enter Avaya Vantage Basic.
- 3. From the displayed search results, open the application page.
- 4. Install the application.
- 5. **(Optional)** If you want to set the installed telephony application as your primary telephony application, contact your administrator.
 - Some Avaya applications, such as Avaya Vantage[™] Basic or Avaya Equinox[®], require additional setup performed by your administrator. Contact your administrator to see if the installed application requires additional setup.

⊦Logging in to and out of Avaya Vantage[™]

2 About this task

- Use this procedure to log in to the Avaya Vantage[™] device manually. You can log in to the device by using either SIP or Avaya Aura[®] Device Services credentials.
- After the first login, you can activate the Avaya Smart Lock feature. The Avaya Vantage[™] device
- then automatically logs you in when you are within the range of the device while carrying a trusted
- ⁷ device.

10

11

12

13

14

15

16

17

18

20

21

22

28

Note:

- 8 This procedure is only applicable to Avaya Vantage[™] Basic and Avaya Equinox[®], but not to
- other telephony applications, such as Avaya Vantage[™] Open.

Procedure

- To log in, do the following:
 - 1. In **Username**, enter your SIP or Avaya Aura® Device Services user name.
 - In an IP Office environment, you must enter your SIP extension number.
 - 2. In **Password**, enter your user password.
 - 3. Tap Login.
 - If you are using Avaya Aura® Device Services credentials, you might also need to enter your SIP credentials.
 - 4. (Optional) At the first login, accept the software license agreement.
- Avaya Vantage[™] displays the Home screen or the main screen of the active telephony application depending on the settings configured by your system administrator.
- To log out, do one of the following:
 - Swipe down to open the notification area, and tap **Logout** (4).
 - On the Home screen, tap **Logout** (a).
 - In Settings > System, tap Logout.

25 Related links

Enabling Avaya Smart Lock on page 17

₂₇ Locking and unlocking Avaya Vantage[™]

About this task

- Use this procedure to lock and unlock the Avaya Vantage[™] device manually. You can lock the
- device for security and privacy reasons. Locking your phone does not log you out, so you can
- continue to receive calls.

- You can activate the Screen Lock feature so that the device is locked automatically after a period of inactivity. With IP Office deployments, this feature is disabled by default. 2
- You can also activate the Avaya Smart Lock feature. The Avaya Vantage[™] device then
- automatically unlocks when you are within the range of the device while carrying a trusted
- Bluetooth device. When the trusted device goes out of range, the Avaya Vantage[™] device is
- locked automatically.

Note:

- ⁷ This procedure is only applicable to Avaya Vantage[™] Basic and Avaya Equinox[®], but not for
- s other telephony applications, such as Avaya Vantage [™] Open.

Procedure

9

10

11

12

13

14

15

16

17

18

19

20

21

22

27

- To lock the device, do one of the following:
 - Swipe down to open the notification area, and tap **Lock** (A).
 - On the Home screen, tap Lock ().
- To unlock the device, do the following:
 - 1. On the locked screen, swipe up to open the login prompt.
 - 2. In the Enter Password field, enter your SIP or Avaya Aura® Device Services password.
 - If login is performed using SIP credentials, enter the SIP password.
 - If login is performed using Avaya Aura® Device Services credentials, enter the Avaya Aura® Device Services password.
 - 3. Tap ...

When the device is unlocked successfully, Avaya Vantage[™] displays the Home screen or the main screen of the active telephony application depending on the settings configured by your system administrator.

Related links

Enabling Avaya Smart Lock on page 17 24

Avaya Smart Lock

- When Avaya Smart Lock is enabled, the Avaya Vantage[™] device can automatically get unlocked 26 and log you in without the need to enter your account credentials. The automatic login or unlock
- happens based on the proximity of the device to a trusted Bluetooth device. When the trusted
- 28
- device goes out of range, the Avaya Vantage[™] device is locked automatically, and if configured, 29
- you are automatically logged out of the device.
- You can have your phone stay unlocked whenever it is connected to a trusted device. 31

Bluetooth device as the trusted device

- You can choose any Bluetooth device, such as Bluetooth headsets, watches, or Bluetooth-
- enabled Android smart phones, as the trusted device. However, you cannot select the Avaya
- ⁴ Vantage[™] wireless Bluetooth handset as the trusted device. When choosing your trusted device,
- avoid using a device that is always with your Avaya Vantage[™] device. For example, if you always
- have a Bluetooth keyboard and mouse with Avaya Vantage[™], do not use this as your trusted
- 7 device.

9

13

14

15

16

19

20

21

22

23

24

25

26

28

29

30

31

32

33

34

36

37

Note that only one device can be set as the trusted device.

Bluetooth connectivity range

The Bluetooth connectivity range can vary based on factors, such as your device model, the Bluetooth device, and the current environment. Bluetooth connectivity of the Avaya Vantage device can be up to 10 meters.

Avaya Smart Lock vs. Google Smart Lock

- Avaya Smart Lock can automatically log you in or out of the Avaya Vantage[™] device. Google Smart Lock does not support this capability.
- Google Smart Lock does not support an Android smart phone as the trusted device.

Enabling Avaya Smart Lock

About this task

Use this procedure to enable the Avaya Smart Lock feature. You can set your Avaya Vantage $^{\text{TM}}$ device to automatically unlock in certain circumstances, so you do not need to manually unlock the device with your PIN or password.

Before you begin

- On the Avaya Vantage[™] device, turn on Bluetooth.
- Pair a Bluetooth device to use as your trusted device.

Procedure

To enable the Avaya Smart Lock feature, do the following:

- 1. Open the **Settings** menu.
- 2. Tap Security > Trust agents.
- 3. Turn on Avaya Smart Lock and tap Back (←).
 - By default, Google Smart Lock is enabled on Avaya Vantage[™]. Since you can enable only one trust agent at a time, Google Smart Lock is disabled automatically when you enable Avaya Smart Lock.
- To set up automatic unlock options and add the trusted device, do the following:
- 4. Tap Security > Avaya Smart Lock.
- **Avaya Smart Lock** or **Google Smart Lock** are available only when the Screen lock feature is enabled.

- 5. Enter the password that you use to log in and unlock Avaya Vantage[™].
- 6. In the **Avaya Smart Lock** menu, select one of the following lock options:
 - Unlock/Lock: When the trusted device is within range, the Avaya Vantage[™] device unlocks automatically. When the trusted device goes out of range, the Avaya Vantage[™] device is locked automatically.
 - Login and Unlock/Logout: When the trusted device is within the range, the Avaya Vantage[™] device unlocks, and if required, logs you in automatically. When the trusted device goes out of range, the Avaya Vantage[™] device is locked and you are automatically logged out of the device.

After a logout, another user can log in to the device. When a new user logs in, all previous user data is wiped.

- 7. Tap Trust Device.
- 8. On the list of paired and connected devices, tap the device that you want to select as the trusted device.

On the Lock screen, you see the **Lock** () icon with a pulsing circle at the bottom. The icon indicates that the device is unlocked. When the trusted device is within range, the device remains unlocked until you manually lock it.

To access the device Home screen from the Lock screen, do the following:

9. Swipe up the 🗓 icon.

You see the 🗓 icon only when Smart Lock is set up and the trusted device is within range.

Removing or changing the trusted device

Procedure

10

11

12

15

16

17

18

19

20

23

24

25

26

27

28

29

30

- 1. Open the **Settings** menu.
- 2. Tap Security > Avaya Smart Lock.
- 3. Enter the password that you use to log in and unlock Avaya Vantage™.
 - 4. Tap Trust Device.
 - 5. On the list of paired and connected devices, do one of the following:
 - To select a new device as the trusted device, tap the device name.
 - To remove the trusted device, tap None.

2 Locking the device manually when Smart Lock is enabled

3 About this task

- Use this procedure to manually lock your Avaya Vantage[™] device when Avaya Smart Lock is set
- up and the trusted device is within range.
- When the trusted device is within range, tapping **Lock** () from the Home screen or from the
- notification area does not lock the device. The device displays the Lock screen with the **Lock** ($oxedsymbol{\Box}$)
- 8 icon.

Procedure

- On the Lock screen, tap the **Lock** () icon.
- The device stays locked until you manually unlock it with your account password.

Connecting a wireless handset

13 About this task

- Use this procedure to connect or pair a wireless handset with your Avaya Vantage[™] device. You cannot use the wired handset after you connect the wireless handset. You can connect only one wireless handset at a time.
- You need administrative privilege to remove the pairing with the wireless handset.

Before you begin

- Charge the handset battery by placing the handset in the cradle.
- Turn off the wireless handset.

21 Procedure

18

19

20

22

23

1. Lift the wireless handset from the cradle, and press and hold the top **Power** button for at least 10 seconds to enter the pairing mode.



To indicate that the handset is in the pairing mode, the handset LED starts flashing.

- 2. On the Home screen, tap **Applications**.
- 3. Tap Settings.
- 4. Tap Bluetooth.
- 5. Turn Bluetooth on.
- In the list of available devices, tap the entry that matches the ID on the handset label.
 When pairing is successful, Avaya Vantage[™] displays the wireless handset in the list of paired devices as connected.

Result

9

10

11

12

13

16

You can now use your wireless handset for calls as long as the handset is turned on. When the handset is turned off, you cannot use it for calls, but it is still paired with Avaya Vantage[™]. When you turn on the handset the next time, you do not need to repeat the pairing procedure.

Turning the wireless handset on and off

About this task

Your system administrator might connect an optional wireless handset to your Avaya Vantage[™]. To use the handset, you must turn it on.

- When the handset is turned on, the handset LED flashes every 5 seconds. When the handset is not being used on a call and is not in its cradle, it automatically turns off in 60 seconds.
- **Procedure**
- To turn the wireless handset on or off, press the **Power** button for approximately 3 seconds.
- When the handset turns on, the handset LED flashes 4 times.
- When the handset turns off, the handset LED flashes 3 times.

Chapter 4: Navigation

2Physical device layout

- You can choose from the following Avaya Vantage[™] device variants:
 - Avaya Vantage K175: Standard device with an 8-inch screen and an integrated camera for full access to video calls and conferences. You can cover the camera by using a mechanical camera shutter.
 - Avaya Vantage K165: Standard device with an 8-inch screen that does not include an integrated camera. You can still receive video from other users.
 - Avaya Vantage K155: Device with a small 5-inch screen. The device also includes a dial pad and an integrated camera.

12 Layout of Avaya Vantage[™] K165 and K175

The standard Avaya Vantage[™] device resembles a tablet in the portrait orientation. The only difference in the layout of the Avaya Vantage[™] K165 and K175 variants is that K175 comes with an integrated camera and a mechanical camera shutter.




Layout of Avaya Vantage[™] K155



Dial pad and functional keys


The Avaya Vantage[™] K155 device includes a physical dial pad and functional keys.

3




Connectors and controls

- The following images show the options available on the Avaya Vantage[™] device.
- Rear panel
- The rear panel contains a power adapter connector, an RJ9 headset port, and dual Ethernet ports
- with an internal Ethernet switch.



Note:

- 1 Avaya Vantage[™] K165 and K175 devices from Release 1.0 only have a single Ethernet port.
- 2 Devices with hardware version 5 and later support dual Ethernet ports.
- 3 The K155 device has dual Ethernet ports.
- K155 devices have an additional wireless module slot at the top-right side of the rear panel. The wireless module provides Wi-Fi and Bluetooth connectivity.



Slot for wireless module

Right side panel

On Avaya Vantage[™] K165 and K175, the right side panel contains a 3.5 mm audio jack socket and a USB Type-C port.



June 2018

6

8


- On Avaya Vantage K155, the right side panel contains a 3.5 mm audio jack socket and a USB
- Type-A port.




Left side panel 4

3

On all device variants, the left side panel contains a cordless or corded handset cradle connector.



Wireless handset layout




2

3 Avaya Vantage Basic screen navigation


5 Dial pad screen

The following sections show the Avaya Vantage[™] Basic Dial pad screen.

K165 or K175 device



K155 device




4 Contacts screen

2

The following sections show the Avaya Vantage[™] Basic Contacts screen.

K165 or K175 device



2

K155 device




4 Call screen


2

The following sections show the Avaya Vantage[™] Basic Call screen.

K165 or K175 device



K155 device



Chapter 5: Call management operations

- You can perform the following key call management tasks:
 - Making audio or video calls
 - Answering audio or video calls
 - Performing call control operations
 - Viewing your call history and missed calls
 - Working with conferences

Making audio or video calls

Making an emergency call

About this task

11

16

17

19

20

21

22

25

- Use this procedure to make a call to a preconfigured emergency services number. Your system administrator can configure the emergency services numbers.
- In the Avaya Aura[®] environment, you can make an emergency call even when you are logged out of Avaya Vantage[™] or when Avaya Vantage[™] is in the locked state.
 - In the IP Office environment, you can make an emergency call only when you are logged in to Avaya Vantage [™]. You cannot make an emergency call from the Login screen. You can make an emergency call from the Lock screen if the Lock mode is enabled and an administrator has configured emergency numbers in the 46xxspecial.txt file.

Procedure

- To make an emergency call from the Login or the Lock screen, in the lower-right corner of the screen, tap **Emergency call** and do one of the following:
 - To automatically dial the preconfigured emergency number with the highest priority, tap **Auto dial**.
 - To dial one of preconfigured emergency numbers manually, tap **Manual dial**, enter the number and then tap **o**.
 - With K165 and K175, you must tap the digits on the screen. With K155, use the physical keypad on the device to dial the number.

- To make an emergency call from Avaya Vantage[™] Basic, on the Dial pad screen, enter the emergency number and then tap
- With K165 and K175, you must tap the digits on the screen. With K155, use the physical keypad on the device to dial the number.

6 Making an audio or video call using the dial pad

Before you begin

If you are using a handset, lift the handset from the cradle.

Procedure

10

11

12

14

15

16

20

2.1

22

23

24

- 1. Tap the Dial pad tab.
- 2. Enter the telephone number you want to call.

With K165 and K175, you must tap the digits on the screen. With K155, use the physical keypad on the device to dial the number.

- 3. Tap one of the following:
 - 2: To make an audio call.
- To make a video call.

Making an audio or video call using contacts

19 Procedure

- Tap the Contacts tab.
 - 2. Select the required contact.
 - 3. Tap one of the following:
 - 2: To make an audio call.
- To make a video call.

Making an audio or video call from your Favorites list

27 Before you begin

28 Ensure that you have contacts in your Favorites list.

Note:

On IP Office, you cannot add IP Office personal contacts to your Favorites list.

Procedure

- Tap the Favorites tab.
 - 2. Select the required contact.
 - 3. Tap one of the following:
 - To make an audio call.
 - To make a video call.

Making an audio or video call using call history

Procedure

10

11

12

13

14

17

18

19

22

23

24

25

26

27

28

30

- 1. Tap the Call History tab.
- 2. Select the required contact or telephone number.
- Tap one of the following:
 - 2: To make an audio call.
 - To make a video call.

6 Making a second call

About this task

Use this procedure to make a second call while you are already on a call. You can have up to two calls at the same time. When one call is active, the other is placed on hold.

Note:

For multiple line support to work on IP Office, you must enable the Call Waiting On feature for the user account. Otherwise the connection is treated as a single line.

Procedure

- 1. While on a call, tap ...
- 2. In the Call Features window, tap New Call.

Avaya Vantage[™] Basic places the first call on hold and displays the Dial pad screen.

- 3. Do one of the following:
 - Enter the telephone number you want to call.

With K165 and K175, you must tap the digits on the screen. With K155, use the physical keypad on the device to dial the number.

• In the Contacts tab, select the required contact.

- In the Favorites tab, select the required contact.
 - In the Call History tab, select the required contact or telephone number.
 - 4. Tap one of the following:
 - 2: To make an audio call.
 - To make a video call.

After the connection is established, the second call becomes the active call. The first call remains on hold until you toggle between calls.

Redialing a number

About this task

Use this procedure to redial the last dialed number.

Procedure

10

11

12

13

14

15

16

17

18

24

25

- - Avaya Vantage[™] displays the last dialed number on the screen.
- 2. Tap one of the following:
 - Ito make an audio call.
 - : To make a video call.
 - You can also redial by double tapping or .

Managing calls

21 Answering or declining an incoming call

- To answer an audio call, do one of the following:
- Tap on your screen.
- Lift the handset from the cradle when you are using a wired or wireless handset.
- With K155, after answering the call, you can also use the and buttons on the device to toggle between your headset or speaker phone.

To decline a call, tap

3 Entering digits during a call

About this task

Use this procedure if you need to enter DTMF digits during a call. For example, when you check your voice mail, you are prompted to enter digits.

Procedure

9

10

11

12

13

16

22

27

29

- With K165 and K175, do the following:
 - While on an active call, tap .
 The application displays the dial pad.
 - 2. Enter the required digits.
- With K155, use the physical keypad on the device to enter the required digits.
 - On K155, the application does not display the entered digits on the screen.

Muting or unmuting a call

About this task

- Use this procedure to mute or unmute your microphone during an active call. When you are on mute, the other party cannot hear you.
- A muted call gets unmuted automatically when you switch to a different audio device during the call. However, you can perform call operations, such as putting the call on hold or resuming the call, during a muted call without getting unmuted.

- To mute yourself during a call:
- With K165 or K175, tap on the screen.
- With K155, press the button on the device keypad.
- To unmute yourself:
 - - With K155, press the button on the device again.
 - (Optional) On a wireless handset, press the Mute button to mute or unmute yourself.
- When you mute a call on your wireless handset, the application UI does not indicate that the call is muted.
- If you disconnect the call without unmuting the wireless handset, the handset remains muted.

2 Placing a call on hold and resuming the call

Procedure

- To place a call on hold, tap
- To resume the call, tap ...

7 Toggling between calls

About this task

Use this procedure to toggle between two calls when one call is active and the other call is on hold.

Note:

- For multiple line support to work on IP Office, you must enable the Call Waiting On feature for the user account. Otherwise the connection is treated as a single line.
- Procedure

14

15

16

17

20

21

22

23

24

25

26

27

28

29

30

- At the top of the Call screen, tap the label of the held call.
 The application displays the inactive or held call on the Call screen.
- 2. Tap 🕕.
 - The inactive call becomes the active call, and the other call is placed on hold.

Transferring a call

About this task

Use this procedure to transfer a call to another number. A direct transfer, as described in this procedure, is a blind or unattended transfer. When you perform a blind transfer, you cannot notify the other party about the transfer and you cannot return to your original call after starting the transfer procedure.

- 1. During an active call, tap ...
- 2. Tap <u>←</u> .
- 3. Do one of the following:
 - Tap Enter a number and then enter the phone number.
 - Tap Choose a Person and then select the required contact from the Contacts, Call History, or Favorites list.

4. Tap Transfer.

Working with video functionality

About this task

- Use this procedure to start, stop, pause and resume video during a call. When you pause your video, the application stops transmitting your video to the other party. When a video is paused,
- you can still receive video from the other party and your audio is still transmitted to the other party.

Note:

- If you switch to another application while on a video call, video will be stopped. To start video again, switch back to Avaya Vantage[™] Basic.
- For privacy reasons, Avaya Vantage[™] Basic always pauses outgoing video when the other party makes a video call or adds video to an existing call. To transmit your video to the other party, you must enable video manually.

Procedure

14

15

16

17

22

23

24

25

2627

28

29

30

31

32

- To start or stop video, tap and then tap Start Video or Stop Video.
- To pause or mute video:

- With K165 or K175, tap ⊠.

The icon becomes blue. You can tap this icon again to resume video.

With K155, press the ...

Press this button again to resume video.

Selecting an active audio device

About this task

By default, Avaya Vantage[™] uses speakers to transmit audio. If you have a headset or handset connected to your device, you can select which audio device to use in a call.

- From the Dial pad or Call screen, tap Audio device selector and select the required device from the list.
- To select your wireless handset as an active audio device when on a call, lift the handset from the cradle.
 - Avaya Vantage[™] automatically transfers audio to the wireless handset.
- To select the device speaker when using a wireless handset, do the following:
 - 1. Select the device speaker from **Audio device selector**.

2. Place the handset in its cradle.

3 Ending a call

- 4 About this task
- 5 Use this procedure to end a call.
 - Note:
 - 6 If you receive an incoming call while on another call, you cannot end the first call until you
 - 7 answer or decline the second call.
- Procedure

10

14

15

17

18

19

20

21

22

23

24

25

- To end an active call, tap on the screen.
- If you are using a handset, hang up by placing the handset in its cradle.

Viewing call history

- 12 Procedure
 - 1. Tap the Call History tab.
 - 2. Filter the call history using the following options:
 - All Calls
 - Missed Calls
 - Outgoing Calls
 - Incoming Calls
 - 3. (Optional) To view the call history of the synchronized device:
 - With K165 or K175, tap , which is at the top-right side of the contacts list.
 - With K155, in the filter options drop-down (), tap Bluetooth Sync.

Avaya Vantage[™] Basic displays the call history of the synchronized mobile device in the Call History tab if:

- Call history sharing is enabled.
- The paired mobile device is connected with Avaya Vantage[™].
- 6 Related links
- 27 Synchronizing contacts and call history over Bluetooth on page 48

Deleting all call information

- 3 Procedure
 - 1. Tap the **Call history** tab.
 - 2. Filter the call history and select Clear All Calls.
 - Tap **Delete** in the Confirmation dialog box.

7 Working with conference calls

Starting a conference call

- 10 About this task
- Use this procedure to start an audio or video conference call.
 - Important:
 - This procedure does not apply to IP Office deployments. With IP Office, you can only merge calls to create a conference call. Video conference is also not supported with IP Office.
 - Procedure

14

15

16

17

18

20

21

22

23

- 1. During an active call, tap ...
- 2. In the Call Features window, tap **Add Someone**.
- 3. Do one of the following:
 - Tap Enter a number and then enter the phone number.
 - Tap **Choose a Person** and then select the required contact from the Contacts, Call History, or Favorites list.
- 4. Tap Add Someone.
- A call is placed to the selected participant. When the participant answers, the conference starts.

Merging calls to create a conference call

- 26 About this task
- Use this procedure to merge two calls to create a conference call.

Before you begin

You must have two ongoing calls.

- 1. From the Call screen, tap ...
- 2. Tap \(\psi\) to merge both calls into a conference call.

Chapter 6: Contact management operations

2 Adding a contact

	Λ	L	_		4	46		400	1.
3	н	IJ	O	u	ι	un	IIS.	tas	ĸ

- Use this procedure to add new contacts in Avaya Vantage[™] Basic. You can save a personal
- contact in the local storage or to the enterprise directory. In the IP Office environment, you can add
- a personal contact to the IP Office personal directory.
- In Avaya Vantage[™] Basic, you can modify and delete personal contacts added to the enterprise or
- IP Office personal directory. Any modification to such contacts is synchronized automatically
- between Avaya Vantage[™] Basic and the enterprise or IP Office personal directory.
 - Note that Avaya Vantage[™] deletes local contacts data when another user logs in to the device. To store local contacts data, enable data backup and provide a backup account in the Settings menu.

Procedure

10

11

12

13

14

15

17

18

19

20

21

22

23

25

26

- 1. Tap the **Contacts** tab.
- 2. Tap +.
- 3. Choose one of the following options:
 - Local Contact: To store the contact locally on the device.
 - Enterprise Contact: To add the contact to the Avava Aura® enterprise directory.
 - Personal Contact: To add the contact to the IP Office personal directory.

Either the Enterprise Contact or the Personal Contact option is available depending on the environment in which the device is installed.

- 4. In the First Name and Last Name fields, enter the name of the new contact.
- 5. Do the following to add the phone number of the contact:
 - a. Tap Add phone number.
 - b. In the drop-down list, select the appropriate phone category.
 - c. In the **Phone** field, enter the phone number.
 - You must provide at least one phone number for each contact.
- Use the on-screen keyboard to enter contact details. Do not use the physical keypad on 28 the K155 device.

- 6. (Optional) Repeat the previous step to add more phone numbers for the contact.
- (Optional) Add other information about the contact, such as the job title, company name, and address.
- 8. Tap **Done**.
 - The contacts and their details are displayed in your Contacts list.

Editing a contact

About this task

- 8 Use this procedure to edit the details of a contact.
- You can modify local contacts and personal contacts added to the enterprise or IP Office personal directory. Any modification to personal contacts is synchronized automatically between Avaya Vantage Basic and the enterprise or IP Office personal directory.

Procedure

12

13

14

15

16

17

18

20

25

26

28

- 1. Tap the **Contacts** tab.
 - 2. In the contacts list, tap the contact that you want to edit.
- On the Contact Details page, tap Edit.
- Tap the field that you want to edit.
 - 5. Use the on-screen keyboard to modify the information.
 - Tap **Done**.

Deleting a contact

About this task

- Use this procedure to delete a contact from the contacts list.
- You can delete local contacts and personal contacts added to the Avaya Aura® enterprise or IP Office personal directory.

- 1. Tap the **Contacts** tab.
- 2. In the contacts list, tap the contact that you want to delete.
- 3. On the Contact Details page, tap **Delete**.
 - Tap Yes to confirm the action.

Searching for a contact

- About this task
- Use this procedure to search for a contact.
- In the IP Office environment, IP Officesystem contacts are visible only through search.
- Procedure
 - 1. Tap the **Contacts** tab.
 - 2. On K155, tap the cicon.
 - 3. In the **Search** field, start typing the name of the contact that you want to look for.
 - The application displays all relevant contacts.

IP Office contact search options

- In the IP Office environment, Avaya Vantage[™] Basic and the standard Contacts application (□) available on the Avaya Vantage[™] device support centralized IP Office directory contact search, which includes the following:
 - IP Office system contacts across a small community network (SCN).
 - IP Office hunt group contacts across a small community network (SCN).
 - IP Office external contacts in the LDAP, system, and HTTP directories configured in IP Office.



Setting contact display options

- 19 About this task
- Use this procedure to modify how contact names are displayed in the Contacts list. Contacts can be displayed with the first name first or with the last name first.
 - Procedure

15

17

22

24

25

26

28

- 1. In Avaya Vantage[™] Basic, tap Extension > User Settings.
- 2. Tap Application.
- 3. In Display preferences, tap **Name display preferences** and then select one of the following options:
 - First Name First: To display the contact names with the first name first followed by the last name.
 - Last Name First: To display the contact names with the last name first followed by the first name.

- 4. Tap Name sort preferences and then select one of the following options:
 - First Name First: To sort the contact list based on the first name.
- Last Name First: To sort the contact list based on the last name.

4 Setting a contact as a favorite

- About this task
- 6 Use this procedure to add a contact to your Favorites list.
 - Note:
 - 7 In the IP Office environment, you cannot add IP Office personal contacts to you Favorites list.
- Procedure

10

21

23

25

26

27

28

- 1. Tap the **Contacts** tab.
 - 2. Tap the appropriate contact.
- 3. In Contact Details, tap 🌣, which is beside the contact's name.

Synchronizing contacts and call history over Bluetooth

About this task

- Use this procedure to synchronize your mobile phone's contacts and call history with the Avaya Vantage[™] device over Bluetooth. After the synchronization, you can access all contacts and call history of the paired phone on your Avaya Vantage[™] device when the devices are connected.
- Contacts from all accounts on your mobile phone, including Google and Facebook, are shared with the Avaya Vantage[™] device, but only so long as the devices remain connected. If Bluetooth connectivity is lost, the shared phone contacts and call history data is automatically deleted from the Avaya Vantage[™] device.

- To pair a mobile phone with the Avaya Vantage[™] device, do the following:
- 1. On the mobile phone and the Avaya Vantage[™] device, turn on Bluetooth.
- On the Avaya Vantage[™] device, tap Settings > Bluetooth.
 - 3. In Available devices, tap the name of the mobile phone.
 - 4. On the screens of both devices, do the following:
 - a. Verify the displayed passcode.
- b. Select the option to allow the paired device to access the contacts and call history.

- c. Tap **Pair**.
- To synchronize and share contacts and call history from the paired phone, do the following:
 - 5. On the Avaya Vantage[™] device, tap **Settings** > **Bluetooth**.
 - 6. In Bluetooth Contact & Call History Sharing, enable the following:
 - Contact Sharing
 - · Call History Sharing

The synchronized contacts become available through the following:

- The Contacts tab in the Avaya Vantage[™] Basic or Avaya Equinox[®] application.
- The standard Contacts application on the Avaya Vantage[™] device.

The synchronized call history is available on the Call History tab of the Avaya Vantage[™] Basic application.



- 12 Any third-party application that is capable of displaying call logs from the default
- 13 telephony application can display the call history from the synchronized mobile device.
- 14 After the Bluetooth connection is disconnected, if such application is caching the call
- 15 history and not clearing the cache, the call history from the synchronized device is
- 16 retained.

7 Filtering contacts

18 Procedure

10

11

19

20

21

22

23

24

25

26

27

28

29

30

31

- 1. Tap the Contacts tab.
- 2. Filter the contacts using the following options:
 - All Contacts: To view the local and enterprise contacts.
 - Enterprise Contacts: To view Avaya Aura® enterprise contacts.
 - Personal Contacts: To view IP Office personal contacts.
 - Local Contacts: To view the contacts stored in the local storage, such as Google or Exchange contacts.
- 3. **(Optional)** To view the contacts of the synchronized device:
 - With K165 or K175, tap ①, which is at the top-right side of the contacts list.
 - With K155, in the contacts filter drop-down (), tap **Bluetooth Sync**.

Avaya Vantage[™] Basic displays the contacts of the synchronized device under All Contacts and Local Contacts if:

Contact sharing is enabled.

The paired device is connected with Avaya Vantage[™].

2 Related links

Synchronizing contacts and call history over Bluetooth on page 48

Chapter 7: Customization

2 Modifying the ring tone

- About this task
- 4 Use this procedure to change the default ring tone for incoming calls in Avaya Vantage[™] Basic.
- You can select from a list of built-in and administrator-downloaded ring tones.
- You can change the ring tone in the telephony application but not on the Avaya Vantage device.
- Procedure

10

11

20

21

22 23

24

25

- 1. In Avaya Vantage[™] Basic, tap **Extension > User Settings**.
- 2. Tap Audio/Video.
- 3. In Ring Preferences, tap Choose Ringtone.
- 4. Select the new ring tone and tap **OK**.

Disabling video using the privacy shutter

- 13 About this task
- On the K175 device, you can physically prevent the camera from capturing video using a privacy shutter. When you close the shutter, the camera is still on, but it only transmits a black
- background. The camera LED is also on, indicating that the camera is working.
 - Note:
 - The K155 device does not include a physical shutter. You can use the video mute button (to disable video.

- To disable video capturing, shift the lever located above the camera to the leftmost position so that the camera is entirely covered with the shutter.
 - If the shutter does not cover the entire camera, the camera might be able to capture partial video.
- To enable video capturing, shift the lever to the rightmost position so that the shutter does not cover the camera.

Changing the wallpaper

About this task

Use this procedure to change the default wallpaper on the Avaya Vantage[™] device. You can select an administrator-downloaded wallpaper or any other image file available on the device.

Procedure

9

10

11

- Tap Settings > Display.
 - 2. Tap Wallpaper.
 - 3. Tap one of the following options available on the device:
 - Live wallpapers
 - Photos
 - Wallpapers
- 4. Select the new wallpaper and tap **Set wallpaper**.

Chapter 8: Resources

Documentation

See the following related documents at http://support.avaya.com.

Title	Use this document to:	Audience
Deploying		
Installing and Administering Avaya Vantage [™]	Install, configure, and maintain Avaya Vantage [™] .	Implementation personnel
Using		
Using Avaya Equinox® for Android, iOS, Mac, and Windows	Set up and use Avaya Equinox® clients.	End users Support personnel
Using Avaya Vantage [™] Open	Use Avaya Vantage [™]	 End users Support personnel

5 Finding documents on the Avaya Support website

Procedure

10 11

12

13

14

- 1. Navigate to http://support.avaya.com/.
- 2. At the top of the screen, type your username and password and click Login.
- 3. Click Support by Product > Documents.
- 4. In **Enter your Product Here**, type the product name and then select the product from the list
- 5. In **Choose Release**, select an appropriate release number.
- 6. In the **Content Type** filter, click a document type, or click **Select All** to see a list of all available documents.
 - For example, for user guides, click **User Guides** in the **Content Type** filter. The list displays the documents only from the selected category.
- 7. Click **Enter**.

Viewing Avaya Mentor videos

- Avaya Mentor videos provide technical content on how to install, configure, and troubleshoot
- 3 Avaya products.

4 About this task

Videos are available on the Avaya Support website, listed under the video document type, and on the Avaya-run channel on YouTube.

Procedure

10

11

12

13

14

15

16

17

18

- To find videos on the Avaya Support website, go to http://support.avaya.com and perform one of the following actions:
 - In Search, type Avaya Mentor Videos to see a list of the available videos.
 - In **Search**, type the product name. On the Search Results page, select **Video** in the **Content Type** column on the left.
- To find the Avaya Mentor videos on YouTube, go to www.youtube.com/AvayaMentor and perform one of the following actions:
 - Enter a key word or key words in the Search Channel to search for a specific product or topic.
 - Scroll down Playlists, and click the name of a topic to see the available list of videos posted on the website.



19 Videos are not available for all products.

₀ Support

- Go to the Avaya Support website at http://support.avaya.com for the most up-to-date
- documentation, product notices, and knowledge articles. You can also search for release notes,
- downloads, and resolutions to issues. Use the online service request system to create a service
- request. Chat with live agents to get answers to questions, or request an agent to connect you to a
- support team if an issue requires additional expertise.

7 Using the Avaya InSite Knowledge Base

- The Avaya InSite Knowledge Base is a web-based search engine that provides:
 - Up-to-date troubleshooting procedures and technical tips
- Information about service packs
 - Access to customer and technical documentation

29

- Information about training and certification programs
- Links to other pertinent information
- If you are an authorized Avaya Partner or a current Avaya customer with a support contract, you can access the Knowledge Base without extra cost. You must have a login account and a valid
- 5 Sold-To number.

10

11

12

- Use the Avaya InSite Knowledge Base for any potential solutions to problems.
 - 1. Go to http://www.avaya.com/support.
 - 2. Log on to the Avaya website with a valid Avaya user ID and password.
 - The system displays the Avaya Support page.
 - 3. Click Support by Product > Product Specific Support.
 - 4. In Enter Product Name, enter the product, and press Enter.
 - 5. Select the product from the list, and select a release.
 - 6. Click the **Technical Solutions** tab to see articles.
- 7. Select relevant articles.

Index

	synchronizing	48
		 0
active call	contact search	
entering digits <u>39</u>	IP Office	<u>47</u>
add a contact		
answering a call <u>38</u>	D	
Avaya Smart Lock <u>16</u>	D	
enabling	declining a call	38
Avaya Vantage Basic	delete the call history	
installing <u>14</u>	deleting a contact	
supported features <u>10</u>	device layout	
Avaya Vantage device layout	Avaya Vantage K155	
K155 <u>24</u>	•	
K165 and K17522	K165 and K175 standard Avaya Vantage device	
Avaya Vantage overview9	disabling video	<u>51</u>
	display	
	changing wallpaper	
C	document changes	
	DTMF digits	<u>39</u>
call history		
deleting	E	
viewing <u>42</u>	_	
call management <u>35</u>	editing a contact	46
calls	emergency call	35
adding video to a call41	enabling	
answering <u>38</u>	Avaya Smart Lock	17
ending <u>42</u>		
making a call using a call history37	=	
making a call using contacts36	F	
making a call using dial pad36	for a house a	40
making a call using favorites36	features	<u>10</u>
making an emergency call35		
making a second call37	G	
toggling between calls		
transferring40	Google Play applications	<u>13</u>
call transfer		
unattended transfer40	Н	
change history8	П	
changing default ring tone <u>51</u>	handset	
changing wallpaper <u>52</u>	wireless	19
conference call43	Wil Closs	<u>10</u>
merging calls into conference43		
connecting	1	
wireless handset <u>19</u>		
connectors and controls	ignoring a call	
contacts	InSite Knowledge Base	
adding a contact45	installing applications	
	IP Office contact search	<u>47</u>
adding to favorites		
deleting a contact	1	
editing a contact	L	
filtering	layout	
making a call using contacts36	Avaya Vantage K155	24
searching47	K165 and K175 standard Avaya Vantage device	
contacts and call history	11700 and 11770 standard Avaya vantage device	<u>~~</u>

legal notices	•	
locking		
locking when Smart Lock is enabled 19		
logging in		<u>39</u>
logging out		
М	V	
	video	
making a call	adding video to a call	
using call history <u>37</u>		
using contacts list36	-	
using dial pad36		
using favorites list36		<u>42</u>
making a call using contacts36		
making an emergency call		
making a second call		
merging calls into conference	WII 01000 Harradot	
muting a call39	icatares	The state of the s
	layout	
N	LED indication	
	turning on and off	<u>20</u>
new in this release <u>13</u>	3	
_		
P		
physical layout		
placing a call on hold40	<u>)</u>	
ports	<u>i</u>	
R		
••		
redialing a number38	3	
rejecting a call38	<u> </u>	
related documentation53	<u>3</u>	
resuming a call40	<u>)</u>	
ring tone		
changing default ring tone <u>51</u>	<u> </u>	
S		
searching contacts47		
second call37	, -	
select active audio device41		
setting contact display options47	, -	
support <u>54</u>		
synchronizing contacts and call history	<u>1</u>	
Т		
third party applications13		
toggling calls40	<u>)</u>	
trusted device		
changing <u>18</u>		
removing <u>18</u>		
turn on the wireless handset20	<u>)</u>	