Model:C6401



Thank you for choosing the C6401. In order to optimize the user experience, please read this manual carefully before operation, and keep this manual properly for future use.

Warning:

- 1. This product is not a toy. To avoid fire, burns, personal injury or electric shock, please install out of the reach of children.
- 2. In order to ensure the normal operation of the lamp, please use the voltage indicated on the package.
- 3. Please do not modify the lamps during the warranty period.
- 4. Do not install near gas or electric heaters, fires, candles or any dangerous objects.
- 5. Before installation, please check whether the lamps and various parts are in good condition.
- 6. Be sure to cut off the power before installation.
- 7. Do not expose the lamp to corrosive conditions.
- 8. If the power cord is damaged, please cut off the power immediately and stop using it.

Technical Specification:

Connection method: 2.4G Wifi&Bluetooth Control method: APP/voice/button Adapter input voltage:100-240VAC Adapter output voltage: 12VDC/3A Rated working voltage: DC12V Rated power: 18W String light type: P12A Lamp color: RGB Control method: TTL Memory function: yes Working temperature: -20°C~+60°C Controller levels of protection: IP 20 Lamps levels of protection: IP65 Work with Amazon Alexa and Google Assistant.

Packinglist:

- 1. C014 controller
- 2. Infrared remote control
- 3. Waterproof power supply 12V/3A wall plug horizontal American standard UL (IP44)
- 4. Christmas LED String lights (50 pixels)
- 5. 1 copy of the manual
- 6. installation card buckle * 5



Manualof Controller:



Button Instruction:

Mode key: Mode key for switching non-music modes.

Speed key: Adjust the effect speed for non-music modes.

Switch 🕐: Short press is on/off. When the device is on, long press in 5 seconds is reset to pairing mode. Light will blink in white.

Technical parameter:

Working temperature: -20°C~+60°C Size: 85mmx35mmx16mm (excluding wires)

Product wiring diagram:



APP Intelligent operation introduction:



Local mode: Sync to music with built-in mic, 6 modes. APP mode: use mic of phone.

Color adjustment Tap + to add selected color, long press color dot to delete.



Adjustment of speed, sensitivity, color (partial) and direction (partial).



Dynamic mode Recommend scene included 15 popular modes. Custom Scene support DIY static color of each segment and dynamic modes.



Supporting Static, Gradient,Jump,Breathe, Flashing Rainbow and Stream modes DIY.

Set name for DIY mode to reserve.

On is to open transition effect for segment.

Preview to review the DIY mode. Add the scene to custom scene.

	C OG402 Smart LED String type	C6402 Smart LED String light	Click from other page to enter to device page. Click pen icon to rename the device.	
	tinin (Dense Information 1 Dense Information 1 Dense Universe Dense De	Timer: Set the device off in given time. Schedule: Set the device on or off in specified time.	
• <i>⊓</i> ● =	() • 750 + #	HELE Facilitates	Share the device to other people for controlling. Create a group to control multiple devices.	

Γ

Pairing Instruction:

APP Download. Search the **Smart Life** from Google Play or App Store. You can also scan the QR code from below.

1.Download the APP and **Log In** with existing account or **Sign Up** the new account.



- 2.Power on the device, confirm the device is blinking rapidly in white. Turn on the Bluetooth and Wi-Fi of phone. Please make sure the phone is connecting the 2.4GHz Wi-Fi router.
- 3.Tap **Add Device** or the plus icon (+) in the top-right corner on the **Home** page to go to the device adding page.



4.Enter the Wi-Fi password and click Next. Make sure the Wi-Fi is 2.4GHz not the 5GHz. Because the Wi-Fi chip is 2.4GHz. Wait about twenty seconds and the device will be added completely.



5. Then the device can be found in home page. Now you can play it with your imagination.



6.Click the edit icon in the upper right corner to show more gameplay.

C 06402 Smart LCD String light		4		
ine .	100	C6402 Smart LED String light 🕜		Modify device name
		Device information		
Sheeke		Tei-to-Rue and Aylomatori		Linkage with other equipment
		Device Review		
		Office helfscales		
		-		
		Stare Oneine		Share control with family
		Dana (bargi		
		FAQ & Peedback		
		Disct Dents Network Court Inter 1		
		Device Optime	Linkage with other devices to achieve or	Linkage with other devices to achieve one-click execution
🔘 (* .n. e. 🗰		Referent Daving		and automation

Step for Bluetooth control:

Note: The Bluetooth control is for the device that disconnected from router.

- 1. Open the Bluetooth and use the Bluetooth for pairing.
- 2. Make sure the router is power off and close the phone Wi-Fi. Keep the 4G/5G internet and Bluetooth open. Wait about 3-5 mins.
- 3. After that, the device can be controlled by Bluetooth. Even though the 4G/5G network of phone is off.

Common problems and solutions

1. Unable to connect to your Wi-Fi network.

Please make sure to enter the correct Wi-Fi password during use. Wi-Fi settings.

Check your internet connection for problems. If the Wi-Fi signal is too weak,

please reset your wireless router and try again.

- 2. The installer is not working properly.
- (1)Then close all applications running in the background and reopen the Smart Life APP.
- (2) Uninstall and reinstall the Smart Life app and repeat.
- 3. The smart light strip is not responding.
- (1) Check whether the smart string light is turned off. If yes, turn them on and wait until the smart light strip reconnects to The wireless network works automatically.
- (2) Check if there is any problem with your internet connection. If necessary, reset the wireless router and try again.

Guarantee:

- 1. During the warranty period, we provide services including refunds or free replacement for those who use the device for its intended purpose.
- 2. This warranty does not include:
- (1) Malfunction or damage caused by improper use, repair or modification.
- (2) Failure or damage due to falling.
- (3) Failure or damage caused by fire, earthquake, flood, lightning and other natural disasters.
- (4) Malfunction or damage when used other than for its intended purpose.
- (5) Failure or damage caused by third-party products.
- (6) Failure or damage to the product caused by human factors.

FCC Warning:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference

(2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following.

Measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

—Consult the dealer or an experienced radio/TV technician for help.

Note: The Grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. such modifications could void the user's authority to operate the equipment.

To maintain compliance with FCC's RF exposure guidelines, the distance must be at least 20 cm between the radiator and your body, and fully supported by the operating and installation configurations of the transmitter and its antenna(s).

MADE IN CHINA