

OVERVIEW BLUETOOTH® OPERATION Bluetooth specifications: Bluetooth® version 5.0 Please ensure that the Bluetooth function has been turned. Support profile: A2DP,AVRCP,HFP,HID,AVCTP,AVDTP,SPI on in the settings of your Bluetooth enabled device, Transmission distance: up to 10m (This may vary based on Turn the earbuds on by pressing the power/multifunction button until the LED indicator light begins to flash. The LED indicator light will flash to detect Bluetooth enabled devices near you and will enter pairing mode, environmental factors or the type of Bluetooth® device being Kai Bluetooth®Earbuds Built-in battery: 65 mAh Lithium Battery USB Recharge voltage: 3,7V 3. "GEMLINE EB" will appear on the Bluetooth device list, select 100253-001B Frequency Response: 20hz-20Khz GEMLINE EB " to establish pairing. Sensitivity: 100dB ± 3 When you want to play audio from another Bluetooth device, disconnect the earbuds from the original device and follow steps 1-3 to re-pair the Earbuds with a new Bluetooth enabled device. . LED Indicator Light PACKING LIST LED Indicator Light
 Micro USB Charging Port
 Volume Up / Next Track Button
 Power/Multifunction Button
 Volume Down / Previous Track Button
 Mic Bluetooth® Earbuds USB Charging Cable
Silicone Earbud Covers
Travel Case
User Manual BUTTON CONTROL Power On/Off: Press and hold the power/multifunction button for approximately 4 seconds. Play/Pause: Press the power/multifunction button once to (BC) Play/Pause

封面

CHARGING THE EARBUDS When the battery is low, please charge via the included USB cable. The charging time is approximately 2 hours, and provides up to 5-6 hours of continuous operation.

The LED indicator light will be red during charging and will turn off once it is fully charged. When the battery is low, the LED indicator light will flash red.

WARNING

- WANNING

 1. Do not disassemble, repair, or modify the earbuds.

 2. Do not place product in or near fire to avoid danger, as it.

 3. Avoid storage at extreme temporatures, this can shorten the battery life and may affect the earbuds.

 4. Keep the earbuds dry and do not store the earbuds in damp areas to avoid damage to the earbuds.

 5. Avoid dropping the earbuds as it may cause damage the

product.

- 1. To prolong the earbuds life span and to avoid hearing damage, please do not listen to music under high volume for long periods of time.

 2. When an error occurs with the earbuds, please turn of f the earbuds and restart it to troubleshoot.

 3. When the earbuds power is low the Bluetooth range may

1

- be affected. Please charge the earbuds to avoid disruptions during use.

PROBLEM	TROUBLESHOOTING METHOD
Unable to pair the earbuds with a mobile device	Inspect whether the earbuds are searching for a Blastoch enabled device to connect to. If not, a Blastoch enabled device to connect to. If not, 2, 20 filliadly to enable gain and connecting to a desired device can be affected if multiple devices are equipped, turned, and in range for Blastoch connectivity. Please turn off or disable the Blastoch connectivity. Please turn off or disable the Blastoch turned on the drift or devices. 3. The power of the battery is insufficient, please rechange the earburgher.

TROUBLESHOOTING METHOD PROBLEM Inspect the distance between the earbuds and le Bluetooth enabled device, it may exceed the luctooth transmission range. luctooth transmission range.
Inspect if there is an obstacle between the earbuds and the Bluctooth enabled device. ime to time The power of the battery is insufficient, please charge the earbuds.

Inspect the volume of the connected earbuds Bluetooth enabled device and adjust the volume The sound is low or The power of the battery is insufficient, please

2

arge the earbuds. The power of the battery is insufficient, please recharge the earbuds.
 Restart the earbuds. The Bluetooth remains OF

The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by The Gem Group is under license. Other trademarks and trade names are those of their respective

3

applicables auxappareils radio exempts de licence. L'exploitation

est autorisée aux deux conditions suivantes :(1) l'appareil ne doit

accepter tout brouillage radioélectrique subi, même si le brouillag

pas produire de brouillage, et(2) l'utilisateur de l'appareil doit

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules, These limits are designed to provide

of the PCC Nates, mase simils are designed to provide reasonable protection against harmful interference in a residential installation, This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful

interference to radio communications. However, there is no guarantee that interference will not occur in a particular

est susceptible d'en compromettre lefonctionnement.

- Volume Up/Next Track: Press and hold "+" button to increase
- volume, press once for next track.
 Volume Down/Previous Track: Press and hold "-" button to

- decrease volume, press once for previous track.

 Hands-free Phone Use, Press the power/multifunction button once to answer an incoming call. White on a call, press the power/multifunction button once to end the call.

 Reject a call. Press and hold the power/multifunction button to reject a call.

nstallation. If this equipment does cause harmful interference This device complies with I ndustry Canada licence-exempt RSS to radio or television reception, which can be determined by standard(s). Operation is subject to the foll owing two conditions turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following (1)this device may not cause interference, and (2) this device mus accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

4

- Consult the dealer or an experienced radio/TV technician for

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including Interference that may cause undesired operation.
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

5

6

8

封底

76.2mm

7