


USER'S MANUAL





- Wireless Clone
 - One-click Code Breaking
 - Screen Display
 - Scanning
 - Monitoring
 - VOX
 - TOT
 - Chinese/English Voice Prompt
 - Keyboard Lockout
 - Power Display
 - Busy Channel Lockout
 - High-Low Power Selection
 - Power Saving Mode
 - Low Battery Warning
 - Voice Companding/Scrambling Function
 - Special Signaling
 - 50 CTCSS/208 DCS
- Model: KD-C170L, KD-C172L


Charging the Battery Pack:

1. The battery is not charged in the factory, please charge the battery under the environmental temperature 5—40℃ before using.
2. After purchasing or long-term storage (more than two months), charging the battery for the first time can not reach its saturation capacity, repeat charge/discharge for twice or three times to make battery capacity achieve the best state.
3. Before charging, please power off the transceiver, using the transceiver during charging may affect correct charging.
4. If the battery has been charged fully, please do not charge it again, otherwise the service life of the battery may be shorten or may be damaged.
5. If the service time is significantly reduced even after completely correct charging, the battery can not be used any more, please replace a new battery.

Be Familiar With The Machine:



Icons:



1. LOGO icon: you can input the logo or the number of the user via the software.
2. HEADPHONES icon: after inserting headphones, headphones icon displayed, you can use the headphones to talk.

Basic Operation:

1. Turn the power switch to turn on/off the **transceiver**.
2. Short press **【UP】** key or **【DOWN】** key to adjust the channels.
3. PTT: press this button whenever you wish to talk with the users of the other **transceivers**.

Functions Operation:

- Scanning
It is convenient for the user to search for calls from other channels. When "Side Key 1 or Side Key 2" in the software is programmed to the scanning function, long press **【UP】** **【DOWN】** keys for two seconds to enter into the scanning mode, the transceiver will start to scan with the current channel, operate them again to exit.
- Keyboard Lockout
Long press **【FUNCTION KEY】** to lock all buttons, operate it again to unlock.
- Monitoring
When "Side Key 1 or Side Key 2" in the software is programmed to the monitoring function, long press **【UP】** **【DOWN】** keys for two seconds to enter into the monitoring mode, release them to exit.

- Chinese/English Voice Selection
The transceiver has a manual switching function between the Chinese and the English voice. Press **【FUNCTION KEY】** to enter the menu, select "VOICE" to enter into the language selection, then press the **【FUNCTION KEY】** to confirm.

- One-click Code breaking
Turn the transceiver to Channel 1 and turn it off, then press **【DOWN】** key and turn it on, "Scan Freq..." displayed, the transceiver enter into the code-breaking mode. When any transceiver transmits, if the transceiver receive the signal, the screen will display the deciphered frequencies, that is, the channel has been deciphered, short press **【FUNCTION KEY】** to save to the channel. The transceiver can be used normally after restarting it.

- Wireless Clone
Turn the two transceivers to Channel 2 and turn them off, then press **【DOWN】** key and turn them on, "FSKcopy..." displayed and green light flashes, press the PTT key of the transceiver which need to be cloned to start the data transmission. The transceiver can be used normally after restarting it.

- Time Out Timer (TOT)
The purpose of the TOT is to prevent any single person from using a channel for an extended period of time. An alarm will sound if the transmission continues beyond the set time. The transceiver will stop transmission if this occurs. To stop the alarm, release the PTT key and the transceiver will return to standby.

- Busy Channel Lockout
The function can prevent interference from other transceivers using the same channel. Press **【FUNCTION KEY】** to enter the menu, select "BCL" to enter into the selection of ON/OFF.

- Battery Power Saving
If there is no signal or operation, the transceiver will reduce its power consumption. The battery power-saving function activates when the channel is unoccupied or has not been in operation.

- Low Battery Warning
If the battery power falls to the predetermined value during transmission, the transceiver will give out a voice prompt, please charge in time.

- Scrambling
It is a voice encryption mode which is different from sub audio.

- Companding
It is a function setting which prevents the inter-channel interference.

- CTCSS/DCS
The transceiver has 50 CTCSS and 208 DCS, also non-standard subaudio can be programmed!

- Special Signaling
Special Signaling refers to the CDCSS on the channels which is special processed codes. Only when the transceivers in the same company are programmed to the same frequency point with the same CDCSS and meanwhile special signaling is set, then they can talk to each other.

Technical Parameters:

SPECIFICATIONS	
Frequency Range	462.5500-462.7250MHz 467.5625-467.7125MHz
Supply Power	DC3.7V
Memory Channel	22
Antenna Configuration	Internal Antenna
Work Mode	Co/Differ-frequency Simplex Communication
Ground Method	Cathode
Dimension	148×55×25.5mm
TRANSMITTER	
Output Power (ERP)	(462.5500-462.7250MHz) 30.95dBm (467.5625-467.7125MHz) 25.49dBm
Modulation Mode	FM(F3E)
Max.Frequency Deviation	≤5KHz
Sparious Radiation	≤7.5μW
Preemphasis Character	Per Octave 6dB
Emission Current	≤1200mA
RECEIVER	
Sensitivity	<0.16μV (12dB SINAD)
Audio Power	≥300mW
Audio Distortion	<5%
Intermodulation Interference Resistance	≥60dB
Receiving Current	≤300mA
Standby Current	≤20mA

*We May Change The Specifications For Technical Improvement Without Prior Notice.

FCC Statement:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

SAR tests are conducted using standard operating positions accepted by FCC/ISED with the device transmitting at its highest certified power level in all tested frequency bands, although the SAR is determined at the highest certified power level, the actual SAR level of the device while operating can be well below the maximum value. Before a new model is available for sale to the public, it must be tested and certified to the FCC/ISED that it does not exceed the exposure limit established by the FCC/ISED. Tests for each product are performed in positions and locations as required by the FCC/ISED.

For body worn operation, this device has been tested and meets the FCC/ISED RF exposure guidelines when used with and accessory designated for this product or when used with and accessory that contains no metal.

To maintain compliance with FCC/ISED RF exposure guidelines hold the transmitter and antenna at least 1 inch (2.5 centimeters) from your face and speak in a normal voice, with the antenna pointed up and away from the face.

The equipment complies with FCC/ISED radiation exposure limits set forth for an uncontrolled environment. In order to comply with the FCC/ISED RF exposure requirement, the antenna installation must comply with following:

Users must be fully aware of the hazards of the exposure and able to exercise control over their RF exposure to qualify for the higher exposure limits.

Your wireless hand-held portable transceiver contains a low power transmitter. This product sends out radio frequency (RF) signals when the Push-to-Talk(PTT) button is pressed.

The device is authorized to operate at a duty factor not to exceed 50%.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

ISED RSS Warning:

This device complies with Innovation, Science and Economic Development Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'ISED applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Les tests SAR sont effectués en utilisant des positions de fonctionnement standard acceptées par la FCC/ISED avec l'appareil transmettant à son niveau de puissance certifié le plus élevé dans toutes les bandes de fréquences testées, bien que le SAR soit déterminé au niveau de puissance certifié le plus élevé, le niveau SAR réel de l'appareil tout en fonctionnement peut être bien en deçà de la valeur maximale. Avant qu'un nouveau modèle ne soit disponible à la vente au public, il doit être testé et certifié par la FCC/ISED qu'il ne dépasse pas la limite d'exposition établie par la FCC/ISED. Les tests pour chaque produit sont effectués dans les positions et emplacements requis par la FCC/ISED.

Pour un fonctionnement porté sur le corps, cet appareil a été testé et répond aux directives d'exposition RF FCC/ISED lorsqu'il est utilisé avec un accessoire conçu pour ce produit ou lorsqu'il est utilisé avec un accessoire qui ne contient pas de métal.

Pour maintenir la conformité avec les directives d'exposition RF de la FCC/ISED, tenez l'émetteur et l'antenne à au moins 1 pouce (2,5 centimètres) de votre visage et parlez d'une voix normale, avec l'antenne pointée vers le haut et loin du visage.

Votre émetteur-récepteur portatif sans fil contient un émetteur de faible puissance. Ce produit envoie des signaux de fréquence radio (RF) lorsque le bouton Push-to-Talk (PTT) est enfoncé. L'appareil est autorisé à fonctionner à un facteur de marche ne dépassant pas 50 %.