

Quick Guide:

INSTALLATION GUIDE:

! IMPORTANT: Before operating or maintaining this unit, please read these instructions carefully and pay extra attention to the safety warnings and precautions. Use this unit correctly and with care. Failure to do so may cause damage and/or personal injury and will void the warranty.

Warranty:

AUTEL guarantees that the TR201 is free from material and manufacturing defects for a period of 24 months or for 24,000 miles, whichever comes first. AUTEL will at its discretion replace any merchandise during the warranty period. The warranty shall be void if any of the following occurs:

1. . Improper installation of the product;
2. Improper use;
3. Product damage due to collision, man-made damage or natural disasters;
4. Exceed the product-specific use restrictions.

CAUTION:

1. The Autel TPMS ECU needs to be used with the Autel standard cable. Otherwise, it may cause a short circuit on the vehicle.
2. When using the original TPMS ECU, avoid using the Autel standard

cable. Otherwise, it may cause a short circuit on the vehicle.

3. Before installing the TPMS ECU, please confirm that the installation model is correct. Otherwise, it may cause a short circuit on the vehicle.

Instruction Guide:

Procedures:

1. Program the TR201 TPMS ECU using the TPMS programming tool
2. Code the vehicle and retrofit TPMS function
3. Install the TPMS ECU and sensor
4. Relearn the TPMS system according to the relearning steps

Operations Guide:

1. Take **MX808TS** and **VCI Mini** as an example, connect TR201 and VCI Mini to the corresponding interface of **ECU_DPL_01** programming cable, and supply 12V to the programming cable, then connect MX808TS and VCI Mini via Bluetooth. The specific connection is as follows:
2. Tap the **TPMS** icon in the MX808TS main menu
3. Select the **Model** → **Year** in turn
4. Tap the **Retrofit** button in the navigation bar at the top of the screen to display the installation interface. Tap the **Autel ECU Relearn** button at the bottom of the screen to program the TR201 TPMS ECU.
5. In the installation interface, detailed operation guide is displayed, including the relearn function, TR201 installation position and so forth.

Before starting the operation, please read the operations guide carefully in order to realize the TPMS function easily.

Packing List	Quantity
TR201 TPMS ECU	1
Standard Cable	1
Quick Guide	1

Item	Description
Weight(NW)	53g
Dimensions	95*90*24 mm
Rated Voltage	12V
Rated Current	50mA
Operating Temp.	-40---85℃
Receive Frequency	433.92Mhz & 315Mhz

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.