

# BS-05


## Bluetooth speaker

### SPECIFICATION

Version:	5.3
Power:	6.5W+1
Battery:	1200mAh
Playtime:	3-5 hours
Recharge time:	3hours

### Key Description:

1. Click on the next track, long press to increase volume
2. Click on the light conversion, long press to control the light switch, double-click on Bluetooth to disconnect
3. Click on the mode conversion and long press the couplet function
4. Press and hold the power button, then click pause/play (FM mode: double-click to automatically search for channels, double-click again to stop automatic channel search, Bluetooth mode: click answer/hang up for incoming calls, double-click call back, default first) (press and hold for 8 seconds to reset)
5. Click on the previous track, long press to reduce volume
6. Type-C charging port
7. TF card socket



### CAUTION:

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### CAUTION:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### FCC Statement:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.