Smart Light Bulb

User manual

①

Please download Smart Life APP first

You can scan the QR code, or search “Smart Life” from APP store, Android Market, Google play to download it.

②

Open Smart Life to click “register”



③

Agree to the privacy policy.



④

Input your phone number or email to finish the registration



⑤

After the registration is done, click Log in



⑥

To log in, please input your mobile number/Email as well as the password, or you can also verify via SMS



⑦

Click Add Device after you successfully log in.



⑧

Click All to proceed.



⑨

Choose Lighting Devices



⑩

Then you will be asked to confirm the bulb is flashing rapidly.



How to make the smart bulb flash
rapidly? (EZ mode)

1. Connect the bulb to the power source.
2. Press the switch “on-off-on-off-on” continuously.
3. Then the smart bulb will be flashing quickly.

How to make the smart bulb flash
slowly? (AP mode)

1. Power on device. Power off after 10s then power on again.
2. Turn on-off-on-off-on continuously.
3. When the buld is now flashing rapidly, go to next step.
4. Operate again: On-off-on-off-on. Then the bulb will be flashing slowly.

⑪

Go on with Confirm light blinks rapidly



⑫

Enter the WIFI password at your place.



⑬

It is connecting now.



⑭

After the successful connection, you are able to rename the smart bulb.



How to use voice control of Amazon Echo to control your Smart devices?

Step 1: Open the” Amazon Alexa” APP, click **Skills**



Step 2

Enter smart life



Choose smart life



Click Enable



Enter the account and password of Smart life



→

Enter the account and password of Amazon Alexa



Click Authorize



→

Successfully done



Using Google home to control smart bulb

①

Go to homepage of Google home



②

Choose “Home control”



③

Tap “+”



④

Choose “smart life”



⑤

Enter your smart life account and password.



⑥

Click Authorize



⑦

Click to assigned rooms



⑧

Your device will be listed in the Home control page.



Voice command(Assume the name of the item is bedroom light

1. Alexa, turn on bedroom light.
2. Alexa, turn off bedroom light.
3. Alexa, set bedroom light to 100%
4. Alexa, set bedroom light to red/green/blue/yellow (Only works for RGB bulbs)

Basic parameters

Operating voltage: AC 85-265V
Power: 7W
Beam Angle: 120°
Watt equivalent: 60W
Wireless type: WIFI 2.4GHZ
Wireless standard: IEEE 802.11b/g/n
Lampholder: E27
Bulb size: 108*60mm
Certificates: CE, ROHS, FCC

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and (2) this device must accept any interference received,
including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance
could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device,
pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against
harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and,
if not installed and used in accordance with the instructions,
may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in
a particular installation. If this equipment does cause harmful interference to radio or television reception,
which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the
following measures:

-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different
from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC’s RF Exposure guidelines,
This equipment should be installed and operated with minimum distance between
20cm the radiator your body: Use only the supplied antenna.

FCCID: 2ASTM-TB