# Let's get started.

GL·iNet

GL-XE300 / Puli
4G LTE Wireless Router

SETTING UP

1 Insert Cards & Power On

When powered up, your GL-XE300 router will broadcast Wi-Fi signal with the SSID: *GL-XE300-xxx*.

⚠ *Hot plug for TF card and Nano SIM card are not supported for this router.*

Nano SIM Card (Optional)

TF Card / Micro SD Card (Optional)

After Inserting cards, turn on the router by pressing the power button

2 Connect via Wi-Fi   **Connect via LAN**

Connect to the Wi-Fi called *GL-XE300-xxx*, and input the default Wi-Fi password *goodlife,* which is also printed on the bottom of the router.

| Wi-Fi | ⬤ |
| ✓ GL-XE300-xxx | 🔒 📶 |

Search the SSID and connect to it

| Password | •••••••• |

Default password is *goodlife*

or

Plug the cable connecting to your computer into LAN port

3 Set up Router

Visit *http://192.168.8.1* in your browser to set up your router; start by choosing your preferred language.

http://192.168.8.1

Product name	XE300 user manual	Color PANTONE :
Material No	505-0217	⬛ C10 M0 Y0 K70
Size	80*125mm	🟦 C78 M27 Y15 K0
Print	Double / Color	
Material	157g coated paper	
Remarks	Single Card	
(Last updated): 2020/12/15		

SUPPORT

Power
Battery
WAN
LAN
Wi-Fi
3G/4G

Power port
WAN Ethernet port
LAN Ethernet port

Nano SIM Card (Optional)
MicroSD Card (Optional)

USB2.0 port

Reset button
Power button

Repair / Reset

If you cannot access the web-based setup page or cannot connect to the router, you can press the **Reset** button:

- Press and hold for **3 seconds**, and then release to repair your network.

- Press and hold for **10 seconds**, and then release to reset the router to factory settings. All user data will be cleared.

https://docs.gl-inet.com/en/3/

Technical Supports

- For more detailed and updated instructions, please visit our website **docs.gl-inet.com**

- For further questions, you can get help from the following ways:
  - Email to **support@gl-inet.com**
  - Message us on our Facebook: **facebook.com/gl.inet.wifi/**
  - Post questions in our forum: **forum.gl-inet.com**
  - Ask professionals in other forums e.g. OpenWrt, LEDE or other professional websites

WARRANTY

- We provide **one year limited warranty** for routers and **3-month limited warranty** for accessories. Extra warranty may apply according to the local law in which the product purchase took place.
- Highly recommend using the included **5V/2A** power adapter.
- Any damage to the router caused by not following the instructions will render this warranty null and void.
- Any damage to the router caused by modifying the PCBA, components or case will render this warranty null and void.
- Issues caused by the use of third-party firmware may not get official support from us.
- Any damage to the router caused by inappropriate use, e.g. inappropriate voltage input, high temperature, dropping in the water or on the ground will render this warranty null and void.
- Pictures on the instructions are only for reference. We reserve the right to change or modify these materials without further notice.
- Keep your device within the recommended operating temperature (0°C to 40°C). Recommend storage temperature for your device is between -20°C to +45°C. Please note lower or higher temperatures may cause damage to the device.
- To avoid battery or device failure, do not remove or replace the non-removable battery.
- The device should shut down due to overheating (in the event the battery temperature exceeds 60°C).

FCC ID: 2AFIW-XE300C4 | 2AFIW-XE300C6 | 2AFIW-XE300C4G

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
   (1) This device may not cause harmful interference, and
   (2) This device must accept any interference received, including interference that may cause undesired operation.
2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
3. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
 - Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help important announcement.
Radiation Exposure Statement

D Specific Absorption Rate (SAR) information:

This 4G LTE Wireless Router meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health.

e FCC RF Exposure Information and Statement

The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types: 4G LTE Wireless Router (FCC ID: 2AFIW-XE300C4G) has also been tested against this SAR limit. The highest SAR value reported under this standard during product certification for properly worn on the body is 1.082W/kg. This device was tested for typical body-worn operations with the back of the handset kept 0mm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 0mm separation distance between the user's body and the back of the handset. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.

Body-worn Operation

This device was tested for typical body-worn operations. To comply with RF exposure requirements, a minimum separation distance of 0mm must be maintained between the user's body and the handset, including the antenna. Third-party belt-clips, holsters, and similar accessories used by this device should not contain any metallic components.

Body-worn accessories that do not meet these requirements may not comply with RF exposure requirements and should be avoided. Use only the supplied or an approved antenna.

CE ⬚ RoHS COMPLIANT FC

ver. 20210219