物料名称:	GTX Pro快速指南	成品尺寸:	70x100mm	V2
时　间:	2025.04.17	材　质:	128g哑粉	V3
设　计:		工　艺:	四色，双面印刷，风琴折	V3
料　号:		备　注:		V4

正面

How to Control

● **Function Button**

| Press | ● Wake the screen
● Return to the home screen
● Go to the **Function List**
● Pause / resume the sport |
| Hold | ● Power On/off, Restart. |

● **Touch Screen**

● Swipe to go to different interfaces.
● Press and hold Home screen to change watch face.

GTX Pro
Smart Watch
Quick Start Guide

All pictures in this guide are for illustration purposes only. Actual product may vary due to product firmware and app upgrades.

USING YOUR WATCH

Charging 1

Please fully charge your watch before initial use.

① Insert the USB plug of the charging cable into a USB charger.

② Attach the other end to the charging contacts on the back of the watch.

Select Watch Usage Mode 2

The watch can both be used with APP or without APP.

"Do not bind" mode:
You can use your watch without linking to your phone in this mode and you still can use the basic functions such as heart rate monitor, SpO2 monitor, Sleep monitor, track your daily steps, walking distance, and burned calories. Alarm Clock, timer, and stopwatch functions are also available in this mode.

Steps:
1.After charging, power on the watch by long-pressing the side button.
2.Choose language.
3.Select "Do Not Bind" to use the watch without the app.
4.Set up your profile by prompts in the screen.
5.Once these steps are completed, your watch is ready to use.

Note:
If you want to use with APP later on to enjoy more functions, you may Bind APP by going to "Settings > Bind APP" .

"Bind APP" mode:
To use with **"VeryFit"** app, your watch could have many extra functions, such as message notification, phone calls pickup, weather checking, controlling your phone camera and music, etc. Your daily activities also could be synchronized to the app so that you can check your historical activity data afterward. There are also many fancy watch faces in the app. You can download them to your watch by using the app, which may make you feel that you have a brand new watch again.

After charging, power on the watch by long-pressing the side button. Choose the language then select "Bind APP" to prepare using the watch with app:

1.Install **"VeryFit"** APP into your smartphone first:

You can download **VeryFit** from Apple Store / Google Play or scan the QR codes below to download.

veryfit

Note: The App is only compatible with smartphones, not tablets or PCs.

2: Pair the Watch with Your Phone

① Turn on the Bluetooth of your phone.

② Open the VeryFit App. Go to the **"Device"** page and tap **"Add Device"**.

③ Two pairing methods.

If **"GTX Pro"** appears in the automatic search results, click the model name to pair.

OR

Tap **"Scan QR Code "** and scan the QR code on the watch to pair.

Note:
"**Bluetooth Pairing Request**" will pop up twice on your phone, please click "**Pair**" both times.

④ Tap ✓ on the watch to confirm the connection.

反面

Watch Interfaces 3

Quick Settings

Steps　　Heat rate

Quick Settings

Sleep　　Workout

Notifications

Note:
If your phone is an Android phone, notifications will only be delivered when:
1.Your watch is connected to VeryFit App,
2.The app is running in the background on your phone, and "Notification Alerts" are enabled in the app.

Tips:

Find My Phone:
Your phone and watch are connected via Bluetooth, you can use the watch to locate your phone by making your phone vibrate or ring.
Note: This feature is not available on Android phones if the VeryFit app is not running on your phone.

Do Not Disturb (DND) mode:
• When the DND mode is enabled, the watch won't ring or vibrate when it receives incoming call alerts, SMS, app notifications. And Raise to Wake function will be disabled.
• DND mode does not affect Alarms.

How to Connect the Bluetooth Call function

1. **DND** mode must be disabled before using Bluetooth Calling.
2. On your phone, go to "**Settings**" → "**Bluetooth**" , tap "**GTX Pro BT(Connected for calls)**" to connect.

Notes:
• To use the Bluetooth Calling feature on the watch, please keep the watch connected to your phone via Bluetooth.
• When the **DND** mode is enabled on the watch (Quick settings bar →), the watch will not receive incoming call reminders, but you can use the watch to make calls.
• Ringing or vibration switching can be modified in "**Settings**" → "**Sounds and Vibration**".
• This feature will reduce the watch's battery life.

FAQ:

Q1: How to set up my watch?
A1: There are two ways:
1. In Home screen, swipe the screen down to the quick setting menu, then tap to enable " wake gesture on", or
2. Press the function button, and the screen will pop up function list. Swipe up the screen to the end and you will find which contains a lots of different settings for your watch.

Q2: How can I make the watch screen light up when I raise my wrist?
A2: There are two ways:
1. In Home screen, swipe the screen down to the quick setting menu, then tap to enable " wake gesture on", or
2. Go to "Settings> Display> Raise to wake" to enable the Wrist Awake function. You may also set up your preferred display brightness and screen-on time there.

Q3: My watch's time is not accurate. How to adjust?
A3: Without APP: Go to "Settings> Time " to adjust.
With APP: Just synchronize your watch with your app.

Q4: I want to give this watch to someone else after my usage. How could I erase all the data in this watch?
A4: You could run "Reset" function to restore this watch by going to "Settings > General > Reset".

PACKAGE CONTENTS

Smart watch with bands x 1

Charging cable x 1

Quick start guide x 1

Important Safety Instructions

The device contains electrical equipment that may cause injury if not used properly. For example, prolonged contact may contribute to skin allergies for some users. To reduce irritation, please read the safety guidelines on the following pages to ensure proper use and care.
• Do not expose your device to liquid, moisture, humidity or rain while charging; do not charge your device when it is wet, as this may result in electrical shock and injury.
• Consult your doctor before use if you have any preexisting conditions that might be affected by using this device.
• Do not expose your watch to extremely high or low temperatures.
• Do not leave your watch near open flames such as cooking stoves, candles, or fireplaces.
• This product is NOT a toy - never allow children or pets to play with this product. Always store the product out of the reach of children. The devices themselves or the many small parts they contain may cause choking if ingested.
• Never try to abuse, crush, open, repair or disassemble this device. Doing so will void the warranty and can result in a safety hazard.
• If any parts of your product require replacement for any reason, including normal wear and tear or breakage, please contact us.
• Do not use your device in a sauna or steam room.
• Dispose of this device, the device's battery and its package in accordance with local regulations.
• Do not check any notifications, GPS, or any information on your device's display while driving or in other situations where distractions could cause injury or hazard. Always be aware of your surroundings while exercising.

Battery Warnings
A lithium-ion battery is used in this device. If these guidelines are not followed, batteries may experience a shortened life span or may cause fire, chemical burn, electrolyte leakage, and/or injury.
• Do NOT disassemble, modify, remanufacture, puncture or damage the device or batteries.
• Do NOT remove or attempt to remove the non-user-replaceable battery.
• Do NOT expose the device or batteries to fire, explosion, or other hazards.

Health Warnings
• If you have a pacemaker or other internal electronic device, consult your physician before using a heart rate monitor.
• The optical wrist heart rate monitor emits green light and flashes occasionally. Consult your physician if you have epilepsy or are sensitive to flashing lights.
• Always consult your physician before beginning or modifying any exercise program.
• The device, accessories, heart rate monitor, blood oxygen level measurement and related data are intended to be used only for recreational purposes and not for medical purposes and are not intended to diagnose, monitor, treat, cure, or prevent any disease or condition.

• The heart rate and blood oxygen level readings are for reference only, and no responsibility is accepted for the consequences of any erroneous readings.
• While the optical wrist heart rate monitor technology typically provides the best estimate of a user's heart rate, there are inherent limitations with the technology that may cause some of the heart rate readings to be inaccurate under certain circumstances, including the user's physical characteristics, fit of the device, and type and intensity of activity.
• The smart watch relies on sensors that track your movements and other metrics. The data and information provided by these devices are intended to be a close estimation of your activity and metrics tracked, but may not be completely accurate, including step, sleep, distance, heart rate, blood oxygen, stress and calorie data.

FCC ID: 2A2KS-GTXPRO

NOTE: This equipment has been tested and found to comply with the limits for Class B digital devices, in accordance with section 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
• Reorient or relocate the receiving antenna.
• Increase the separation between the equipment and receiver.
• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
• Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions.
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Important Safety Guide

Some people with allergic skin may react when their skin is exposed to materials used in watches for a long time. This may be caused by allergies, environmental factors, prolonged exposure to irritants such as sweat and soap, or other factors. If you have known skin allergies, please pay special attention when wearing the watch.

Please do not wear your watch too tight.

If your watch gets wet (for example after sweating or showering), clean and dry it thoroughly before putting it back on your wrist.

Make sure your skin is dry before you put your watch back on.

Prolonged rubbing and pressure may irritate the skin, so give your wrist a break by removing the watch regularly.