

QUICK START GUIDE RADAR HUMAN PRESENCE SENSOR





3.Button Description /

Function	Action
Power On/Off	Install the batteries
	Remove the batteries
Reboot	Press and hold reset button for over 3s
Reset to Factory Default	Press and hold reset button for over 10s

4. Power Supply



+

140

01.





5. Configuration /

After the device is powered on, it can be configured via Bluetooth or NFC. 1. Download "Milesight ToolBox" App on an NFC-supported or Bluetooth-supported smartphone.





iOS

Android

Bluetooth Configuration

2. Enable Bluetooth and location function on the smart phone.

3. Open "Milesight ToolBox" App, select Bluetooth method and search for the target device to connect, and then enter the Bluetooth password to read/write the device until App shows a successful prompt. It's suggested to configure a device password for security. (Default password: 123456)



NFC Configuration

2. Enable NFC function on the smart phone.

3. Open "Milesight ToolBox "App, attach the smartphone with NFC area to read/write the device until App shows a successful prompt. It's suggested to configure a device password for security. (Default password: 123456)



6. Installation

Step1:

Location: On a wall at a height of 2.5 to 2.9 meters. Ceiling installation is not supported.







Installation Note:

Step2:

- It is recommended to install the device at a higher position and tilt it downward. Adjust the tilt angle according to the actual situation to ensure the target is within the detection range.
- Do not face the device directly towards smooth surfaces (such as walls, metal, glass, etc.) at close range to avoid reflection interference. Avoid placing multiple devices too close to each other and overlapping

FCC Statement

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and.

(2) This device must accept any interference received, including interference that may

cause undesired operation.

Note:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits aredesigned to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator& your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Milesight / Make Sensing Matter

Milesight IoT Co., Ltd.
⊕ www.milesight.com