


# SIT50 User Guide


## 2015 08 05

### In the box


**CIRCUIT**  
WIRELESS ACTIVITY TRACKER




**User Guide**  
Model : SIT50



Fitness Band




User Guide



Charging Cable


### Location of controls



1 LED Screen  
2 Mode Button  
3 Clasp  
4 Charging Port

### Charging

1. Open the cover of the charging port.  
2. Insert the charging pin.  
3. Plug the USB cable into a computer or a USB power adaptor (not included).



Charging port  
Charging pin


Connect to a computer to charge

When the band is fully charged, you are ready to begin. The device will remain on until the battery is drained.

Band display while charging  
Band display when fully charged

**i** You will see this icon on the band when it is fully charged.  
You can also check the battery status of your band on the settings screen of the "Me by Sharper Image" app.


Battery level indicator (Settings)



settings  
battery level 87%  
band status not paired  
gender male  
birthday 3/31/1989  
height 5'7 IN

### Modes

Press the **mode button** to toggle through the different modes of the band.



12:00 PM 00320 steps  
home screen steps


015.0 distance 0,350 calories  
distance calories

### App installation

Launch the Google Play store or iOS app store (Apple devices) on your smartphone or tablet.


**i** The device is only compatible with:  
• Android devices that run OS 4.3 or later, and that support Bluetooth 4.0.  
• Apple (iPhone 4S and later, iPod Touch (5th gen.), iPad 3 - 4, Mini, and Air.

Search for "Me by Sharper Image" on the app store.  
Select "Me by Sharper Image"



Me by Sharper Image

Install the "Me by Sharper Image" app.




Me by Sharper Image  
INSTALL

### Pairing & connecting to a Bluetooth® device

Before launching the app, make sure your device's Bluetooth feature is enabled, and the band is charged.

When you open the app for the first time, you will be prompted to connect your device to the band.

1. Select "PAIR NOW" as shown below.




PAIR NOW  
CANCEL

2. When the "pairing screen" appears, press the "mode" button of the band.


3. When the band is connected and paired to your device, "connected" is displayed on the bottom of the home screen.

When the band is not connected or paired to device, "disconnected" is shown.




mode button

connected



my goal 51.2 MI 68 CAL  
distance calories burned  
connected  
home screen (connected)




my goal 51.2 MI 68 CAL  
distance calories burned  
disconnected - tap to connect  
home screen (disconnected)

**i** The band will disconnect when separated from your device (over 20 ft).

### Home Screen

After connecting your device, you will be taken to the home screen where your daily activities will be displayed.




Daily goal  
Steps  
Calories burned  
Distance traveled

home screen

### Syncing

Swipe down on the home screen to sync the band to the app and update your activity data.




home screen

**i** About Syncing  
1. Make sure that the band is connected to your device when syncing.  
2. After using the band, be sure to sync it with your device within 48 hours so that you do not lose your data.

### Menu


On the menu screen, you can view activity history, adjust your goal, or access settings.



menu screen


### Goal

Your daily goal is set to 10,000 steps by default. You can change the goal by using the arrows as shown below.




my goal screen

You can only adjust the first two digits.



15000

### Settings



settings screen

**i** Updating the software of your band  
1. To check for updates, tap "band software" in "settings".  
2. If there is an update available, your band will begin updating automatically.

Pair or unpair your band by tapping on band status

### Care & safety tips

Keep the following tips in mind when caring for your "Circuit" band:

- Clean and dry the band regularly, particularly under the band.
- Wear your "Circuit" band loosely enough to allow air circulation.
- Use skin care products sparingly on the areas of the wrist covered by the "Circuit" band.

**Important Safety Instructions**

- Do not expose your "Circuit" band to liquid, moisture, humidity, or rain while charging. Exposure of the "Circuit" band to moisture while charging could result in electric shock.
- Do not temper with or abuse the "Circuit" band. For example, without limitation, do not drop, disassemble, open, crush, excessively bend, or otherwise damage the band.
- Do not use abrasive cleaners to clean your "Circuit" band.
- Do not expose your "Circuit" band to extreme heat or cold.
- Do not expose your "Circuit" band to direct sunlight for extended periods of time.
- Do not leave your "Circuit" band near open flames such as cooking burners, candles, or fireplaces.
- Do not bring your "Circuit" band into contact with any sharp objects. This could cause scratches and damage.
- Do not insert anything into your "Circuit" band unless otherwise specified in the user instructions. This could damage the internal components.
- Do not attempt to repair, modify, or disassemble your "Circuit" band. It does not contain any user-serviceable components.

**Battery & Battery Precautions**

- Do not attempt to replace your "Circuit" band's battery. It is built-in and not changeable.
- Use only the supplied USB cable to charge the "Circuit" band.
- Only charge the battery in accordance with the user instructions supplied with the "Circuit" band.
- Do not over-charge your "Circuit" band while you are charging it.
- Do not attempt to disassemble the "Circuit" band or open the built-in battery.
- Do not charge the "Circuit" band in damp areas, because this could result in electric shock.
- Do not clean the "Circuit" band when it is being charged, always using the charger first before cleaning the "Circuit" band.
- Do not dispose of your "Circuit" band in a fire. The battery could explode causing injury or death.

**WARNING: TO REDUCE THE RISK OF FIRE OR ELECTRICAL SHOCK, DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE.**

**WARNING: RISK OF ELECTRICAL SHOCK. DO NOT OPEN.**

**THE LITHIUM-ION BATTERY WITH APPROVED CHARGING CABLE IS INTENDED TO ALLOW THE USER TO RECHARGE THE BATTERY. LITHIUM-ION BATTERIES CAN BE DANGEROUS IF MISUSED. DISCHARGE THAT MAY BE OF SUPPORT MATERIALS TO CONSTITUTE A RISK OF ELECTRICAL SHOCK TO PERSONS.**

**THE DECLARATION OF THE USER'S RESPONSIBILITY TO ADHERE TO THE INSTRUCTIONS TO USE THE PRODUCT AND TO MAINTAIN IT PROPERLY, ACCORDING TO THE INSTRUCTIONS.**

### Legal information

FCC Part 15B  
This equipment has been tested and found to comply with the requirements for a Class B digital device under Part 15B of the Federal Communications Commission (FCC) rules. These requirements are intended to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/television technician for help.

Do not attempt to repair or modify this equipment.  
Warning: Changes or modifications to this equipment not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.  
This device complies with Part 15B of the FCC Rules. Operation is subject to the following two conditions:  
(1) this device may not cause harmful interference, and  
(2) this device must accept any interference received, including interference that may cause undesired operation.

Disposal: USB cables must be used with this unit to ensure compliance with the Class B FCC limits.

**Battery Disposal & Recycle**  
This device contains a Lithium-ion battery. The battery must be recycled or disposed of properly. Contact your local waste management office for information on battery recycling or disposal. 877-802-822-8877

**RECYCLE**  
DO NOT REUSE

Distributed by Southern Telecom, Inc. Brooklyn, NY 11232  
©2015 Southern Telecom, Inc. All rights reserved. Made in China.

SHARPER IMAGE® name and logo are registered trademarks. Manufactured and marketed by Southern Telecom, Inc. under license to Sharper Image. All rights reserved.

Apple is a registered trademark of Apple Inc., registered in the U.S. and other countries, used with permission.

Google and the Google Play logo are registered trademarks of Google Inc., used with permission.

The Bluetooth® word mark and logos are owned by the Bluetooth SIG, Inc.

### Limited Warranty

This Product (including any accessories included in the original packaging) as supplied and distributed here by an authorized dealer is warranted by Southern Telecom, Inc. to the original consumer purchaser against defects in materials and workmanship ("Warranty") as follows:

Product Type: Fitness band  
Warranty: 90 days

**To obtain warranty service:**

- Call the Customer Support number located below, or go to our website portal to receive an RMA number.
- Provide proof of the date of purchase within the package (dated bill of sale).
- Prepay all shipping costs to the authorized service center and remember to insure your return.
- Include a return shipping address (no P.O. Boxes), a telephone contact number, and the defective unit within the package.
- Describe the defect or reason you are returning the product.

**Customer Support**  
877-768-8481 (Toll Free)  
Monday - Friday 8AM - 10PM (EST)  
Click on "Product Support"

To receive Warranty service, the original consumer purchaser must contact Southern Telecom, Inc. or an authorized service provider for problem determination and service procedures. Proof of purchase in the form of a bill of sale or receipted invoice, evidencing that the Product is within the applicable Warranty period, MUST be presented to Distributor, or an authorized service provider of the Distributor, in order to obtain the requested service.

This Warranty covers manufacturing defects in materials and workmanship encountered in the normal, non-commercial use of the Product, and does not cover consumer instruction, delivery, installation, software issues, set-up, adjustments, cosmetic damage or damage due to acts of nature, accident, misuse or abuse, negligence, intentional use or modification of or by any part of the Product. In addition, this Warranty does not cover images "burnt" into the screen.

This Warranty applies to the original consumer purchaser only and does not extend to resellers or WITH ALL FAULTS, sold as Reconditioned, Refurbished or Re-manufactured, or consumables (e.g., fuses, batteries, bulbs, etc.). The Warranty is voided if the factory-applied serial number has been altered or removed from the Product. This Warranty is valid only in the country where the consumer purchased the product, and only applies to products purchased and serviced in that country.

**NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OTHER THAN THOSE EXPRESSLY DESCRIBED ABOVE, SHALL APPLY. DISTRIBUTOR FURTHER DISCLAIMS ALL WARRANTIES AFTER THE EXPRESS WARRANTY PERIOD EXPIRES ABOVE. NO OTHER EXPRESS WARRANTIES OR GUARANTEES SHALL APPLY. PERSON, FIRM OR ENTITY WITH RESPECT TO THE PRODUCT SHALL BE BINDING ON DISTRIBUTOR. RETURN, REPAIR, REPLACEMENT OR REFUND OF THE ORIGINAL PURCHASE PRICE - AT DISTRIBUTOR'S SOLE DISCRETION - ARE THE EXCLUSIVE REMEDIES OF THE DISTRIBUTOR. IN NO EVENT WILL DISTRIBUTOR, ITS MANUFACTURERS, BE LIABLE FOR ANY INCIDENTAL, DIRECT, INDIRECT, SPECIAL, PUNITIVE OR CONSEQUENTIAL DAMAGES TO OR FOR THE PRODUCT, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS, BUSINESS, SAVINGS, DATA OR RECORDS CAUSED BY THE USE, MISUSE OR INABILITY TO USE THE PRODUCT, EXCEPT AS STATED HEREIN. NO OTHER WARRANTIES SHALL APPLY. NOTWITHSTANDING THE FOREGOING, CONSUMER'S RECOVERY AGAINST DISTRIBUTOR SHALL NOT EXCEED THE PURCHASE PRICE OF THE PRODUCT, SOLD BY DISTRIBUTOR. THIS WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL CONSUMER WHO PURCHASED THE PRODUCT AND IS NOT TRANSFERABLE.**

Some countries, states or provinces do not allow the exclusion or limitation of incidental or consequential damages or allow limitations on warranties, so limitation or exclusions may not apply to you. This warranty gives you specific legal rights, and you may have other rights that vary from state to state or province to province. Contact your authorized dealer to determine if another warranty applies.

# SHARPER IMAGE®