

USER MANUAL

1 Main parameters

Item No.E638-003

Materials: plastic and electronic components

Vehicle battery: 1 pc of 3.7V rechargeable battery


Remote control battery: 2 pcs of 1.5V AA batteries (not included)



2 Installing batteries

1.Remove the battery compartment door at the back of the remote control. Install 2 pcs of 1.5V AA batteries in the correct polarity as indicated into the battery compartment. Reinstall the battery door and fix it with the screw (Fig 2A).

2.Remove the battery compartment door at the back of the vehicle. Install the 3.7V rechargeable battery in the correct polarity as indicated into the battery compartment. Reinstall the battery door and fix it with the screw (Fig 2B).



3 2.4GHz pairing procedure

- 1.Install the batteries into the vehicle and the remote control. Turn on the remote control and the vehicle. The pairing procedure will start automatically. The remote control indicator light will turn off and the vehicle will emit double beep indicating that pairing procedure was successful (Fig 3A).
- 2.The remote control can be paired only with one vehicle at once. Each set has an interference free system.
- 3.If there is no linking signal for 1 minute the remote control will automatically shut down.
- 4.To re-pair the set restart the remote control and the toy.



3 Operations

1. Sounds On/Off

The sounds feature works after the vehicle in idling mode. Short press the "🔊" button to turn on the horn. Long press the "🔊" button to turn off the vehicle sounds.

2. Forward/Backward


Use the driving stick to control forward and backward movement (Fig 3B).

3. Left/Right

Use the steering stick to control left/right movement (Fig 3C).


These functions could be multiple used for simulating operation.

The device has been evaluated to meet g eneral RF exposure requirement. The dev ice can be used in portable exposure co ndition without restriction.



5 Charging the battery

- 1.Please charge the battery before initial use.The vehicle battery charging time is about 3 hours. Do not charge more than 8 hours.
- 2.Connect the battery to the USB charger and then insert the charger into the computer USB interface, mobile phone charger or mobile power supply for charging (Fig 4A).
3. The indicator light of the USB charger will start flashing indicating that the battery is being charged. Disconnect the battery from the charger once the indicator light is end flashing.
- 4.Please use only recommended USB charger.
- 5.Take good care of the charging line and avoid using it with other batteries.
6. Always turn off the set and remove the batteries when the vehicle is not in use and when it is being stored.



6 Notice

1. Do not play this toy on roads or crowded places to avoid danger.
2. Do not play this product in stagnant water, as it may short-circuit the circuit and damage it.
3. The surface of the product should be kept clean. If it is dirty, use a clean and soft cloth to wipe the stains on the surface of the toy.
4. The vehicle speed slows down significantly during operation, and the battery may be insufficient. Please charge in time.
- 5.Non-rechargeable batteries are not to be recharged. The batteries should be charged under adult supervision.
- 6.Batteries are to be inserted with the correct polarity.
- 7.Different types of batteries or new and used batteries are not to be mixed.
- 8.The supply terminals are not to be short-circuited.
- 9.Exhausted batteries are to be removed from the toy.
- 10.Rechargeable batteries are to be removed from the toy before being charged.
- 11.The toy is not to be connected to more than recommended number of power supplies.
- 12.Regularly inspect the battery, cord, plug, enclosure and other parts. Do not use if damaged.

CHOKING HAZARD-small parts, not for children under 3 years.
Specifications, colors and contents may vary from illustration.

Frequency bands: 2405MHZ to 2475MHZ

Maximum radio-frequency power: -8.85dBm(for EU compliance)

FCC Compliance Statements

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.