


LEXIBOOK® Tablet Master Pocket®



Instruction manual



www.mylexibooktablet.com

LEXIBOOK®

MFC144

Welcome!

Congratulations! You just bought the new Lexibook® tablet. We invite you to read this manual to take full advantage of all the features offered by your Lexibook® tablet as well as detailed instructions and safety tips.

One tablet, thousands of possibilities

With the Wi-Fi and touch screen functions, you can use your tablet with ease wherever you want, whenever you want!

Reading digital books, watching videos, sending emails, playing music, browsing the Internet, playing video games, enriching your knowledge... are only some of the numerous opportunities offered by your tablet.

Your tablet can be updated automatically with the integrated OTA feature ("Over The Air", live Wi-Fi update) with only a few clicks and no stress at all.

Learn, play, relax

The tablet is preinstalled with applications ready to use! With your Lexibook® tablet you will access to free digital books, games and videos already installed.

And with the Lexibook® Market application on your tablet, you can download and install thousands of new applications designed for the whole family.

Note: Since the products are updated regularly, the illustrations and content of this manual are for reference only and may be different from the actual product.

Table of Contents

Welcome!	2
Table of Contents	3
Safety Instructions	4
Important Safety Instructions	5
Epilepsy Warning	7
Packaging Contents	7
1. Discovering Your Lexibook® Tablet.....	8
Presentation of Your Lexibook® Tablet	8
Turning Your tablet On and Off	8
How to Reboot the Tablet in the Event of a Problem	9
How to Activate/Deactivate the Wi-Fi on Your Lexibook® Tablet	9
The Settings Menu of Your Lexibook® Tablet	15
Headphones Connection	16
Using a Memory Card	17
Navigation	20
Rotating the Screen	21
Using the Virtual Keyboard	21
Inserting the Micro USB	22
Transferring Files	23
Charging the Battery	25
Using the Battery	26
2. The Home Screen of Your Lexibook® Tablet.....	27
The Taskbar	27
The Applications of Your Lexibook® Tablet	28
3. Applications Preinstalled on Your Lexibook® Tablet	33
Applications Accessible from the Home Screen.....	33
Applications Accessible from the Applications Menu	36
The Lexibook® Protect Internet Browser	38
The Lexibook® Market.....	46
The Lexibook® Market Premium.....	60
The Lexibook® Videostore.....	73
4. Technical Information	74
Tablet Specifications	74
Maintenance and Warranty	74

Safety Instructions



CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK. DO NOT REMOVE COVER (OR BACK). NO USER SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

The graphic symbols on the back cover of the set mean the following:



DANGEROUS VOLTAGE:

The lightning flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of uninsulated “dangerous voltage” within the product’s enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



ATTENTION:

The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

WARNING:

- To reduce the risk of fire or electric shock, do not expose this appliance to rain or moisture.
- The apparatus shall not be exposed to dripping or splashing and that no objects filled with liquids, such as vases, shall be placed on the apparatus.
- The mains plug is used as the disconnect device, the disconnect device shall remain readily operable.
- In order to disconnect the apparatus from the mains completely, the mains plug should be disconnected from the mains socket outlet completely.

IMPORTANT SAFETY INSTRUCTIONS

WARNING: THIS PRODUCT IS NOT A TOY, ADULT SUPERVISION IS REQUIRED.

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Do not use the product on your lap for more than 30 minutes, without a 5-minute break at least.
6. Do not use this unit near water.
7. Clean only with a dry cloth.
8. Do not block any ventilation openings. Install in accordance with manufacturer's instructions.
9. To avoid overheating, do not leave the product in a non-ventilated space (e.g. a schoolbag) when it is turned on.
10. Do not install near any heat sources such as radiators, heat registers, stoves or other apparatus (including amplifiers) that produce heat.
11. Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding-type plug has two blades and a third grounding prong. The wide blade or the third prong is provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
12. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the unit.
13. Only use attachments/accessories specified by the manufacturer.
14. Unplug this unit during lightning storms or when unused for long periods of time.
15. Refer all servicing to qualified service personnel. Servicing is required when the unit has been damaged in any way, such as the following: the power-supply cord or plug has been damaged; liquid has been spilled or objects have fallen into the unit; and/or the unit has been exposed to rain or moisture, does not operate normally, has changed its performance or has been dropped.
16. Do not overload wall outlet. Use only power source as indicated.
17. Use replacement parts as specified by the manufacturer.
18. Upon completion of any service or repairs to this product, ask the service technician to perform safety checks.
19. Keep the device away from metallic objects (coins, keys...). Do not leave it near magnetic fields that could cause data loss or damage the device.
20. Do not drop the device. Do not expose it to mechanical shock, friction or impact. When transporting the device, put it in a protective cover.
21. Protect the device from humidity and rain. If it gets wet, wipe it immediately.
22. Do not touch the power cord when your hand are wet and do not pull on the charger to unplug it.
23. In order to prevent data loss, remember to keep a backup (data or paper) of the information recorded on the device.
24. To prevent interference, do not use the device next to other electronic devices, artificial pacemaker or near medical equipment.

25. Shut off the device in locations that are susceptible to explosions and when travelling by airplane.
26. Do not use the product near inflammable or explosive sources.
27. Keep the device out of direct sunlight and away from other sources of extreme heat or cold.
28. Do not attempt to disassemble the device; it would no longer be covered by the warranty.
29. Do not place sharp objects directly in contact with the surface and do not spray cleaning products directly on the screen.
30. Do not push hard on the screen and do not place objects on top of it. This can cause tears in the screen.
31. The socket-outlet shall be installed near the equipment and must be easily accessible.

Epilepsy Warning

Please read prior to any use of a video game by yourself or by your child.

Some people are susceptible to epileptic seizures or loss of consciousness when exposed to certain kinds of flashing lights or elements common in our everyday environment. These individuals may suffer a seizure when they watch certain televised images or when they play certain video games. These phenomena can occur even if the person has no previous medical history or has never suffered an epileptic seizure. If you or a family member has ever displayed symptoms related to epilepsy (seizure or loss of consciousness) in the presence of stimulation in the form of light, please consult your physician before using. We advise parents to be attentive to their children while they play video games. If you or your child experience the following symptoms: dizziness, altered vision, eye or muscle twitches, loss of consciousness, disorientation, involuntary movements or convulsions, immediately stop playing and consult a physician.

General Precautions When Using Video Games

- Do not stand too close to the screen. Play at a safe distance from the television screen and as far as the connecting cord allows.
- It is preferable to play video games on a small screen. Avoid playing when tired or when needing sleep.
- Make sure to play in a well lit room.
- When in use, take breaks of 10 to 15 minutes every hour.

WARNING: Prolonged use of the tablet may be harmful to the health of the user.

Packaging Contents

When unpacking, ensure that the following elements are included:


- 1 x Lexibook® Tablet Master Pocket®
- 1 x USB cable
- 1 x Instruction manual

WARNING: All packaging materials, such as tape, plastic sheets, wire ties and tags are not part of this product and should be discarded for your child's safety.

Note: To fully protect and care for your tablet, you can use accessories like screen protectors, for example. Please consult the following link to find out more about Lexibook® accessories: <http://www.lexibook.us/Accessories/vmchk>

1. Discovering Your Lexibook® Tablet

Presentation of Your Lexibook® Tablet



1. Touch screen
2. On/Off button
3. Menu button
4. Return button
5. Volume + button
6. Volume - button

7. Front camera
8. Headphone connector (3.5mm jack)
9. Micro USB port
10. Micro SD card slot
11. Speakers
12. Back camera

Turning Your Tablet On and Off

1. To turn your Lexibook® tablet on, press the “On/Off” button (2) for 3 seconds. The button is located on top of the unit.
2. Please wait while the Android™ operating system is loading.
3. After a few seconds, the welcome screen appears.
4. To turn your Lexibook® tablet off, close all running applications and press the “On/Off” button (2) for 3 seconds.
5. Press “**Power off**”, then select “**OK**”.

Notes: The tablet automatically locks after a few minutes of inactivity. To unlock, press the “On/Off” button briefly. A closed padlock inside a circle appears on the screen. Drag it to the right towards the unlocked padlock to access the Home screen. You can briefly press the “On/Off” button to put your tablet in standby mode.


How to Reboot the Tablet in the Event of a Problem

If you wish to reboot your tablet, press the “On/Off” button (2) for 5 seconds. The tablet turns off and then reboots automatically.


How to Activate/Deactivate the Wi-Fi on Your Lexibook® Tablet

- **Activate the Wi-Fi function**


1. On the home screen, press the clock located at the top right corner.




2. Slide your finger towards the bottom and then select “Wi-Fi”.



3. Touch the Wi-Fi “**OFF**” switch and slide it to the right.



4. Please wait while the Wi-Fi turns on. This operation may require 5-10 seconds.




5. The list of available Wi-Fi networks appears on the right side of the screen. Touch the Wi-Fi network that you want to connect to. The name of the network depends on your Wi-Fi modem or router. If unsure, please check the relevant instruction manuals or contact your network provider.


Notes: The network list updates automatically every few seconds.

The wave symbol  on the right side of each network indicates the Wi-Fi signal strength (more white bars indicate a stronger signal).


The small padlock symbol  on the right side of each network indicates that the Wi-Fi network is password-protected.




6. Click on the password box.




7. Enter the password of the Wi-Fi network. The password depends on your Wi-Fi modem or router. If unsure, please check the relevant instruction manuals or contact your network provider.



8. Click on the “**Done**” button and then the “**Connect**” button to connect to the Wi-Fi network. This operation may require 5-20 seconds. If you cannot connect, please make sure that the password is correct and that you are inside the range of the Wi-Fi network.




9. Once connected, the “**Connected**” message is displayed under the Wi-Fi network.




- **Deactivate the Wi-Fi function**


1. On the home screen, press the clock located at the top right corner.



2. Slide your finger towards the bottom and then select “**Wi-Fi**”.



3. Touch the Wi-Fi “**On**” switch and slide it to the left. The password is saved.



The Settings Menu of Your Lexibook® Tablet

• Go to the “Settings” menu

There are two ways to access the settings menu of your tablet:

1. On the Home screen, press the  button at the top right of the screen.

Then click on the  button to access the Settings menu.

2. On the Home screen, click on the  button to access the applications menu, then click on the Settings icon .

The list of the different alterable settings appears on the screen. Select the setting of your choice to modify it.

• The main settings of your tablet

WIRELESS & NETWORKS	
Wi-Fi	To connect to a Wi-Fi network (wireless).
Data usage	To check and modify the data usage of the tablet.
More...	To activate and deactivate the airplane mode, as well as to modify other network settings.
DEVICE	
Sound	To adjust the volume and the different notification sounds.
Display	To adjust the brightness, set the desktop wallpaper and the display options.
Screenshot settings	To access the screenshot settings (take pictures of your tablet's screen with a single click).
Storage	To access the settings of the micro SD card and the memory information of the tablet.
Battery	To check the battery information (charge, consumption...)
Apps	To manage the different applications of the tablet and to deactivate or uninstall them.
PERSONAL	
Location	To set the geographic location options of the tablet.

Security	To set the security options of the tablet (passwords...) Warning: Be careful to remember/write down your passwords to avoid blocking your tablet in case you forget them.
Language & input	To set the regional options including the language of the tablet and the keyboard.
Backup & reset	To back up the data of the tablet and restore all the settings to factory default. Warning: Any reset leads to the loss of data saved on the tablet, of all personalized settings and of all applications that you have installed.
ACCOUNTS	
Add account	To create and manage email accounts on your tablet.
SYSTEM	
Date & time	To set up the date and time on your tablet.
Accessibility	To configure the accessibility tools aimed at people with special needs.
Printing	To pair up a printer with your tablet.
About tablet	To view information about the tablet.

Headphones Connection

A headphone connector (8), suitable for any headphones or earphones fitted with a 3.5mm jack plug, is located on the left side of this device. When the headphones are in use, the speakers turn off automatically.


CAUTION: Too high volume, especially when using headphones, can damage your hearing. For this reason, please turn the volume down before connecting headphones.

Using a Memory Card

In order to store additional files or to have more storage space on your tablet, you can buy a micro SD/TransFlash card (sold separately), and then insert it in the tablet. You may also delete the included files in your tablet such as videos, songs and electronic books. **Warning:** once the files included with your tablet are erased, you cannot recover them. Please make a backup copy before erasing them.

• Memory card compatibility

The device is compatible with micro SD/TransFlash (TF) memory card with capacity up to 32GB.




• Insert a memory card

1. Insert a micro SD/TransFlash (TF) memory card in the micro SD card slot (10) on the left side of your tablet. **Make sure the metal connectors of the card are facing down when the front of the tablet is facing you.**
2. Gently push the card into the card reader until it “clicks”.


- **Remove the memory card**

Note: BEFORE removing the memory card, you should always disable it.

1. From the Settings menu, select "Storage" and then click on "**Unmount SD card**".



2. Press "OK" to confirm and wait for the card to be unmounted.




3. You can now remove the memory card. Press the card slightly until you hear a "click" sound and the card is unlocked. Slowly take the card out from the slot.


Notes: Never remove the memory card without first disabling it. Never remove the memory card while the tablet is reading from or writing to the card. This may result in data loss and/or damage to the memory card.

- **Format the memory card**

1. From the Settings menu, select "**Storage**" and then click on "**Erase SD card**".



2. Confirm by clicking on "**Erase SD card**" and then "**Erase everything**".



Warning: "Erase SD card" will **permanently** erase all the content of the SD card.

Navigation

The touch screen makes navigation fast and fluid. Move your finger or a stylus for capacitive screens (not included) on the surface of the touch screen to select different menus or applications and navigate through your Lexibook® tablet.

- To select a menu or launch an application, press the touch screen once with your finger or a stylus for capacitive screens (not included).
- To move an item, keep your finger or a stylus for capacitive screens (not included) pressed on the item and drag it to the desired location.

• Navigation with the Explorer

You can use the Explorer application to navigate through your files. You may access the selected file directly. You may also scroll through your image files and browse your photos by using the “Gallery” application available on the application menu.

• Navigation with the Gallery

You can use the Gallery application to browse your pictures. Images imported to your Lexibook® tablet via USB or micro SD card are automatically added to the Gallery.

• Precautions when using the touch screen

We strongly suggest that you take the following precautions when using the touch screen:

- Ensure that the touch screen is not brought into contact with dirt, liquids or grease.
- Do not touch the touch screen with dirty hands or sharp objects/edges.
- Do not place heavy objects on the touch screen.
- In case the touch screen does not respond anymore, reboot or reset the tablet and recalibrate the touch screen.
- Do not let the tablet fall.

Note: For a better protection of the touch screen, the device comes with a protective film preinstalled on the screen; this protective film must be removed at the first use.

Rotating the Screen

The tablet is equipped with a motion sensor that will automatically switch the display to portrait mode (vertical) or to landscape mode (horizontal).

To change the display orientation, simply rotate your tablet. The size and direction of the current display will be automatically adjusted.

Warning: some applications do not provide this feature.


Notes: To allow the automatic rotation of the screen display, you must enable the “Auto-rotate screen” setting in the menu “Settings/Display”. This setting is enabled by default.

Using the Virtual Keyboard

Your tablet is equipped with a virtual keyboard that allows you to type a text, an e-mail or to do an Internet search.

• Display the keyboard

1. To make the keyboard appear on the screen, click on any text input field.
Note: The "text input field" is where you want to type your text, such as a search bar or a form.
2. The virtual keyboard is displayed on the lower part of the screen.



3. Type your text using the virtual keyboard.
4. Press the  key on the keyboard to complete and start the search.

5. Press the HIDE KEYBOARD key  or anywhere outside the keyboard area to hide the keyboard.

Note: You may also connect an external Lexibook® keyboard to your Lexibook® tablet. The keys may vary depending on the application used.

- **Typing numbers**

To type numbers, press the NUMBERS key  to display the keypad on the keyboard.

Inserting the Micro USB

WARNING: Before connecting the cable's micro USB side to your tablet, please ask your parents' or an adult's help. Do not install the cable on your own. Do not force entry as you might damage the fragile micro USB plug.

Insert the micro USB plug into the micro USB port of the tablet. Make sure the pins (longer side) are facing up just as illustrated below.




Notes to the parents:


Please make sure the plug is plugged in on the correct side to avoid breaking the end of the micro USB cable or the micro USB port of the tablet.

Transferring Files


1. Connect the Lexibook® tablet to a computer using the USB cable (included). Press the connection icon located in the top left corner.




2. Slide your finger towards the bottom and then select “**USB connected**”.



3. Select **“Turn on USB storage”** in order to activate the USB connection. This allows files to be transferred from the computer to the Lexibook® tablet and vice versa.



4. Once the file has been copied to the Lexibook® tablet's internal memory, you must deactivate the USB connection. To do this, click on the icon at the top left of the screen and slide your finger towards the bottom. Select **“Turn off USB storage”**, and then confirm by selecting **“Turn off the USB storage”**.



Charging the Battery

IMPORTANT: The battery must be charged for at least 8 to 12 hours before the first use.

Your tablet is equipped with an internal rechargeable battery. You can recharge the battery using the USB cable (included).

• Charging via USB cable

1. Plug the micro USB connector of USB cable (included) into the micro USB port (9) of the tablet located on the left side of the unit.
2. Then connect the other end of the USB cable to a USB port on your computer.
3. The charging icon of the battery when:

a) The tablet is turned off



appears on the screen for 3 to 4 seconds. The screen turns off afterwards. The icon reappears when you press the on/off button briefly. Long press the on/off button to turn the tablet on.

b) The tablet is turned on

appears in the taskbar  and indicates the charging progression.

4. When the battery is fully charged, you can unplug the cable from the tablet.

Note: The battery will only recharge while the tablet is in standby mode or turned off.

Using the Battery

Notes :

- Always wait at least 5 seconds after having turned off the device before restarting it. Shutting off and immediately turning on the device can damage the electrical circuits.

The battery life may vary based on usage patterns of the device.

The lithium battery is intended for use only with this tablet. Do not disassemble the battery. Do not dispose of the battery in fire or water. To avoid risk of fire, burns or damage to your battery, do not allow a metal object to touch the battery contacts. Handle a damaged or leaking battery with extreme care. If you come in contact with the electrolyte, wash the exposed area with soap and water. If it contacts the eye, flush the eye with water for 15 minutes and seek medical attention. Do not charge the lithium battery pack if the ambient temperature exceeds 45°C (113°F). When discarding a battery pack, contact your local waste disposal provider regarding local restrictions on the disposal or recycling of batteries.

WARNING: Malfunction or loss of memory may be caused by strong frequency interference or electrostatic discharge. Should any abnormal function occur, reset the unit and plug it in again.

2. The Home Screen of your Lexibook® Tablet

The Taskbar

The taskbar is located at the bottom of the screen. It includes the following:




- **Touch screen keys:** These keys provide direct access to specific menus or functions of the tablet.
- **Touch screen keys of the Home screen**
 - **"Back"** button  to return to the previous screen.
 - **"Home"** button  to exit the current application and return to the Home screen.
 - **"Recent Apps"** button  for quick access to recently used applications. Slide your finger or a stylus for capacity screens (not included) to the left or the right to scroll through a list of recently used applications. To remove an application from the list, slide the application to the top or bottom. You may also long press the application and select **"Remove from list"**.
 - **"Screenshot"** button  to take photos of the tablet screen. To display the icon on the taskbar, access the **"Settings"** menu, then **"Screenshot settings"** and select the third option. The  icon is now displayed.

The Applications of your Lexibook® Tablet

• Applications accessible from the Home screen

When you turn on your Lexibook® tablet, you will find several icons located on the Home screen for easy access!



You may choose any application by clicking on its icon. For more information about the applications, please refer to the section “Applications preinstalled on your Lexibook® tablet”.

• Running applications from the home screen

1. On the home screen, click on the icon  to access the applications menu.
2. Select an application by clicking on its icon.
3. Click on the home button  to return to the Home screen. Click on the Back button  to return to the previous screen.

Note: You can also add a shortcut to your favourite applications directly on the home screen.

• Adding screen pages

By default, the tablet only has one page: the home screen. To create a new page, press and hold your finger on one icon and slide it towards the right end of the tablet until a blank page appears.

- **Moving icons on the home screen**


To organize applications, keep your finger pressed on the corresponding icon and drag it inside the page or on another page of the home screen.

- **Add or remove icons to/from Home screen**

1. Access the applications menu by clicking on the Applications button .
2. Select the application you want to move to the Home screen by holding your finger on the corresponding icon. A shortcut is automatically created on the home screen.
3. You can then move the icon at the location of your choice, on one of the pages of the home screen.
4. To delete an icon, keep your finger pressed on the icon and then drag it on top of the cross button (X) that appears on the left of the screen. You can also “throw” the icon towards the top of the screen to remove it from the home screen.

- **Access to shortcuts**


Keep your finger pressed on the home screen to access: screen pages, wallpapers, widgets and settings.




Wallpapers

1. Select the “**Wallpapers**” option. Slide your finger to the right of the list located at the bottom of the screen to display other wallpapers.


Notes: the live wallpapers are located at the end of the list and have a name.



2. You can also choose a wallpaper from the Gallery. Press “**Pick image**”, then and “**Gallery**”.




3. Choose an image from the folder(s).




Widgets

1. Select **"Widgets"** to create a widget on the screen page.
2. Long press one of the widgets.



3. Keep your finger pressed on the widget icon and place it on a screen page.



Settings

Select **"Settings"** to quickly access the settings menu of the tablet.

• To create a folder on the home screen

1. Select an icon of your choice. Hold your finger on it and slide it on top of another icon. A black circle will appear behind the bottom icon. The folder has now been created.
2. To add more applications in the same folder, hold your finger on an icon, then slide it towards the folder.
3. Click on the newly created folder.
4. Click on **"Unnamed folder"**. Use the virtual keyboard to type in the name you wish to give your folder and press on **"Done"**.
5. You can also rename your folders by clicking on the folder you would like to edit. Click on its name and use the  key on the keyboard to erase letters and type in the new name of your folder.
6. To take out an application out of a folder, hold your finger on the desired icon. Slide it out of the folder to put it on the home screen.

3. Applications Preinstalled on Your Lexibook® Tablet

Note: Lexibook® cannot guarantee the content or services accessible through the Lexibook® tablet. In addition, Lexibook® cannot be held responsible for any data loss, damage or alteration of the unit linked to downloading or updating applications or software on the tablet. Moreover, it cannot be held liable for any expense, cost or financial loss caused by purchases made on the Internet using this tablet.

Note: Most of the applications listed below require an Internet connection. Before you launch an application, check that your tablet is connected to a wireless Internet network (see "Activate the Wi-Fi on your Lexibook® tablet").

Applications Accessible from the Home Screen



LXB Markets

Click on this folder to access the following applications:



Lexibook® Market

Click on this icon to launch the Lexibook® Market application. With this downloading platform, you will easily find and install thousands of applications on your Lexibook® tablet. Including educational games, puzzles, action games, photo apps – each application is carefully selected by Lexibook®. The Lexibook® Market is a secure platform, suitable for the whole family! For more information, please refer to the section "The Lexibook® Market".



Lexibook® Market Premium

Click on this icon to launch the Lexibook® Market Premium application.

Note: To obtain the latest version of Lexibook Market®, please follow the link: <http://www.mylexibooktablet.com/fr/applications-pour-tablettes/applis-lexibook>. This link is also accessible from the tablet home screen, just press the "LXB Update" icon.

	LXB Apps Click on the folder to access the following applications:  My Translator Press this icon to launch the Lexibook® My Translator application and access a 15-language translator with a database of 10,000 words!  My Hobbies Click on this icon to launch the Lexibook® My Hobbies application and access 52 interactive activities that you can play with your friends, family or even on your own!  Lexibook® Protect Click on this icon to launch the Lexibook® Protect application and safely surf the Internet. This browser includes a built-in parental filter that blocks up to nine categories of websites. For more information, please refer to the section "The Lexibook® Protect Internet browser".  Lexibook® Videostore Click on this icon to launch the Lexibook® Videostore application and access your favourite cartoons. You can watch cartoons online or download them onto a micro SD card (not included). For more information, please refer to the section "The Lexibook® Videostore". <i>Note: In order to save space on the internal memory of your tablet, we strongly recommend that you install a micro SD card (not included) into your tablet before downloading a cartoon.</i>
	Student Agenda Click on this icon to access the agenda.
	hubiC This application allows you to stock your data (up to 25GB) in an entirely secured space. You get to decide how, and with whom to share your files.

	Photo and video Click on the folder to access the following applications:  Aviary Click on this icon to launch the photo editing application of your Lexibook® tablet. Edit your pictures, change colours and add funny effects with this simple yet powerful editor!  Magisto Click on this icon to open the video editor. Just shoot and upload your videos and photos and Magisto turns them into beautifully edited movies, complete with music and effects, in minutes. And it's all done automatically, in a click!  Face Changer Click on this icon to edit your pictures using the “Face Changer” application.
---	--

	Note: Once you add music files, image files and video files to your Lexibook® tablet, they will be automatically available in the corresponding application.
	Camera Click this icon to open the Camera application of the tablet and take pictures and videos with the integrated camera.
	Daily Horoscope Click on this icon to check out your horoscope.
	Toon Goggles™ Click on this icon to access the “Toon Goggles™” platform of cartoons and games.
	My Games 1 and My Games 2 Click on the “My Games 1” and “My Games 2” folders to access the 28 games already pre-installed on your tablet.
	Help Click on this icon to access the full version of the manual of your Lexibook® tablet.

Applications Accessible from the Applications Menu

	E-Book Click on this icon to launch the E-Book application. This application allows you to access your personal library of digital books. 50 electronic books are already stored on your tablet and ready to read! A reading guide also allows you to learn more about the authors.  EXCLUSIVE! 10 fun educational eBooks from Twin Sisters Productions are also included! Note: E-Books were created with the software Calibre under the "GNU General Public License v3.0" license. The source code is available on: http://code.google.com/p/calibre-ebook/downloads/list.
---	---


	Calculator Click on this icon to launch the Calculator application. This calculator allows you to perform simple and advanced mathematical operations.
	E-mail Click on this icon to launch the E-mail application and access your personal e-mails. This application is compatible with most existing e-mail providers.
	Clock Click on this icon to access the Clock application of your tablet. This is where you can set sound alarms and view the current time in full screen.
	Sound Recorder Click on this icon to launch the application "Recorder" and record audio messages. Press  to start recording, then  to stop and then  to listen. The file is automatically saved in the main folder inside the internal memory. Note: The microphone is located near the bottom right of the front of the tablet.
	Settings Click on this icon to access the Settings of your tablet. Note: For more information, please refer to "The Settings menu of your Lexibook® tablet".
	LXB Update Click on this icon to download the latest version of the Lexibook® Market and get the latest updates for your Lexibook® tablet.
	Tablet Update Click on this icon to check if any update is available for your tablet. Download and installation is as easy as it gets.
	World Weather Clock Widget This powerful widget displays weather information and forecasts from all over the world. It also includes a detailed map of the world. Note: To add a new widget, long press the home screen and then select the "Widget" tab. Select the widget in one of the available sizes. Hold your finger on the widget and place it on a screen page. Choose your information (city, display options...). Once the widget is on the home screen, click on it to view the weekly weather forecasts and the world map.

The Lexibook® Protect Internet Browser


The Lexibook® Protect browser is an Internet browser which helps block up to nine categories of websites and whose filters are regularly updated. Moreover, the Lexibook® Protect browser includes a feature that helps block all websites with the exception of those that have been manually approved. Please follow this guide to setup the browser.

Please note that Lexibook® highly recommends parental guidance while using Internet. Since Internet is an ever-growing database of several billions of websites, some inappropriate websites and contents might not be filtered correctly. The Lexibook® Protect browser does not replace the guidance and assistance of an adult while using Internet.


1. When first using the Lexibook® Protect browser, a window opens automatically. Please create and confirm the master password that will allow access to browser settings, and then select "OK".




2. The settings screen is displayed. Check the desired options and then select **“Back”** to return to the browser. For more information on the browser settings, follow steps 9 to 11.




3. The browser settings are also accessible via the browser's address bar. Select the **“Settings”** button in the upper right-hand part of the screen.




4. Enter the master password created at step 1 and then select “OK”.




5. The settings screen is displayed. Check the desired options and then select “Back” to return to the browser. For more information on the browser settings, follow steps 9 to 11.




6. Once the master password has been created (step 1), it is also possible to access settings from the options bar. Select “**Options**” at the bottom of the screen and then “**Admin. mode**”.




7. Enter the master password and then select “**OK**”.




8. The “**Settings**”, “**More options**” and “**Exit admin. mode**” buttons are displayed on the screen. The “**Exit admin. mode**” button enables you to return to the browser.




9. In the “**Settings**” menu, the “**Block Everything**” option enables you to block all websites with the exception of those that have been manually added to the whitelist (list of allowed websites). When this option is activated, the “**Categories**” section and the “**Blacklist**” option are not available. To add websites to the whitelist, please follow step 14.




10. Still in the “**Settings**” menu, the “**Categories**” section enables you to block up to nine website categories. Check the desired categories.




11. Still in the “**Settings**” menu, the “**Blacklist and whitelist**” section enables you to remove websites from the blacklist or from the whitelist added previously. To add websites to the blacklist or to the whitelist, please follow steps 13 and 14. The “**Other**” section enables you to modify the browser home page, to modify the master password and to activate or disable the Google SafeSearch filter. For even more effective filtering, it is recommended not to disable the Google SafeSearch filter.




12. The “**More options**” menu enables you to add websites to the blacklist or to the whitelist and to erase the browser history. To add websites to the blacklist or to the whitelist, please follow steps 13 and 14.




13. To add a website to the blacklist, go to the website in question (for example, “www.google.co.uk”) and select “**Blacklist**” in the “**More options**” menu (step 12). The website is immediately blocked. To remove the website from the blacklist, select it in “**Blacklist**” option of the “**Settings**” menu (step 11).




14. To add a website to the whitelist, it must first be in the blacklist. Go to the website in question (for example, "www.google.co.uk") and select "**Whitelist**" in the "**More options**" menu. The website is immediately unblocked. To remove the website from the whitelist, select it in the "**Whitelist**" option of the "**Settings**" menu (step 11).



15. To add a website to the bookmarks, click the grey star in the upper right-hand part of the screen, in the browser address bar. The star lights up (★ → ★) and the website is automatically added to the "**Bookmarks**" menu. To remove a website from the bookmarks, click the star again.



16. In the “**Bookmarks**” menu, a short click on a bookmark enables you to open it. A long click on a bookmark gives you access to a sub-menu that enables you to open it and to change its name and web address, as well as to erase it.



The Lexibook® Market

With the “Lexibook® Market” you can quickly and easily find and install thousands of applications on your Lexibook® tablet.

On the Lexibook® Market you'll find:

- Thousands of applications selected by Lexibook® to suit the whole family.
- Applications (paid and free) downloadable in a few seconds.
- Regular updates
- Famous applications (Skype® ...) and educational applications (games, puzzles, coloring ...)


Important:

Ask for help and permission from your parents BEFORE you purchase and download paid applications on your tablet.


Lexibook® cannot be held liable for any expense, cost or financial loss, in any form whatsoever, caused by a purchase on the Internet using this tablet.

- **Create an account on the Lexibook® Market**


1. On the Home screen, click on the Lexibook® Market icon to launch the application.
2. Click on the “**Options**” button at the bottom of the screen.





Then, click on the “**Account statement**” that pops up.



3. Select **“I would like to register”**.



4. Two windows, “Terms and Conditions” and “Privacy Policy” will then appear on the screen one after the other. Click on **“Accept”** each time.



5. Complete the registration form by entering your email address, a password and your name and validate by clicking "**Submit**".

Account Statement

Register

E-mail address (not visible for others)

lxbttest@gmail.com

Password (free choice)

.....

Password confirmation

.....


First and last name (will be displayed on your entries and comments)

lxbttest


Submit Cancel

- **Connect to the Lexibook® Market**

1. On the Home screen, click on the icon Lexibook® Market to launch the application.
2. Click on the "**Options**" button at the bottom of the screen, then on "**Account statement**".



3. Enter your email address and your password, then press **“Save”**. You can also select the option “Remember login details” if you do not wish to enter your information whenever you connect to the Lexibook® Market.



• Search for applications on the Lexibook® Market

Three categories of applications are available:


- Applications for your device
- Games for your device
- Additional Apps

Click on "Categories" to bring up the menu and discover the subcategories.




You can also look for applications on the Lexibook® Market using the search engine:

1. Click on the “**Search**” button of the tool bar.




2. Click on the input field of the search box to display the virtual keyboard. Type in the keyword(s) for your search, and then press “**Search**” to confirm and start the search.




- **Install an application on the tablet**


1. Inside the Lexibook® Market, click on the application you want to download.
2. Please be patient while your application loads.




3. Click on **“Install”** to begin the installation.



4. Select **"Open"** to immediately use the application.




5. The application is then available in the applications menu.




• Purchase an application


1. First, you need to connect to your account. Please follow the steps described in the “Connect to the Lexibook® Market” section above.
2. On the page of the application you want to purchase, click on “**Buy**” after checking the price of the application.




3. Click on “**Yes**” to enter your payment information.



4. Select your payment method and click on “**Continue**”.



5. If you choose to pay through PayPal, select “Mobile browser on this device” and click on “**Continue**”.



6. Select your country, enter your information and click on **“Continue”** to proceed.

PayPal

https://www.paypal.com/cgi-bin/webscr?cmd=_xclick&business=paypal%40androidpit.de&custom=live-:

Pay with a card

United Kingdom

Card number

Card type: Visa/Delta/Electron

Expiry: 01/2013

Security code:

Email address

Continue

Have a PayPal account?
[Log in to PayPal](#)

17:46

7. If you have a PayPal account, click on the **“Log in to PayPal”** option at the bottom and log in to your account with email or phone.

Mobile Express Checkout - PayPal

https://www.paypal.com/uk/cgi-bin/wapapp?cmd=_flow&CONTEXT=X3%2d7SZn2ExXucINxlliZ%5f05NdFs

Fonpit AG

My total: €5.00 EUR

Login

Log in with email and password:

Email

Password

Log In

Don't have a PayPal account?
[Pay with a card](#)


[Problem with login?](#)

17:47

• Find purchased applications

If you have uninstalled a previously purchased application, you can reinstall it without having to purchase it a second time.

1. Connect to the Lexibook® Market by identifying yourself (see “Connect to the Lexibook® Market”).
2. On the search screen (see “Find purchased applications”), type the name of the previously downloaded application.
3. If you have previously purchased the application, the word “**Purchased**” will appear on the top right corner of the screen.




4. To reinstall the application, click on “**Install**”. You will not be asked to make any payment.


• Changing the Lexibook® Market language

By default, the Lexibook® Market is displayed in the language of your tablet. Should this not be the case, or should you wish to display the Lexibook® Market in a different language, please follow the steps below.


1. From the Home screen of the Lexibook® Market, press the “**Options**” touch button, and then press the “**Settings**” button that pops up, represented by a monkey wrench.




2. In the menu that shows up, press the arrow (facing down) from the “**Content language**” option.



3. In the drop-down list that shows up, select the language required. To do so, slide a finger toward the bottom or the top of the screen.



4. Press the “**Save**” button in the bottom-left corner. The Lexibook® Market is now displayed in the language required. To display the Lexibook® Market in a different language, repeat step 1 to 4 and select the required language at step 3.



Notes:

Lexibook® are continually improving their products. To obtain the latest version of the Lexibook® Market and download the latest updates, please visit the following link: <http://www.mylexibooktablet.com/fr/applications-pour-tablettes/applis-lexibook>.


This link is also accessible directly from the "LXB Update" shortcut, located on the Home screen of your tablet. Help us improve the Lexibook® Market! Feel free to contact Lexibook Customer Service if you notice inappropriate applications.

The Lexibook® Market Premium


Embark on a whole new journey with the Lexibook® Market Premium for Android™ applications. A selection of current best games and apps!

- **Create an account on the Lexibook® Market Premium**


1. On the Home screen, click on the Lexibook® Market Premium icon to launch the application.
2. A terms and conditions window will appear on the screen. Read the terms and click on "OK" when you are done.



3. Click on the “**Register**” button.



4. Enter your email address and click on “**Quick registration**” or “**Normal registration**”.




- **Connect to the Lexibook® Market Premium**

1. On the Home screen, click on the Lexibook® Market Premium icon to launch the application.
2. Enter your username and password. The option “**Save username and password**” is selected by default. If you wish to login every time you access the Lexibook® Market Premium, simply deselect this option.




- **Search for applications on the Lexibook® Market Premium**

1. Slide your finger to the right to access the “Categories” page or simply click on this icon . Click on one of the categories to display different sub-categories.




You can also look for applications on the Lexibook® Market Premium using the search engine:


2. Click on the “**Search**” button at the top.



3. Type in the keyword(s) for your search and then press the “**Go**” key of the keyboard.




4. Depending on the tablet model, you may also use the voice search to look for applications. Simply click on the microphone button located at the top. Speak in your tablet's microphone and wait for matching applications to load.




- **Install an application on the tablet**

1. Inside the Lexibook® Market Premium, click on the application you want to download.
2. Click on “**Download**” twice. Please be patient while your application is being downloaded.
3. Information about the application is displayed on the screen.


Notes: click on “**Next**” or slide your finger up to display the rest of the message.




4. Click on **"Install"** to begin the installation.



5. A confirmation window appears. Select **"Open"** to immediately use the application or **"Done"** to confirm and close the window.




6. The application is then available in the applications menu.




- Add credit to your account


1. Click on the “**Account statement**” button, located at the top of the screen.



2. Next, click on the **“Add funds to your wallet”** button and wait for the page to load.



3. Type in the amount you wish to add to your wallet, and then choose the payment method.



4. a) Select “**PayPal & Cards**” to pay through a PayPal account or by card. Please follow the instructions.

Wallet topup € 0.00

My total: \$5.00 USD

Pay with a card Powered by PayPal

United Kingdom

Card number

Card type: Visa/Delta/Electron

Expiry date: 01/2014

Security code:

Email address

(+44) Phone number

Continue

Have a PayPal account? [Log in to PayPal](#)

Wallet topup € 0.00

My total: \$5.00 USD

Login PayPal

Log in with email and password:

Email

Password

Log In

Don't have a PayPal account? [Pay with a card](#)

[Problem with login?](#)

- b) Select “**Amazon Payments**” to pay through Amazon. Please follow the instructions.

Wallet topup € 0.00

amazonpayments™

Sign in with your Amazon account

E-mail Address:

Password:

Sign in

[New to Amazon.com?](#)

[Forgot your password?](#)


About Amazon.com Sign In

Amazon Payments uses information from your Amazon.com account to identify you and complete purchases. Your use of Amazon Payments is governed by our Privacy Notice and User Agreement linked below.


© 2014 Amazon.com, Inc., or its affiliates | [User Agreement](#) | [Privacy Notice](#)

- **Purchase an application**

1. First, you need to connect to your account. Please follow the steps described in the “Connect to the Lexibook® Market Premium” section above.
2. On the page of the application you want to purchase, click on “**Download**”.
3. After checking the application’s price, click on “**Purchase**”.



4. Choose the method of payment.



5. a) Select “**PayPal & Cards**” to pay through a PayPal account or by card. Please follow the instructions.


The screenshot shows the PayPal payment interface. At the top, the title is 'Purchase My Learning Journey' with a shopping cart icon and a total of '\$19.92 USD'. Below this, the 'Pay with a card' section is active, showing fields for 'United Kingdom', 'Card number', 'Card type' (Visa/Delta/Electron), 'Expiry date' (01/2014), 'Security code', 'Email address', and 'Phone number'. A 'Continue' button is at the bottom. A link 'Log in to PayPal' is also visible.

The screenshot shows the PayPal login interface. At the top, the title is 'Purchase My Learning Journey' with a shopping cart icon and a total of '\$19.92 USD'. Below this, the 'Login' section is active, showing fields for 'Email' and 'Password', and a 'Log in' button. Links for 'Don't have a PayPal account? Pay with a card' and 'Problem with login?' are also visible.

- b) Select “**Amazon Payments**” to pay through Amazon. Please follow the instructions.

The screenshot shows the Amazon Payments sign-in interface. At the top, the title is 'Purchase My Learning Journey' with a shopping cart icon and a total of '€ 0.00'. Below this, the 'amazonpayments' logo is visible. The 'Sign in with your Amazon account' section includes fields for 'E-mail Address' and 'Password', a 'Sign in' button, and links for 'New to Amazon.com?' and 'Forgot your password?'. At the bottom, there is a copyright notice: '© 2014 Amazon.com, Inc., or its affiliates | User Agreement | Privacy Notice'.


6. Once you obtain your receipt, you can download the application you have just bought.



• Find purchased applications

If you have uninstalled a previously purchased application, you can reinstall it without having to purchase it a second time.


1. Connect to the Lexibook® Market Premium by identifying yourself (see “Connect to the Lexibook® Market Premium”).
2. On the search screen (see “Find purchased applications”), type the name of the previously downloaded application.
3. If you have previously purchased the application, “You already own this application” will be displayed on the screen. To reinstall the application, click on “**Download**”. No additional payment will be asked.




• Changing the Lexibook® Market Premium Language

By default, the Lexibook® Market Premium is displayed in the language of your tablet. Should this not be the case, or should you wish to display the Lexibook® Market Premium in a different language, please follow the steps below.


1. From the Home screen of the Lexibook® Market Premium, press the “**Options**” button, and then select the “**Preferences**” option that pops up.



2. Select the “**Target language**” option to set the language of your choice.



3. In the drop-down list that shows up, select the language required. To do so, slide a finger toward the bottom or the top of the screen.



4. To display the Lexibook® Market Premium in a different language, repeat step 1 to 4 and select the required language at step 3.

Note: Lexibook® are continually improving their products. To obtain the latest version of the Lexibook® Market and download the latest updates, please visit the following link: <http://www.mylexibooktablet.com/fr/applications-pour-tablettes/applis-lexibook>.

This link is also accessible directly from the "LXB Update" shortcut, located on the Home screen of your tablet. Help us improve the Lexibook® Market! Feel free to contact Lexibook Customer Service if you notice inappropriate applications.

The Lexibook® Videostore

The Lexibook® Videostore allows you to watch your favourite cartoons directly on your tablet. You can choose from our catalog of videos and find your favourite series!

You can watch the selected episodes online or download them to your tablet.

Important notes:

Always ask for the help and permission of your parents before buying videos on the Lexibook® Videostore. To access the Lexibook® Videostore, your tablet must be connected to a Wi-Fi network. To download a video, it is recommended that you insert a micro SD card in the tablet.

4. Technical Information

Tablet Specifications

Screen	TFT LCD 4.3 inches
Screen Resolution	480 x 272 pixels
O.S.	Google Android™ 4.4
CPU	1GHz
Storage	8GB – Micro SD cards compatible up to 32GB
RAM	DDR 512MB
Wi-Fi	802.11 b/g/n (built-in)
Audio	Built-in mono speaker
Connectors	1 micro USB 2.0 port, 1 micro SD card slot, 1 headphone jack
Supported image format	JPEG, BMP, GIF
Supported music format	MP3
Battery	Lithium battery (included) - 1000mAh, 3.7V
Battery life	2 hours (average)
Dimensions	158 x 99 x 13 mm
Weight	180g
Language	English

Maintenance and Warranty

To prevent fire or shock hazard, disconnect your unit from the AC power source when cleaning. The finish on your unit may be cleaned with a dust cloth and cared for as other furniture. Use a soft, clean cloth moistened with plain, lukewarm water to clean the exterior of the unit. Use caution when cleaning and wiping the plastic parts. Mild soap and a damp cloth may be used on the front panel.

This product is covered by our 2-week warranty.

For any claim under the warranty or after sale service, please contact your distributor and present a valid proof of purchase. Our warranty covers any manufacturing material and workmanship defect, with the exception of any deterioration arising from the non-observance of the instruction manual or from any careless action implemented on this item (such as dismantling, exposition to heat and humidity, etc.). A broken screen as well as any damage caused by using an adapter other than the one provided is not covered by our warranty. It is recommended to keep the packaging for any further reference.

In a bid to keep improving our services, we could implement modification on the colours and the details of the product shown on the packaging.

NOTE: Please keep this manual, it contains important information. The contents of this manual may change without notice. No part of this manual may be reproduced without the written consent of the manufacturer.

Reference: MFC144

Designed and developed in Europe – Made in China, Shenzhen

© 2014 LEXIBOOK®

LEXIBOOK

Calex Logisticcs

Attn to: Brian Wesley / Jessica Munoz

175-177 SOUTH MAIN STREET

PA 18705

PLAINS

USA

Toll free number for English Speakers: + 1-866-654-7008

Service consommateurs à votre écoute : +33 (0) 892 23 27 26 (0,34€ TTC / min + coût d'un appel international)

E-mail : supportUS@lexibook.com

www.mylexibooktablet.com



**This product
is not a toy.**



**WARNING: Prolonged use at
full power of this product might
damage the ear of the user**

This device complies with Industry Canada licence-exempt RSS standard(s).
Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

FCC Notice

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes of modifications to this unit not expressly approved by the party responsible for compliance could void the user authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End user must follow the specific operating instructions for satisfying RF exposure compliance. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

The portable device is designed to meet the requirements for exposure to radio waves established by the Federal Communications Commission (USA). These requirements set a SAR limit of 1.6 W/kg averaged over one gram of tissue. The highest SAR value reported under this standard during product certification for use when properly worn on the body

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.