


























User manual

Display Instruction



1	Signal	 The signal state of the logger, good or bad.  
2	4G Tag	 Sign of 4G logger
3	Flight mode	 Signs of flight patterns
4	Bluetooth	NA
5	Hall	 Hall switch 
6	Charging icon	 This icon will be displayed when charging
7	Battery icon	 Full  sufficient  Low  Run out
8	Recording	 Record status: Recording
9	Alarm	 OK  Alarm
10	Start delay	 This icon is displayed during the start delay phase
11	Unit	 
12	Humidity	% relative humidity
13	Probe	 Probe is connected OK
14	Statistic type	 Max temp  Min temp  Average temperature
15	Alarm area	H L± Triggered the high or low threshold
16	Measured value	 Temperature, Humidity, Time
17	Colon	 Time, the interval between minutes and seconds
18	Decimal point	 The decimal point of the value

1. **Start :**

Long press "Start/stop" button till "REC" has been showed on the LCD interface, device is ready to monitor. At the same time, the record quantity also will be showed on the LCD interface.



2. **Stop :**

Long press “Start/Stop” button till “REC” disappear from LCD interface, the device has been stopped.



3. Check data :

Short press “Data” button, to show some information:

MAX temperature value

MIN temperature value



4. **Mode Switch** :

- Long press “Mode” button, to enter flight mode:
In flight mode, the logger only records data and doesn’t send data to platform.
LCD will be shut down, display nothing.
- Long press “Mode” button again, to quit flight mode:
Data report, LCD show, everything back to normal



6. **Usage scenarios**

Put the device in the container with goods together.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and

on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance of 20cm from your body.
