

## General description of the RF transmitter

The RF remote control system consists of a RF transmitter and a RF receiver mounted within the control unit. The RF transmitter is mechanically integrated in the head of the key. This transmitter is used to transmit an information for locking or unlocking the vehicle by an unidirectional RF transmission line for normal remote operation by pressing a button.

In general the following functions are provided:

- Lock the car
- Unlock the car
- Unlock trunk

## Power supply

The transmitter is provided with 1 Lithium battery (CR 1616) that gives a tension of feeding of +3V.

The battery inversion is protected mechanically.

## Buttons

There are two buttons which enable to lock, unlock the doors and unlock the trunk. During activation, the button is forced to the ground via a “pull-up” within the microcontroller.

## LED

The LED is turned on between transmission blocks.

## Variants

Siemens type designation	frequency	difference
5WY 8201	315 MHz	without transponder
5WY 8202	315 MHz	with transponder-master
5WY 8203	315 MHz	with transponder-non master
5WY 8204	433 MHz	without transponder
5WY 8205	433 MHz	without transponder
5WY 8206	433 MHz	with transponder-non master

**All variants have the same schematic, pcb and layout. The only difference is the transponder usage.**