


# IPRO

# Jade8S

## Quick Starter Guide


# IPRO



## Quick Starter Guide

Thanks for using this Android™ Phone.

**Phone Overview**



1. Earphones jack
2. USB port
3. Receiver
4. Front camera
5. Volume key
6. Power on/off key
7. Mic hole
8. Back camera
9. Flash LED
10. Speaker
11. Fingerprint

**Basic Operations**

Switch on  
Touch and hold the Power button until the phone switches on.  
Note: If you have enabled USIM/SIM locking in the Settings menu, enter the correct PIN number upon power-on before you use the phone.

Caution: Three consecutive attempts of entering an incorrect PIN will lock the SIM card. If it is locked, use a PUK provided by the operator to unlock it.

Switch off  
Touch and hold the "Power button" until the Phone Options screen displays. Tap "Power off" to switch off the phone.

Unlock  
Short press the "Power button" light up the screen, according to the clues of the screen interface can be unlocked.

**Touchscreen Usage**  
Use your fingers to perform operations directly on icons, buttons, and the on-screen keypad.

Tap/Touch/Click  
Tap the icon of an App to start it.

Touch & Hold  
Touch and hold an item to display a pop-up menu of options. For example, go to Address Book, touch and hold a contact on the Address Book page, and a menu of options pops up.


**Drag**  
Tap an item on the screen and drag it to another place.

**Slide/Sweep**  
To sweep vertically or horizontally across the screen, you can view apps, pictures, and webpages in a convenient manner.

**Scroll**  
Similar to sweeping, but faster.

**Pinch**  
Put two fingers on the screen to pinch in or out an item, such as a webpage or picture.

**Home Screen**  
1. Status bar: allows you to view status icons and notices, such as signal, battery, current time and data service.  
2. Notification bar: On the Home screen, tap the status bar and drag it down to display the notification bar. Tap this bar. Then you can view the notices. Touch the return button to switch back to the previous page.  
3. App icon: Tap an app to open it.  
4. Main menu: allows you to enter the app main menu.



manage your SIM cards on the pop-up page.  
2. Network: In the Settings menu, select WLAN to configure your radio network; or select Traffic usage to configure your mobile data services; or select Mobile Network under More to configure data services of your phone.  
3. Sound : In the Settings menu, choose Sound. The allows you to set the volume, enable/disable vibration during ringing, and select ringtones for incoming calls and messages, as well as enable/disable keypad touch sound effect, touch alert tone, and screen lock tone  
4. Display: allows you to configure the brightness, wallpaper, automatic device rotation, sleep duration, and font size.  
5. Security: In the Settings menu, choose Security. The Security page allows you to set the screen locking mode and USIM/SIM locking mode. App Permission: allows you to configure certain permissions for an App and monitor their usage.  
6. Anti-theft: allows you to remotely lock the phone or clear all data of it.  
7. Manage apps: In the Settings menu, choose Apps. Then you can view or manage your apps.  
Note: Disable or unload certain apps if available space is less than 100MB.  
8. Message: On the Message page, tap the Menu button and choose Settings. On the Message Settings page, you can enable/disable report sending, create or select a message template, and configure a message alert tone for each short or multimedia message.  
9. Call: To display the Call Settings page, choose Settings on the Call page.

<p><b>Widget</b></p> <p>Android 8.1 offers <b>multiple</b> ease-of-use <b>widgets</b> on the Home screen. On this screen, Long press the screen and then the <b>Widget</b> tab, to display the widget selection page. Tap and hold a desired widget to be put on the Home screen, drag it left or right to locate it at a proper place, and complete the Widget settings as prompted.</p> <p><b>Move/Uninstall apps</b></p> <p>1. Access the App main menu from the Home screen. On the ALL App page, tap and hold an app to be put on the Home screen, and drag it left or right to locate it at a proper place. In this way, a desktop app is created.</p> <p>2. On the All App page, tap and hold an app, and drag it to <b>Uninstall</b> on the desktop. In this way, an app is removed from the phone.</p> <p>Note: You are not allowed to uninstall basic apps of the phone.</p> <p>3. On the All App page, tap and hold an app, and drag it to <b>APP Info</b>, on the desktop. In this way, details about the app is displayed.</p> <p><b>Call</b></p> <p>This phone allows you to make or answer a call, initiate an emergency call, and launch a multi-party call.</p> <p>On the bottom left of the Home screen, tap the Dial-up icon. The Dial-up page is displayed. Enter a phone number and choose between card 1 and card 2 to make the call. When you enter the number, the phone will automatically search among all contacts a number that best matches the entered numerals, to facilitate your operation.</p> <p>During a call, tap <b>Add a Call</b>, and this call automatically switches to <b>Silent mode</b>. Enter the number of another contact, tap <b>Dial-up</b>, and the previous call automatically switches to <b>On-hold mode</b>. After the second call is answered, tap <b>Join</b>. In this way, a teleconference is established to achieve a multi-party talk.</p> <p>Note: You need to subscribe to this service from your carrier before you use it.</p> <p>You are also allowed to initiate a call by selecting a phone number from the list of contacts or the Message page.</p>	<p><b>Contacts</b></p> <p>Tap <b>Contacts</b> to open it. The <b>Contacts</b> page offers management functions. It allows you to view the list of contacts and related details, make a call or send an SMS to a certain contact, and share the contact.</p> <p><b>Contact import</b> : On the <b>Contacts</b> page, tap the <b>Menu</b> button, and choose <b>Import/Export</b> to select a mode for importing or exporting a contact.</p> <p><b>Add a contact</b> : On the lower right of the <b>Contacts</b> page, tap the <b>Add</b> button to add a contact to your phone or USIM/SIM. Enter the name and number, and tap <b>Finish</b>. In this way, a contact is created.</p> <p><b>Contact list</b> : On the <b>Contacts</b> page, tap the image of a contact. Details about the contact is displayed. This allows you to quickly make a call or send an SMS to the contact.</p> <p><b>Search contact</b> : On the <b>Contacts</b> page, tap <b>Search</b>, and enter related information about a certain contact to search it among the list of contacts.</p> <p><b>Message</b></p> <p><b>Tap Message</b> on the desktop. Then you can create and send an SMS or MMS.</p> <p><b>New message</b>: Tap the <b>Add</b> icon on the upper right of the <b>Message</b> page. The message creating page is displayed. Enter the name or phone number of the target contact to the <b>Recipient</b> bar. The phone will automatically search among the list of contacts for one that best matches the entered info. (You can also select the contact from the list of contacts or groups.)</p> <p><b>Input method</b>: Tap the text editing zone to invoke the keypad. Long press the space bar to switch your input method.</p> <p><b>Send</b>: After an SMS is complete, tap <b>Send</b> and choose between card 1 and card 2 for sending the SMS.</p> <p><b>Browser</b></p> <p>Tap <b>Browser</b> to open it. The <b>Browser</b> page allows you to access and manage WAP and WWW webpages.</p> <p>During a browse, tap the <b>Menu</b> button, choose <b>Bookmark</b> to display</p>	<p>the <b>Bookmark</b> list. In addition, tapping the <b>Menu</b> button helps save the webpage that you are viewing to the <b>Bookmark</b>.</p> <p>Tap the <b>Menu</b> button during a webpage browse: also allows you to share the webpage, search on the webpage, and view history records.</p> <p><b>Add a webpage bookmark</b> to desktop: On the <b>Bookmark</b> page, tap and hold a bookmark, and choose "Add shortcut to the Home screen". In this way, you can add frequently used webpages to the desktop for future access.</p> <p><b>Browser settings</b>: Tap the <b>Menu</b> button and choose <b>Settings</b>. The <b>Browser Settings</b> page allows you to configure the browser as desired, such as common content settings and privacy &amp; security settings. <b>Advanced settings</b> allows for resetting to default settings.</p> <p><b>E-mail</b></p> <p>Tap <b>E-mail</b> to open it. The <b>E-mail</b> page is display. On this page, you can send and receive an e-mail via the phone.</p> <p>For the first time you use this function, enter your e-mail account and password to set up an account. You can also set more accounts for ease of uniform management of all mails.</p> <p><b>Gallery</b></p> <p>Gallery saves and manages all pictures obtained via the camera, Internet, and the MMS received.</p> <p>On the <b>Home</b> screen, tap <b>Gallery</b> to open it. The <b>Gallery</b> page is displayed. It supports management of all pictures.</p> <p>Open a picture and then click the share button at the top. In this way, the picture is shared via the Bluetooth, message, and mail.</p> <p><b>Clock</b></p> <p>Tap <b>Clock</b> to open it. The <b>Clock</b> page is displayed.</p> <p><b>Set clock</b>: Tap the alarm clock on the upper left. The <b>Alarm Clock</b> page is displayed.</p> <p><b>Add clock</b>: On the <b>Alarm clock</b> page, tap "+" on the top to add an alarm. Edit the alarm time and tap <b>Finish</b>. When editing the alarm time, select <b>Hour</b> before <b>Minute</b>. For example, in the 12-hour format,</p>	<p>select 8 as the hour and 0 as the minute, and select a.m.</p> <p><b>Multimedia Function</b></p> <p>The phone also supports many multimedia functions, such as camera, music, and recorder. Tap any icon of theirs to open any one of them.</p> <p><b>Manage File</b></p> <p>This function allows you to copy, paste, share and delete a file stored on the SD card or other memory cards.</p> <p><b>Search</b></p> <p>On the <b>Home</b> screen, Tap <b>Google™</b>, and enter keywords. In this way, you can search for a webpage, app, contact, and music. The result will be displayed below the search bar.</p> <p><b>Voice Search</b></p> <p>In the network-connected state, tap <b>Voice Search</b>, and speak to the microphone what you want to search, such as weather and other information.</p> <p><b>Google Play Store</b></p> <p>This store allows you to download the latest Android apps, games, movies, TV programs, books, and magazines to your phone.</p> <p><b>Troubleshooting</b></p> <p>To save time and avoid unnecessary cost, please conduct the following checks before contacting our after-sale personnel:</p> <p>1. Unable to turn on the phone: Check whether you have tapped and hold the <b>Power</b> button for over two seconds. Check whether the battery is in good contact. If not, remove the battery, reinstall it, and turn on the phone again. Check whether the battery runs out. If yes, charge it.</p> <p>2. Poor signal: It is possibly because of where you are, for example, on the basement or near a high-rise, that deteriorates the reachability of radio waves. Please move to someplace with better signal reachability.</p> <p>3. Echo or noise: The network trunk line of certain carriers may be in poor quality. Please tap the hang-up icon and redial, so that you</p>	<p>may switch to another trunk line with better quality.</p> <p>4. Unable to charge the battery: Your battery may fail. Please contact the dealer.</p> <p>5. SIM card error: The metal surface of the SIM card is dirty. Rub the metal contact terminals with a clean dry cloth.</p> <p>The SIM card is not installed properly. Install it again as specified in the user manual.</p> <p>The SIM card breaks down. Contact the network service provider.</p> <p>6. Unable to enter anything into <b>Phone Book</b>: This is possible because that your phone book memory is full. Please delete needless data from <b>Contacts</b>.</p> <p>Google, Android, Google Play and other marks are trademarks of Google LLC.</p> <p><b>FCC Warning</b></p> <p><b>Specific Absorption Rate (SAR)</b> information SAR tests are conducted using standard operating positions accepted by the FCC with the phone transmitting at its highest certified power level in all tested frequency bands, although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value, in general, the closer you are to a wireless base station antenna, the lower the power output.</p> <p>Before a new model phone is a available for sale to the public, it must be tested and certified to the FCC that it does not exceed the exposure limit established by the FCC, Tests for each phone are performed in positions and locations (e.g. at the ear and worn on the body)as required by the FCC.</p> <p>For body worn operation, this mobile phone has been tested and meets the FCC RF exposure guidelines when used with an accessory designated for this product or when used with an accessory that contains no metal and that positions the handset a minimum of 1.0cm from the body.</p>	<p>This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</p> <p><b>Note:</b> This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</p> <p>--Reorient or relocate the receiving antenna.</p> <p>--Increase the separation between the equipment and receiver.</p> <p>--Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.</p> <p>--Consult the dealer or an experienced radio/TV technician for help.</p>
---	---	---	--	---	---