



Sage Co., Ltd.

2F,KY- Bldg. 2-24 Sumiyoshi-Cho Naka-Ku
Yokohama-City Kanagawa Pref
231-0013 Japan

User manual for

OP Tag JSG-B001

Ver 1.0

Sage Co.,Ltd.

May 23, 2022

Date: 2022/5/23

Contact Information

Taiki Urasaki

Engineer

t.urasaki@jsage.co.jp

Sage Co., Ltd.

2F,KY- Bldg. 2-24 Sumiyoshi-Cho Naka-Ku
Yokohama City Kanagawa Pref
231-0013 Japan



Sage Co., Ltd.
2F,KY- Bldg. 2-24 Sumiyoshi-Cho Naka-Ku
Yokohama-City Kanagawa Pref
231-0013 Japan

Contents

GENERAL

- 1.JSG-B001 date sheet
2. System Block diagram
3. Appearance
4. Components
5. State transition diagram



Sage Co., Ltd.
2F,KY- Bldg. 2-24 Sumiyoshi-Cho Naka-Ku
Yokohama-City Kanagawa Pref
231-0013 Japan

General

Purpose of this Guide is to install the devices and to describe the related function how to use them for the Dealers and Mechanic of contracting company. The functions are necessary to operate the initial setup and maintain an appropriate usage of the App.

FCC Statement :

Any changes or modifications not expressly approved by the party responsible for compliance could void the User's authority to operate the equipment.

This Device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This Device may not cause harmful interference, and (2) this Device must accept any interference received, including interference that may cause undesired operation

Class B digital device:


This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

1 JSG-B001 data sheet

Physical	
Size	W33xD45xH7.4 mm
Weight	9g
Environment	
Operating temperature	0 degrees C to +40 degrees C
Storage temperature	-10 degrees C to +55 degrees C
Performance	
Maximum electric power consumption	400 μ A/3 V(CR2032)
Standby electric power consumption	100 μ A/ 3V
Version	
Hardware version	1.00
Software version	1.00


2 System Block diagram



3 Appearance



4 Components



1: Power (CR2032)

2: BLE Module

5 State transition diagram

