





Quick Start Guide for Parts: EQT3-4, EQT3-7 & EQT3-10




Step 1 (Option 1): Mounting - Panel Mounting

(1) Cut panel door to size specified in punchout table

(2) Mount EQT3 securing with clips provided


Punchout Table

Part #	Width x Height
EQT3-4	4.331x 2.914 in. (11 x 7.4 cm)
EQT3-7	6.9 x 4.646 in. (17.5 x 11.8 cm)
EQT3-10	9.607 x 6.26 in. (24.4 x 15.9 cm)




Step 1 (Option 2): Backplane or VESA Mounting

(1) Using screws provided, mount to backplate or to VESA bracket. Note, the EQT3-4 unit does not use standard VESA mounting holes. Refer to drawing below.



Version1.0

Step 2: Power Wiring





WARNING



Do not apply line voltage
(mains), 12~24 Vdc only

2-conductor wire 18 AWG for distances up to 100 feet (30 meters)

Step 3: Comm Wiring



Step 4: Comm Wiring



Antenna Connector

BT SMA connector for Bluetooth
WIFI(Aux) SMA connector for WIFI Aux
WIFI(Main) SMA connector for WIFI Main
Only EQT3-7 and EQT3-10 support
Bluetooth & WIFI function

Professional installation instruction

1. Installation personal
This product is designed for specific application and needs to be installed by a qualified personal who has RF and related rule knowledge. The general user shall not attempt to install or change the setting.
2. Installation location
The product shall be installed at a location where the radiating antenna can be kept 20cm from nearby person in normal operation condition to meet regulatory RF exposure requirement.
3. External antenna
Use only the antennas which have been approved by the applicant. The non-approved antenna(s) may produce unwanted spurious or excessive RF transmitting power which may lead to the violation of FCC limit and is prohibited.
4. Installation procedure
Please refer to user's manual for the detail.
5. Warning
Please carefully select the installation position and make sure that the final output power does not exceed the limit set force in relevant rules. The violation of the rule could lead to serious federal penalty.



Federal Communication Commission Interference Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

This device meets all the other requirements specified in Part 15E, Section 15.407 of the FCC Rules.

Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.