

User Guide

Product Introduction



Scan to check
the installation video
SKU: MS4902 V1.0



Battery Indicator

Indicator	Battery Status
● ● ● ● ●	100%
● ● ● ● ●	80%~90%
● ● ● ● ●	60%~70%
● ● ● ● ●	40%~50%
● ● ● ● ●	20%~30%



Wireless Charging area

Power Switch

USB-C

60 mm

Recharging Your Devices

1. Place the watch on the wireless charger with precise alignment.
2. Make sure the charging indicator is on when charging.



NOTE:

Please note that the watch needs to be precisely placed in the right position on the wireless charger, taking care not to let the protective case of the watch interfere with the charging.

Specifications

Product Name	Switch Wireless Charge Power Bank		
Battery Capacity	1000mAh 3.7V/3.85Wh	Model	DC-052
Wireless Output	5V/500mA	Input	5V/750mA
Package Content	1* Switch Wireless Charge Power Bank, 1* Carabiner, 1* USB Cable, 1* User Guide, 1* Brand Sticker		

120 mm

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.