Rename Item

Name of the Passport Wallet can be changed. Remove Item

- Make sure "Lost Mode" is disabled and click "Remove **Item**". After selecting the option, the system will pop up "Remove Item?" and click "Remove" to complete the
- The Passport Wallet is now reset and ready to pair to a new device.

Share This Item

- Tap "Add Person" to share your Passport Wallet with another individual
- Tap "Continue" and select specific people to share.
- Tap "Share" and wait for the others to confirm your invitation.
- Others also can locate this item and tracking notification will be

*Available for iOS 17 and above.

System Requirements and Compatibility

- Apple ID
- iPhone models with iOS 14.5 or later.
- · iPad models with iPadOS 14.5 or later.

About the Find My App

The Apple Find My network provides an easy, secure way to locate the item using the Find My app on your iPhone, iPad, Mac, or the Find Items app on Apple Watch.

To use the Apple Find My app to locate this item, the latest version of iOS, iPadOS, or macOS is recommended. The Find Items app on Apple Watch requires the latest version of watchOS.

Learn More

· This item can be located by its owner using the Find My app. For more information, follow the

instructions

- Locate the button on the top of the device.
- Press the button twice. You will hear a confirmation sound.
- Tap "Continue On Website" for more information including any Lost Mode message

How to Disable

- Locate the button on the top of the device.
- Long press the function button three seconds until two beeps are heard. This will stop sharing the location of this Passport Wallet.

Factory Reset

- Press the button 4 times rapidly and then hold it a fifth time until you hear a ringing chime.
- A reset operation is required to enable the device to enter the pairing state again (synchronization of Find My also requires simultaneous disconnection) and reconnect the new

How can I prevent my device from being used for malicious tracking? When someone else's device mixes with your belongings, and tracks it over a period of time, you will he reminded in two ways:

- If you have an iPhone, iPad, or iPod touch, you will get alerts on your Apple device. This feature is available on iOS or iPadOS 14.5 version or above.
- If someone else's device finds its way into your stuff, your iPhone will notice it is traveling with you and send you an alert. After a while, if you still have not find it, the Passport Wallet will start playing a sound to let you know where it is.

Important Tips:

When pairing a device with Find My app, the phone will link to the Apple server. Pairing may fail because of network problems. The following action is recommended:

- a. Change the phone's network, such as switching between Wi-Fi and mobile. The first pairing may take a long time, please wait patiently
- b. Reset your Passport Wallet.

c. When "Lost Mode" is enabled, DO NOT REMOVE ITEM in the APP. Your Find-My-Passport Wallet will be locked and cannot be paired to a new device.

Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory

Apple, Apple Find My, Apple Watch, Find My, iPhone, iPad, iPadOS, Mac, macOS and watchOS are trademarks of Apple Inc., registered in the U.S. and other countries. IOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.

To use the Apple Find My app to locate this item, the latest version of iOS, iPadOS, or macOS is

Care and Maintenance

Read the following recommendations before using the unit. Following these you will be able to enjoy the product for many years.

- Don't expose the unit to liquid, moisture or humidity to avoid the product's internal circuit being affected.
- Don't use abrasive cleaning solvents to clean the unit.
- Don't expose the unit to extremely high or low temperature as this will shorten the life of electronic devices, destroy the battery or distort certain plastic parts.
- Don't dispose of the unit in fire as it will result in an explosion. Don't expose the unit to contact with sharp objects as this will cause scratches and damage.
- Don't let the unit fall down onto the floor. The internal circuit might get damaged. Don't attempt to disassemble the unit as it may get damaged if you are not a professional.
- The wallet should not be disposed of as municipal solid waste. To recycle it, contact your local hazardous waste process or contact Call 2Recycle on their website, call 2recycle.org, or by phone at 877-273-2925 to find the nearest drop-off location for lithium-ion batteries.

Federal Communications Commission (FCC) Statement
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device,

pop-up "Searching Items."

pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

• Reorient or relocate the receiving antenna.

• Connect the separation between the equipment and receiver,

• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- connected.

 Consult the dealer or an experienced radio/TV technician for help.
 The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exosoure condition without restrictions.
- Warning: Changes or modifications made to this device not expressly approved by the party responsible for compliance may void the FCC authorization to operate this device.

RF exposure statement:
This device complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. The device is installed and operated without restriction.

LIMITED LIFETIME WARRANTY

E-filliate warrants that the product is free from defects in materials and workmanship, provided that the product is utilized inaccordance with E-filliate's instructions.

Customer Service:

We're here to help. If you are not fully satisfied with this product or have questions on how to use it, please contact E-filliate, Inc. You do not need to contact the retailer from whom the product was purchased. Please contact one of our service representatives before shipping merchandise to us.

www.efilliate.com

support@efilliate.com

(800) 592-7031 toll-free

(916) 858-1000

(916) 858-1009 FAX

11321 White Rock Road Rancho Cordova, CA 95742 USA

Customer service representatives are available


8 a.m.-5 p.m. PT, M-F

TRAVEĽ DEPOT

FIND-MY-PASSPORT WALLET WITH WIRELESS CHARGING

INSTRUCTION MANUAL

300 0014 TD2





FIND-MY-PASSPORT WALLET WITH WIRELESS CHARGING

Instruction Manual

AWARNING: BEFORE USING THE PRODUCT. PLEASE READ THIS INSTRUCTION MANUAL CAREFULLY AND KEEP IT FOR FUTURE REFERENCE.

Package Contents

- Find-My-Passport Wallet With Wireless Charging
- User Manual

Components at a Glance

Find-My-Passport Wallet Power/Pairing Button 2 LED Indicator Wireless Charging Area Passport Slot Ticket Slot G Card Slot (4) SIM Card Slot (2)

Getting Started

Power On/Off

- **Power On:** Short press the Power button once. You'll hear a short chime, indicating it is powered on and in pairing status
- **Power Off:** Long press the Power button for three seconds. It will beep twice, indicating

Add your Passport Wallet to the Find My App



Open "Find My" App on your supported iPhone, iPad, iPod Touch or Mac computer.

Select "Items" at the bottom, then tap "Add Other Item" or

Allow notifications from the App.

tap on "+" icon directly.

4. Select "Other Supported Items."



You will see "Travel Depot Tag" pop up, then tap" Connect".

Make sure your Passport Wallet is close to your phone. It will





9



Follow the pop-up to fill name, and select an emoii, then tap"Continue



When "This Item Is Linked to Your Apple ID" pops up, tap "Agree".



- - Tap "Finish" to complete your Passport Wallet setup.





Specifications

Polymer Battery Capacity: 80 MAH

Charging: Wireless Charging

- **Function Introduction**
- Find Items Tap "Play Sound" to make your Passport Wallet beep when it is nearby.
- Find Your Item's Location Your Passport Wallet's last known location will appear on the map as the emoji you choose during setup. Tap "Directions" to navigate to the last known location.



(3)

Albert Ann

- Enable the "Notify When Found" toggle, when your Passport Wallet's location is seen by another "Find My"enabled device, you will receive a notification of its updated
- · Enable the "Notify When Left Behind" toggle, you will receive a notification when you leave your Passport Wallet behind and it is no longer in range of your device.

Note: "Notify When Found" can only be activated when your Passport Wallet is out of range.

Lost Mode

- When your Passport Wallet is lost under "Lost Mode", tap the "Enable" tab. A screen calling "Lost Mode" will pop up, tap "Continue". You can enter your phone number or email address and tap "Next".
- You may enter a message that will be shared with the person that finds your Passport Wallet. Tap "Activate" to enable "Lost Mode".
- When "Lost Mode" is enabled," Notify When Found" is automatically enabled. • When "Lost Mode" is enabled, your Passport Walletis locked and cannot be paired to a new device.

