

3

Follow onscreen instructions



Software update starts.

Handset Screens

- **↓** Layout
- ◆ Toggling Home Screen Sheets
- Navigation Bar
- ◆ Portrait Orientation & Landscape Orientation

Layout



Item	Description	
1 Status Bar	Flick down for Notifications Window. Continue and Flick screen down for	
	Quick Settings.	
2 Customize Area	Place application shortcuts, folders, widgets freely.	
3 Dock	Place shortcuts (applications), folders, etc. Appears even when Home	
DOCK	Screen sheets toggled.	
4 Navigation Bar	Tap icons to access functions. For Navigation Bar, see "Navigation Bar."	

5 Side Sense Bar	Open Side Sense menu, return, open Multi Window menu, etc.		
6 Quick Search Box	Search for applications or search 🬀 (Google) with entered words and		
	phrases.		

Toggling Home Screen Sheets


Customize each Home Screen sheet with application shortcuts, widgets, etc. to make handset more convenient. Flick Home Screen left/right to toggle sheets.

■ In any Home Screen sheet, Tap to return to Home Screen top sheet.



Navigation Bar

Tap icons on Navigation Bar (Display bottom) for the following functions/operations. Also use gesture action. For details, see "System Settings."



Item	Description
(Back)	Return to previous screen. Appears as 🔽 for
	onscreen keyboard; Tap to close keyboard.
(Home)	Tap for Home Screen.
	Touch & Hold for Google Assistant.
(History)	Show history of used applications to activate/exit
	them. Also capture screenshot of shown
	application, view in a pop-up window, or activate
	multi-window switch.
(To landscape orientation) / 🗓 (to	Appears when handset and screen orientations
portrait orientation)	are different. Tap 🗀 for horizontal orientation,
	and 📮 for vertical orientation.

Portrait Orientation & Landscape Orientation

appears on Navigation Bar when handset is rotated sideways. Tap to change screen to landscape orientation. To change to portrait orientation, rotate handset vertically and Tap . Set "Auto-rotate screen" to on to change screen to landscape orientation automatically when

handset is rotated horizontally. For details on Auto-rotate screen, see "Display Settings."

■ Depending on the current screen, the orientation may not change even by changing handset orientation.




Status Bar

Status Bar appears at the top of Display. Notification Indicators for new mail, etc. and Status Indicators for handset appear here.

- Status Bar Layout
- Main Notification Indicators
- Main Status Indicators

Status Bar Layout



- **1** Notification Indicators
 - Status Indicators

Main Notification Indicators

Notification Indicators appearing in Status Bar include the following.

Indicator Description

5/14

×	Missed Call
<u>L</u>	Call Arriving/Calling/Dialing
<u>u</u>	Call on Hold
0.0	New Answering Machine Message / Voicemail
\bowtie	New Gmail
₽	New Text Message (SMS) / S! Mail / +Message
A	Error/Caution
?	Wi-Fi Open Network Available
ψ	USB Device Connected
*:	Sharing File via Bluetooth
1	Data Uploading
U	Data Downloading
	Application Update Available
31	Calendar Event Reminder
0	Alarm Sounding/Snoozing/Unchecked Alarm/Next Alarm
Ō	Stopwatch in Use
X	Timer in Use
1	Low Battery Alert (15% or less)
	SD Card Detected/Mounting/Unmounting
D	Software Update Notice/Waiting to Restart after Update

Main Status Indicators

Status Indicators appearing in Status Bar include the following.

Indicator	Description
	Battery Full (100%)
Ø	Battery Charging
•	Battery Low
	STAMINA® Mode
\mathbf{M}	Signal Strength
5G ₄1 1†	5G Data in Use ¹
4G ₁₁1 †	4G LTE/4G Data in Use ²
3G ₁1 1†	3G Data in Use
. 11 [♦]	No Signal
4	Airplane Mode
<u></u> 3	Wi-Fi Connected
5 5 3	Wi-Fi Connected without Internet Accessibility, or Unstable Wi-Fi Signal

*	Bluetooth Connected
<u> </u>	Silent Mode (vibrate)
芨	Silent Mode (no vibrate)
Θ	Do Not Disturb ⁴ On
②	Obtaining Current Location

- 1 Although "5G" may appear in standby (top of Display), this may change to "4G" with data communication then being by the 4G network.
- 2 Handset supports FDD-LTE (SoftBank 4G LTE) and AXGP (SoftBank 4G); indicator appears when handset is connected to either. Handset connects to SoftBank 4G first.
- 3 Number at left in icon indicates the connection standard of the access point.

4: IEEE 802.11n

5: IEEE 802.11ac

No number: IEEE 802.11a/b/g

4 For details on Do Not Disturb, see "Sound Settings."

Using Notifications Window

Check Notification Indicators and the details in Notifications Window.

- Opening Notifications Window
- Notifications Window Layout

Opening Notifications Window

1

Flick Status Bar down




Notifications Window opens.

Closing Notifications Window

Flick screen up

Notifications Window Layout



- 1 Icon may not appear depending on notification.
- 2 Available applications depend on notification. Example: with call notification, dial/send SMS to phone number that call was from.
- 3 Deletion may not be possible depending on notification.

Notifications Window Operations

Setting Notifications Not to Appear In Notifications Window, Touch & Hold notification to set Turn off notifications Apply Some notifications are not changeable.

Changing Notification Types

In Notifications Window, Touch & Hold notification to change Priority/Default/Silent Apply

- Notification type is not changeable for some notifications.
- Shown types depend on the notification.

Using Quick Settings

Tap icons to toggle functions on/off, etc.

- Opening Quick Settings
- Quick Settings Layout


Opening Quick Settings

1

Flick Status Bar down



Flick screen down



- Quick Settings opens.
 - Alternatively, Flick Status Bar down using two fingers.

Screen while Music Playing

When playing back music with Music or other application, control panel appears in Quick Settings. Play, pause, etc. and change where to output audio.

Quick Settings

Closing Quick Settings

Flick screen up


■ Alternatively, Tap to close Quick Settings.

Arranging Quick Settings


Add, delete, and change order of functions in Quick Settings.

In Quick Settings, Follow onscreen instructions and Drag icon

Quick Settings Layout



- 1 Adjust brightness
- 2 Set Wi-Fi/mobile data
- 3 Auto-rotate screen on/off
- 4 Silent mode (vibrate) / Silent mode (no vibrate) / Silent mode (off)
- **5** Bluetooth on/off
- 6 Enter/exit Airplane mode
- Docation on/off



- 1 Nearby Share on/off
- 2 STAMINA mode on/off
- Screen record start/stop
- 4 Show power menu
- **5** Add, delete, and change order of Quick Settings
- 6 Flashlight on/off
- Wi-Fi hotspot tethering on/off
- 8 Show handset settings

Placing/Answering Calls

- Answering Calls

Phone Function

Emergency Location Report

Making emergency calls (110, 119 or 118) automatically reports handset location to corresponding agency (police, etc.). This system is referred to as Emergency Location Report, and notifies location based on positioning from base stations.

- Location Report does not incur registration/transmission fees.
- Location/signal conditions affect positioning accuracy. Always provide location and call purpose.
- Hiding Caller ID (using 184, etc.) cancels Location Report. However, corresponding agency may obtain location information in life threatening situations.
- Location Report is not sent for calls made while outside Japan.

VoLTE/VoLTE (HD+) and HD Voice

Handset supports VoLTE/VoLTE (HD+) and HD Voice for higher voice call quality.

- **P** Hints
- Q Difficulty during call
- A It may not be possible to make a call properly in a noisy location.
- When calling using Speaker, check the call volume. Raising the call volume may make calling difficult.
- Q Sound pops momentarily during a call
- A re you changing location while calling? Sound pops when signal is weak and handset switches to a different area.

Emergency Call Cautions

Emergency calls from handset can be made only in SoftBank service areas.

Placing Calls




In Home Screen, (Phone)



Phone opens.

2

#



Dialing screen opens.



Tap dialpad to enter the other party's number



■ Enter area code first for calling landline numbers.






Phone



Handset dials number. Call begins when other party answers.



To end the call, 💿



Call ends.

Calling the Emergency Number When the Phone's Screen is Locked


Flick Lock Screen up EMERGENCY CALL Enter number for emergency service


- Available only when screen lock is set to "Pattern," "PIN," or "Password."
- Hints
- Q Call does not connect
- A Was the number dialed using the area code? Dial the number starting with "0."
- A Are conditions for calling poor? Call again after moving where signal is good.

Answering Calls




Swipe (Flick) up when call is arriving







To end the call, •





Arriving Call Operations


Cancelling Ringtone

Press Volume Key or Power Key when call is arriving

Rejecting Arriving Calls

Swipe (Flick) own when call is arriving

In-Call Screen Layout/In-Call Operations



1 Appears 🖽 for calls with HD Voice, and 旺 for calls with VoLTE (HD+).

Optional Services

Use the following optional services.

- Optional Services
- Using Call Forwarding
- Using Voicemail
- Using Call Waiting
- Using Group Calling
- Using Caller ID Notification
- Using Incoming Call Barring

Optional Services

Use the following optional services.

Service	Description
Call Forwarding	Divert calls to a preset number when out of
	service area or unable to answer.
Voice mail	Divert calls to a Voicemail Center to take
	messages when out of service area or unable to
	answer.
Call Waiting ¹	Answer calls during a call.
Group Calling ¹	Merge multiple calls.
Caller ID notification / display	Send or hide your number when placing calls.
Outgoing Call Barring / Incoming Call Barring	Restrict incoming/outgoing calls by conditions.

¹ Requires separate subscription.

Using Call Forwarding




In Home Screen, (Phone)



2





3


Voice Mail / Call Forwarding



Voice Mail / Call Forwarding settings open.




Voice Mail / Call Forwarding<mark>ラ</mark> Call Forwarding ON






Ring Time Select ring time






Telephone Number of Forwarding Destination → Tap phone number field → Enter phone number to forward to → REGISTER





CONFIRM



Call Forwarding is activated.

Using Voicemail




In Home Screen, (Phone)



2





3


Voice Mail / Call Forwarding



Voice Mail / Call Forwarding settings open.




Voice Mail / Call Forwarding<mark>ラ</mark> Voice Mail ON






Ring Time Select ring time





CONFIRM





appears in Status Bar for new message. Flick Status Bar down and Tap Voicemail notification, then follow the voice prompts.

Using Call Waiting


This service requires subscription.




In Home Screen, (Phone)







for Call Waiting ()




- Call Waiting is set.
 - Tap icons to toggle set ()/cancel ().
 - If Call Waiting is set and a second call arrives during a call, Call Waiting tone is heard. Swipe (Flick) up to begin call.

Using Group Calling

This service requires subscription.



During a call, Add call



Dialing screen opens.




Enter phone number Call



Call is added.



When the other party answers, Merge



Group Calling starts.


Using Caller ID Notification




In Home Screen, (Phone)







Caller ID<mark>ᢒ</mark> Hide number/Show number



Caller ID notification is set.

Using Outgoing Call Barring

Restrict outgoing calls and SMS to phone numbers.


■ It may not be possible to restrict outgoing SMS in some areas.




In Home Screen, (Phone)








Outgoing Call Barring





Tap outgoing restriction



- Outgoing Call Barring is set.
 - To disable Outgoing Call Barring, Tap Stop Barring of Outgoing Call.

Using Incoming Call Barring


Restrict incoming calls and SMS.




In Home Screen, (Phone)








Incoming Call Barring



Tap incoming restriction



- Incoming Call Barring is set.
 - To disable all Incoming Call Barring, Tap Stop Barring of Incoming Call.

Phone Number



Checking Your Phone Number


Checking Your Phone Number



In Home Screen, (Settings)



About phone



Your phone number appears below "Phone number (sim slot 1)" / "Phone number (sim slot 2)" field.

Using Contacts

Save phone numbers, mail addresses, etc. to Contacts.

Operation when logged in to a Google account is described as an example.



Adding New Contacts

Contacts Cautions

Information saved in Contacts may be lost or changed if Internal Battery is left uncharged for a long period. Accident or malfunction may also cause loss or change to information. It is recommended that you keep a separate copy of contacts and other important information. SoftBank Corp. is not responsible for any damages from lost or changed contacts.


Adding New Contacts



In Home Screen, (Google)



(Contacts)



Contacts appear.

3


+



■ If confirmation appears, follow onscreen instructions.



Enter items Save



Contact is added.

Saving Contacts from Dialing Screen

Save a number entered in dialing screen directly to Contacts.

In Home Screen, (Phone) Tap dialpad to enter number to save Create

new contact Enter each item Save

Tap More details More fields to enter other items for contact.

Sending Messages (+Message)



Sending New Messages

Sending New Messages



In Home Screen, (+Message)



Message












New message






Tap destination



- Message window opens.
 - To send to a phone number/email address not saved in contacts, Tap destination entry field at top of Display Enter phone number/email address Add and create message.



Tap message entry field





Enter message



Message is sent.

Using Gmail

Use Google's webmail service. Use this service to exchange email.



Creating/Sending Mail




In Home Screen, (Google)






(Gmail)



🏁 Mail list opens.

3


Compose




Mail composition window opens.



Enter recipient/subject/mail text� ▶



Message is sent.



Using Chrome™

Use Chrome simply by entering words to search and URLs.



Adding Bookmarks



TLS (Transport Layer Security) is a protocol for encrypting sent/received data. While in a screen connected by TLS, data is encrypted to safely send/receive private information, credit card numbers, corporate secrets, etc., and provide protection against online threats (eavesdropping, falsification, impersonation, etc.).

TLS Cautions

When opening a secured page, users must decide as their responsibility whether or not to open the page with use of TLS. SoftBank Corp. and the Certification Authorities Symantec Website Security G.K. and Cybertrust make no guarantees whatsoever to users regarding security of TLS.

Using Chrome



In Home Screen, (Chrome)



Chrome opens.

■ If confirmation appears, follow onscreen instructions.


2

Tap entry box at top





Enter words to search or URL



Search results appear or a Website opens.

Opening New Tabs

Open several tabs to switch between Websites easily.

In Chrome, 😧 New tab

■ To switch between tabs, Tap ② next to entry field at top of Display and Tap tab (number in icon indicates opened tabs).

Adding Bookmarks



In Home Screen, (Chrome)



Chrome opens.



Show Website to add




3

:










Current Website is added to Bookmarks.



Capturing Still Images/Videos

Capturing Still Images



Capturing Videos



Capturing Still Images/Videos

File Format for Still Images

File formats for still images are JPEG.

File Format for Videos

File format for videos is MP4.

Camera Cautions

If Lens Becomes Dirty

Fingerprints/smudges on lens prevent capturing of clear still images/videos. Wipe lens with a soft cloth beforehand.

Avoid Exposure to Direct Sunlight

Be careful not to expose lens to direct sunlight for long periods. May discolor color filter and affect color of images.

Flash/Photo Light Warning

Do not shine Flash/Photo Light close to eyes. Do not look at Flash/Photo Light directly while in use. Do not shine Mobile Light at other people's eyes. May affect eyesight, etc.

Capturing Still Images



In Home Screen, (Camera)



Viewfinder appears.

- If confirmation appears, follow onscreen instructions.
- Alternatively, Press Power Key twice, or in Lock Screen, Touch & Hold to quick-activate Camera.
- If there is no operation on Viewfinder, Camera operation ends.

2

Swipe (Flick) Viewfinder to switch to "PHOTO" Viewfinder



■ Swipe (Flick) up or down in a landscape viewfinder, or left or right in a portrait viewfinder.



Aim Camera at subject Check Viewfinder, then O



Shutter clicks and still image is saved.

Capturing Videos



In Home Screen,

(Camera)



Viewfinder appears.

- If confirmation appears, follow onscreen instructions.
- Alternatively, Press Power Key twice, or in Lock Screen, Touch & Hold to quick-activate Camera.
- If there is no operation on Viewfinder, Camera operation ends.

2

Swipe (Flick) Viewfinder to switch to "VIDEO" Viewfinder



■ Swipe (Flick) up or down in a landscape viewfinder, or left or right in a portrait viewfinder.



Aim Camera at subject Check Viewfinder, then



- Video capturing starts.
 - To pause, Tap or to resume, Tap .

4

To stop recording,



Video capturing stops and video is saved.

Viewing Still Images/Videos (Photos)



Showing Still Images/Videos

Showing Still Images/Videos

Show captured or downloaded still images/videos. Supported file formats with Photos are as follows.

Туре	File Format
Still image	BMP, GIF, HEIC, ICO, JPG, PNG, TIFF, WEBP, some Raw files
Video	3GP, 3G2, ASF, AVI, DIVX, M2T, M2TS, M4V, MKV, MMV, MOD, MOV,
	MP4, MPG, MTS, TOD, WMV




In Home Screen, (Photos)



Still image/video list opens.



Tap still image/video





Still image/video window opens.

- Tap still image/video window to show/hide menu and other icons.
- Flick still image/video window up to show captured date & time.
- To select other files, in still image/video window, select file again or Flick still image/video window left or right.

Zooming In or Out Still Image

In still image window, Tap Display twice or Pinch

Applications



Setting Required Permissions for Applications

Setting Required Permissions for Applications

Set the operation of applications when activating for the first time.

The type and content of a confirmation differs with the application. Activating (Music) for the first time is described as an example.

■ An application may not function correctly if permission to use it was not set.




In Home Screen, (Music)






ALLOW



- Settings are complete.
 - Shown setting items depend on the function having permission set.
 - For several functions, continue in the same way.



Adding Applications

Download a variety of applications (free/paid) from Google Play™. Change the setting of downloaded applications to enable manual or automatic updates. Log in to your Google account beforehand.

- Installing Free Applications
- Purchasing Paid Applications
- Updating Applications

Installing Applications

Many different kinds of applications can be installed on handset from Google Play (provided by Google LLC). SoftBank Corp. is not responsible in any way for user-installed applications (quality, reliability, legality, fitness for a purpose, credibility, accuracy, etc.) or resulting malfunctions (viruses, etc.).

Installing Free Applications




In Home Screen, (Play Store)



- Google Play appears.
 - If confirmation appears, follow onscreen instructions.
- 2

Tap free application



3

Install



- Application is downloaded and installed.
 - If confirmation appears, follow onscreen instructions.

Purchasing Paid Applications




In Home Screen, (Play Store)



- 🔀 Google Play appears.
 - If confirmation appears, follow onscreen instructions.
- 2

Tap paid application



3

Tap amount



■ If confirmation appears, follow onscreen instructions.







Application is downloaded and installed.

■ If confirmation appears, follow onscreen instructions.

ģ

Purchased Applications

Payment

Pay only once. Redownloads of uninstalled applications are free of charge.

On Other Android™ Devices

Install an application on any Android device under the same Google account for free.

Requesting Refunds

Refund is possible within a limited time. By requesting a refund, the application is deleted and the charge is cancelled. A refund request is valid only once per one application.

In Google Play, Tap account icon at right of search bar Manage apps & device Manage Tap application for requesting a refund Refund Request refund

Purchasing Applications

Purchase applications at your own risk. SoftBank Corp. is not responsible for any