

Motion Detector

Ouick Start Guide 2024

Door.com




Thank you for choosing **DOOR** products!

At **DOOR** we're reinventing how we live. Through the foundation of access control business, we serve the Honest Day's Worker-the builder, property manager, contractor, driver, and in-home service provider-that keeps the world running smoothly.

These individuals are the cornerstone of vital services such as housing, transportation, cleaning, dog walking, and more. They deserve access to technology and products that empower them to provide top-notch experiences to their customers while maximizing the economic benefits of their hard work.

DOOR is proud to stand by and innovate for our Honest Day's Worker every day!



Please note the following user quide icons:



Very important information, please read carefully



Good to know, helpful tips for installation



This device connects to the internet via DOOR Field Station, and it does not connect directly to your WiFi or local network. In order for remote access to the device from the app, and for full functionality, a DOOR Field Station is required.

This guide assumes the DOOR App has been installed on your smartphone and a Field Station is installed and online.

C In the Kit







Motion Detector

2 x AAA Batteries (Installed)







Quick Start Guide



The following items may be required:







Double-Sided Mounting Tape

Rubbing Alcohol Pads

Get to Know Your Device







LED Behaviors



Blinking Red Once, then Green Once Device Start-Up



Blinking Red And Green Alternately Restoring to Factory Defaults

Blinking Green



Connecting to Cloud or Functioning Normally





Blinking Red Once Device Alerts



Fast Blinking Red Every 30 Seconds Low Battery; Replace Batteries



Add Device To DOOR App

If you are new to DOOR, please install the DOOR App on your phone, if you have not already.





Open the app and tap Sign up for an account. You will be required to provide a username and a password. Follow the instructions, to set up a new account. Allow notifications, when prompted. Log in to the app using your new username and password. If you already have an account, please ensure you log in using that one.

Ensure you install the Field Station within the app before proceeding to install the Motion Detector.

1 In the Home screen of the app, tap on the card located in the top right.



Tap on the "Add device" icon.



Add Device To DOOR App

3 Approve access to your phone's camera, if requested. A viewfinder will be shown on the app.



- 4 Hold the phone over the QR code so that the code appears in the viewfinder. If successful, the next steps will be displayed.
- 5 Follow the on-screen instructions in the DOOR App, which will guide you step by step.





Turn on the Motion Detector by briefly pressing the SET button, until you see the LED flash red then green.



Sensor Location Considerations:

Before installing your **Motion Detector**, please consider the following:

- 1. Passive-Infrared (PIR) Motion Detectors such as your Motion Detector detect movement within a specific area by sensing the infrared energy emitted from a body, causing a temperature change, as it moves across the sensor's field of view.
- 2. The **Motion Detector** is intended for indoor use. As the sensor uses infrared sensing technology, ambient temperature and the temperature of the detection target (such as people) is a factor. Hot, outdoor environments, even if under cover (such as a car port) will result in undesired behaviors such as false alarms or failure to detect motion.
- 3. Do not use the sensor in extremely hot or steamy environments, such as in a boiler room or near a sauna or hot tub.
- 4. Do not aim your **Motion Detector** at, or place the sensor near sources of heat, such as space heaters, or near sources of rapid temperature change, such as heating or cooling grilles or registers.
- 5. Do not aim your **Motion Detector** at windows, fireplaces, or other sources of light. For example, at night, lights from a vehicle shining through a window directly into the Door Motion Detector may cause a false alert.
- 6. Mount the **Motion Detector** to a rigid surface, free of vibration.

- 7. Placement of the **Motion Detector** in high traffic areas will reduce the life of the batteries.
- 8. Pets such as cats and dogs can set off the **Motion Detector**. If you have pets and are using the sensor for security applications, consider wall-mounting your sensor, which provides more control over the detection region.
- The Motion Detector best detects motion moving across its field of view, as opposed to moving directly towards it.
- 10. The **Motion Detector** has a 360° cone of coverage (viewed from directly below, sensor facing down), with a 120° coverage profile (viewed from the side of the sensor). Detection range is approximately 20 feet (about 6 meters).
- 11. If mounting your **Motion Detector** on the ceiling, the ceiling height should be no more than 13 feet (about 4 meters).
- 12. If wall-mounting your **Motion Detector**, the suggested mounting height is approximately 5 feet (about 1.5 meters).
- 13. The **Motion Detector** has an integral magnet that allows for mounting to the metal mounting plate or to a metal surface. The metal plate has mounting tape, that allows it to be secured to a suitable surface.
- 14. We recommend you test the proposed location of your **Motion Detector** before permanently installing it. This can be easily done with painter's tape, by taping the mounting plate to the proposed location, allowing for testing the sensor, as explained later.

15. The Motion Detector does not have pet immunity features. One method to prevent false alerts caused by pets includes avoiding the use of this sensor in areas the pets may occupy while the sensor is armed. Wall-mounting your sensor higher on the wall, so that the coverage 'cone' does not include the floor of the room, is another method. Adjusting the Door Motion Detector's sensitivity to low may help (but it may slow response time, or prevent operation entirely). Large dogs and/or pets that climb up on furniture will likely cause a false alert, if in the coverage region of your Motion Detector. A trial & error process of testing the proposed sensor location and settings, with your pet, is recommended.



The mounting tape is extremely adhesive and can be very difficult to remove later without damage to the surface (removing paint, even drywall). Use care when installing the mounting plate on delicate surfaces.

Install and test the Door Motion Detector:

1. If mounting the **Motion Detector** to a metal surface, you can do so at this time. Otherwise, you may either secure the mounting plate to the surface, using painter's tape (to test the location first), or you can secure the mounting plate to the surface. Do so by first cleaning the installation area, using rubbing alcohol or similar to remove all dirt, oil or grease from the mounting surface. Remove the backing from the mounting tape, then place the mounting plate at the desired location, tape side to the mounting surface. Press and hold for at least 5 seconds.

- 2. Place the **Motion Detector** on the mounting plate. Ensure it has a good magnetic connection to the plate.
- 3. Next, test the sensor. It is very important that you test the sensor, as realistically as possible, to ensure it works as required for your application. With your phone in-hand, using the app, refer to the Motion Detector status as you walk through the coverage area. You may need to adjust the location of the sensor and/or sensitivity.
- 4. When the sensor responds as desired, if temporarily installed, you may permanently install it as noted in step 1.



Please note! A **Motion Detector** is not a guarantee of security or protection against intrusion into your home or business. As noted, Motion Detector can be prone to false alarms under certain conditions, and they may also not respond as desired under certain conditions.



FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction



Contact Us

DOOR

Support

support@door.com

Door Technologies, Inc.

www.door.com

1220 N Price Rd

STF 2

Olivette, MO 63132

Copyright © 2024

Door Technologies, Inc.

All rights reserved.

To install and configure devices download the **DOOR App:**



