
# INSTRUCTION FOR DC MOTOR CEILING FAN REMOTE CONTROL



## INNOVATION · ENERGY-SAVING · FUTURE

Warning: changes or modificatitions to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.


This device conplies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.


### WIRING SCHEMATIC DIAGRAM FOR RECEIVER

### Installation Diagram of Receiver



- Adopt RF wireless digit emission technique, biunique controlled, coincident code rate is less than one millionth. (Emitter and receiver must be sent back to
  actors for maintenance if damaged.)
- Receiver can be controlled by any angles of the emitter in prescriptive space, unrestricted by direction With the memory function, the controller can save the status(light and direction) while the supply power OFF and resume to the original after reload the power supply.

### FUNCTION INSTRUCTION OF EMITTER



- Turn off the fan and the light.
- ② Turn on/off the Light. Long press 2s to matching code with the receiver.
- 3 Turn on the Fan and set up the fan's speed.
- 4 Turn off the fan
- (5) Long press 2s to switch the fan to Forward or Reverse. (When the fan is working.)
- ⑥ Activate the Natural wind MODE. (When the fan is working.)
- ⑦ Set up the Timer for the fan.Long press 2s to cancel the Timer. (When the fan is working.)
- ® BATTERY:1.5V x 2 AAALR03.

#### Remark:

According to the different models, it will has a little different, please in kind prevail.

#### KINDLY REMINDES:

- Press and hold the transmitter's Pair code "Light ON/OFF" while the receiver is powering on within 5 seconds. After hearing "DIDI" for three long rings,
  the learning code pairing is successful and can work normally. If not, please turn off the power and restart the above operation. (Note: Do not
  accept learning code pairing after powering for more than 5 seconds.)
- When the emitter cannot control the receiver, please check the battery switch touching normally or not, correction of the positive and negative, full or empty of the power.
- 3. Low voltage of battery will affect the sensitivity of the emitter and the signal reception accordingly (the indicated light will flash out its warning when the battery get low voltage), must replace if the battery is getting low voltage.
- 4. Please take out the battery from the emitter when leaving unused for long time.
- 5. When installing the fan, the fan ceiling cover don't press the antenna(or other wire), it is easy to breakdown the wire and short-circuited.
- 6. Supporting 24W lighting power at maximum.
- PS: please connect the ground wire correctly, otherwise it may cause the light micro-light or flash.