

FP.26.02 User Guide

Appearance



Specification

1. Part Number: FP.26.02;
2. Working Voltage: 29V;
3. Working Current: 5mA @29V;
4. Operation Temperature:-20~55℃;
5. Storage temperature: -45~85℃;
6. RF Frequency Range: 2.402~2.480GHz;
7. RF Modulation: GFSK;
8. Housing Material: ABS 765A, 94V-0;

Interface Description



1. Status Indication: one color, two different status
Status 1: White light flashing, when bluetooth broadcast;
Status 2: White light on, when Bluetooth is linked by smart phone;

2. APP



苹果 IOS




安卓（中国大陆）



安卓（其他地区）

Instructions

1. Connect the Bluetooth plugin first, then power on the main control box, follow the steps below to connect Bluetooth hotpot.




2. Sign up and sign in



TEST ID: 13456397315 PW: a12345678

Switch to Bluetooth, select SleepBT-xxxxxxx , direct selection save



3. Select device, ,hotpot and connect it.Connection succeed.





Note: If you have already connected Bluetooth successfully, but you still cannot operate the bed via this app, then you can try to power off the main control box and repower it, or exit the app then re-enter.

4. After successful pairing, operate the main interface, you can operate the control box.

FCC CAUTION:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment, this transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. The equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

ISED WARNING:

This device complies with Innovation, Science and Economic Development Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible

d'encompromettre le fonctionnement.

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

Les communications effectuées au moyen de cet appareil ne sont pas nécessairement protégées des indiscretions.

The equipment complies with ISED radiation exposure limits set forth for an uncontrolled environment, this transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. The equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

Déclaration d'exposition aux radiations:

Cet équipement est conforme aux limites d'exposition aux rayonnements ISED Canada établies pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec un minimum de 20cm de distance entre la source de rayonnement et votre corps.