

tuya **CAMERA**



QUICK GUIDE

Thank you for using smart camera

Specification

Power supply: 3.3V/5V/5V
 Monochrome video feed, you can hear the voice while viewing the image.
 321 camera lens, 1080P resolution supported by more 321 and 1080P
 Reset button: Long press for 5 seconds to reset the camera and restore factory settings

Install the APP

This APP is compatible with iOS and Android systems. Search for Tuya Smart or Smart Life in the APP Store or Android Market.
 Download APP: Scan the QR code of the APP below and complete the installation.
 Register and log in: Open the APP and register and log in as prompted.




Scan code to download App

Router Settings

This product only supports routers in the 2.4GHz band, but does not support routers in the 5GHz band. See the parameter before configuring WPA. See the relevant parameters of the router and do not input the WPA password of 16-byte characters such as @#123456789. Please use WPA configuration from your phone and device as close as possible to the router to avoid network configuration.



Please keep the WIFI network working

1. Register

Registration
 If you do not already have an App account, you can register an account or log in with an SMS verification code. For an introduction of the registration process, see current and next pages. Click "Register" to enter the privacy policy page of APP. Click "Agree" to enter the mobile phone number or email registration page.



Login
 If you already have an account, you can skip creating a new one and click "Login" to go to the login page.
 (1) The system automatically selects the current country/region, or you can manually select the country/region.
 (2) Enter your registered mobile phone number or email address, and enter your password to log in to the system.

Add equipment



Make sure you are available and connected to the Internet.
 Open the APP and click "+" in the upper right corner of the main screen, see Figure 3(1). Select "Security Camera" and click "Smart Camera" in Figure 3(2). Adding camera equipment. Then click "New" (Figure 3(3)).
 Find the power cable interface of the device, insert the power cable, switch on the power supply, and the device is started.



Click the WiFi account password: Click "Next" as shown in Figure 3(4). The system will be powered on the camera and capture a self-checking code after the camera is powered on, and the device will start. When you have the camera prompt, the mobile APP will generate a QR code. Use the QR code to enter the camera and the camera is added. (5) Scan away from the device as shown in Figure 3(5).






When you hear the "beep" sound, the camera will make a sound that "beep" sound and wait for the connection (as shown in Figure 3(6)). The device is added successfully (as shown in Figure 3(7)). Select the device name and room name.

Engagement sharing

The camera can only be connected to one phone at a time, but other family members can share the Tuya Smart app. While ensuring other family members to log in to APP accounts. The default password for sharing is as follows: Open Settings and click Share Device and a share. Enter the pin account.

Q&A

Q1: What should I do if the camera cannot be connected during the process?
 If you don't hear the beep after the camera is off and is completed, you can press the reset button for 5 seconds to reset the camera. If the camera is not connected, you can try the camera again and you can use the mobile phone to configure the network again.
 * The camera only supports 2.4GHz Wi-Fi, please make sure that the camera is connected to 2.4GHz Wi-Fi when connecting the camera. You will have different access points, please follow the "Voice prompt" to find corresponding devices.

Q2: How to make my camera connect to another Wi-Fi?
 If the camera is in the camera and the Wi-Fi you want to connect to is not connected at the same time, you can click on the camera in the settings menu. Click Remove Device to configure the network in the new Wi-Fi environment. If the camera is disconnected from the current Wi-Fi, the application will prompt you to "Device disconnected". Click "Troubleshoot" to connect to another Wi-Fi, or remove the camera from the app. (Through "Remove device" the camera is in the Wi-Fi you want to connect to).

Q3: After installing the camera, how to use it?
 To record all data, why is there a limit on the camera's storage?
 * Camera has 32GB of storage in internal, front, please insert the SD card. If the camera has 32GB of storage, it will be replaced with another SD card. If the camera has 32GB of storage, it will be replaced with another SD card. If the camera has 32GB of storage, it will be replaced with another SD card.

Q4: Why can't I see my phone camera notification?
 * Make sure you have APP to send you notifications to your mobile device. Settings: Under Settings, you have push notification, please turn on all options. If you have not the camera, please go to the phone's settings to turn on all options. If you have not the camera, please go to the phone's settings to turn on all options.

Q5: When I think the camera is not working, how to reset it?
 * Network: Reset the camera and the camera is not working. Please check the network connection. If the camera is not working, please check the network connection. If the camera is not working, please check the network connection. If the camera is not working, please check the network connection.

Q6: Why is there a limit on the camera's storage?
 * Camera has 32GB of storage in internal, front, please insert the SD card. If the camera has 32GB of storage, it will be replaced with another SD card. If the camera has 32GB of storage, it will be replaced with another SD card. If the camera has 32GB of storage, it will be replaced with another SD card.

Q7: Why does the camera make noise?
 * When the camera is working, the camera will make a small noise, and then the camera will record the camera's storage. Please check the camera's storage. Please check the camera's storage. Please check the camera's storage.

Warranty

One: When purchasing the product, please read the following warranty terms carefully.
 To ensure that the product has a valid warranty.
 1. Name: Please provide the name and address of the purchaser.
 2. The warranty card shall be provided at the same time.
 3. The warranty card is valid if the information is true and correct.
 4. Product warranty period for one year, during the warranty period, both the product and the original device quality in production problems, the company will provide free maintenance and parts replacement.

Two: The following causes of product damage can not be held normally, not within the scope of warranty.
 1. Damage caused by fire, flood, lightning, etc. in accordance with the instructions.
 2. All non-manufactured product damage.
 3. Not approved by the company maintenance, modification or product loading, other matters.
 4. Aging, corrosion and oxidation on the surface of the product.

Three: After the warranty expires, the user can still get the company to provide maintenance services, but need to pay the corresponding fee.

Warranty card

The user data

Product model	
Product SN code	
Purchase date	
Customer's name	

Records of the warranty

Date	Fault and handling methods	Completion date	Customer signature

FCC Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help important announcement

Radiation Exposure Statement

To comply with FCC RF exposure compliance requirements, this grant is applicable to only mobile configurations. The antennas used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter.