IQ11_Hardware Design

LTE Cat1 Module

Version: V1.0.0

Date: 2024-12-04

Notice

Some features of the product and its accessories described herein rely on the software installed, capacities and settings of local network, and therefore may not be activated or may be limited by local network operators or network service providers. Thus, the descriptions herein may not exactly match the product or its accessories which you purchase. Shanghai Mobiletek Communication Ltd reserves the right to change or modify any information or specifications contained in this manual without prior notice and without any liability.

Copyright

Copying of this document and giving it to others and the using or communication of the contents thereof, are forbidden without express authority. Offenders are liable to the payment of damages. All rights reserved in the event of grant of patent or the registration of a utility model or design. All specification supplied herein are subject to change without notice at any time.

DISCLAIMER

ALL CONTENTS OF THIS MANUAL ARE PROVIDED "AS IS". EXCEPT AS REQUIRED BY APPLICABLE LAWS, NO WARRANTIES OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDINGBUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE MADE IN RELATION TO THE ACCURACY, RELIABILITY OR CONTENTS OF THIS MANUAL.TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT SHALL OUR BE LIABLE FOR ANY SPECIAL, INCIDENTAL, INDIRECT, OR CONSEQUENTIAL DAMAGES, OR LOSS OF PROFITS, BUSINESS, REVENUE, DATA, GOODWILL SAVINGS OR ANTICIPATED SAVINGS REGARDLESS OF WHETHER SUCH LOSSES ARE FORSEEABLE OR NOT.

Version History

Date	Version	Modify records	Author
2024-12-04	V1 0 0	Initial	rc.tian,
2024-12-04	V1.0.0		rc.dong

CONTENT

1 Introduction	5
1.1 Hardware Diagram	5
1.2 Main Features	5
1.3 Specifications	6
1.4 Interfaces	7
1.5 Peripherals Features	7
2 Package Information	8
2.1 Pin Configuration	8
2.2 Pin Definition	۵
2.3 Package Information	9 1/1
2.3.1 Dimensions	14 1/1
2.3.2 Product Labeling	
2.3.3 Module Size	
2.3.4 Recommend Pad	16
	10
3 Interface Circuit Design	17
3.1 Power Section	17
3.1.1 Power Supply	17
3.1.2 Hardware Power On	
3.1.3 Hardware Reset	20
3.2 (U)SIM Interface	21
3.2.1 Pin Description	21
3.2.2 (U)SIM Interface Application	21
3.3 USB Interface	
3.3.1 Pin Description	23
3.3.2 Firmware Upgrade	24
3.4 UART Interface	24
3.4.1 Pin Description	24
3.4.2 UART Interface Application	25
3.5 Status Indication Interface	27
3.5.1 Network Indicator Control Circuit	27
3.5.2 Network Indication Pin State Description	27
3.6 I2C Interface	27
3.7 Interactive Application Interface	28
3.7.1 Pin Description	28
3.7.2 Interface Application	
3.8 LCD Interface	29
3.9 Digital Audio Interface	29
3.10 ADC Interface	30
4 Electrical Characteristics	

4.1 Electrical Characteristic	31
4.2 Temperature Characteristic	
4.3 Absolute Maximum Power	
4.4 Recommended Operating Conditions	
4.5 Power Consumption	
4.6 Power Sequence	
4.7 Digital Interface Characteristics	
4.8 ESD	35
5 RF Features	
5.1 RF Main Features	
5.2 Antenna Circuit Design	
5.3 Antenna Design	
6 Storage, Production and Package	
6.1 Storage	
6.2 Production	42
6.2.1 Module Confirmation and Moisture	42
6.2.2 SMT Reflow Attentions	
6.2.3 SMT Stencil Design and the Problem of Less Tin Soldering	44
6.2.4 SMT Attentions	44
6.3 Packaging Information	46
7 Safety Information	

FCC warning message

According to the definition of mobile and fixed device is described in Part 2.1091(b), this device is a mobile or fixed device.

And the following conditions must be met:

This Modular Approval is limited to OEM installation for mobile or fixed applications only. The antenna
installation and operating configurations of this transmitter, including any applicable source-based time averaging
duty factor, antenna gain, and cable loss must satisfy MPE categorical Exclusion Requirements of 2.1091.
 The EUT is a mobile or fixed device; maintain at least a 20 cm separation between the EUT and the user's body

and must not transmit simultaneously with any other antenna or transmitter.

3. A label with the following statements must be attached to the host end product: This device contains FCC ID: 2AQRM-IQ11 . This module must not transmit simultaneously with any other antenna or transmitter

4. The host end product must include a user manual that clearly defines operating requirements and conditions that must be observed to ensure compliance with current FCC RF exposure guidelines.

For portable devices, in addition to the conditions 3 through 6 described above, a separate approval is required to satisfy the SAR requirements of FCC Part 2.1093 If the device is used for other equipment that separate approval is required for all other operating configurations, including portable configurations with respect to 2.1093 and different antenna configurations. For this device, OEM Integrator must be provided with labeling instructions of finished products.

Please refer to KDB784748 D01, section A.6 last two paragraphs: A certified modular has the option to use a permanently affixed label, or an electronic label. For a permanently affixed label, the module must be labeled with an FCC ID - Section 2.926 (see 2.2 Certification (labeling requirements) above). The OEM manual must provide clear instructions explaining to the OEM the labeling requirements, options and OEM user manual instructions that are required.

For a host using a certified modular with a standard fixed label, if (1) the module's FCC ID is not visible when installed in the host, or (2) if the host is marketed so that end users do not have straightforward commonly used methods for access to remove the module so that the FCC ID of the module is visible; then an additional permanent label referring to the enclosed module: IQ11 "Contains Transmitter Module FCC ID: 2AQRM-IQ11" The host OEM user manual must also contain clear instructions on how end users can find and/or access the module and the FCC ID.

Statement

The module is limited to OEM installation only. The OEM integrator is responsible for ensuring that the end-user has no manual instruction to remove or install module. OEM host shall implement a Class II Permissive Change (C2PC) or a new FCC ID to demonstrate complied with FCC standard. The OEM integrator is still responsible for testing their end-product for any additional compliance requirements required with this module installed. The final end product must be labeled in a visible area with the following: "Contains FCC ID 2AQRM-IQ11" The final host / module combination may also need to be evaluated against the FCC Part 15B criteria for unintentional radiators in order to be properly authorized for operation as a Part 15 digital device.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the manufacturer could void the user' s authority to operate the equipment.

To ensure compliance with all non-transmitter functions the host manufacturer is responsible for ensuring compliance with the module(s) installed and fully operational. For example, if a host was previously authorized as an unintentional radiator under the Supplier's Declaration of Conformity procedure without a transmitter certified module and a module is added, the host manufacturer is responsible for ensuring that the after the module is installed and operational the host continues to be compliant with the Part 15B unintentional radiator requirements.

Class B digital device

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Manual Information to the End User

The OEM integrator has to be aware not to provide information to the end user regarding how to install or remove this RF module in the user's manual of the end product which integrates this module. The end user manual shall include all required regulatory information/warning as show in this manual.

Summarize the specific operational use conditions

The IQ11 radio module is designed specifically for control applications in the host product intelligent lightingseries, model: IQ11. The radio module is not intended to be sold as a standalone product. IQ11is applicable to oil platforms, cars, trans, boats and aircraft. IQ11radio module must not coexist or work in conjunction with anyother antenna or transmitter.

Trace antenna designs

Please refer to Chapter 4

Typical antenna types include monopole, PIFA, dipole and PCB(Trace antenna). The modular transmitter is certified based on the conducted output power, a change in antenna gain is possible through a Class II permissive change by contacting the module grantee, or filling for a change in FCC ID.

Important Note

In the event that these conditions cannot be met (for example co-location with another transmitter), then the FCC authorization is no longer considered valid and the FCC ID cannot be used on the final product. In these circumstances, the OEM integrator will be responsible for re-evaluating the end product (including the transmitter) and obtaining a separate FCC authorization.

Note EMI Considerations

KDB 996369 D04 Module Integration Guide has been considered as "best practice# for RF design engineering testing and evaluation of non-linear interactions which can generate additional non-compliant limits due to module placement to host components or properties.

For standalone mode, KDB 996369 D04 Module Integration Guide was referenced, and simultaneous mode considered for the host product to confirm compliance.

How to make changes

Only Grantees are permitted to make permissive changes, it is recommended that module manufactures provide contact information and some guidance to host providers. Each host product model will require AC Powerline Conducted Emissions, Spurious Radiated Emissions, and conducted output power/EIRP verification. A C2PC will be completed for the integration into additional host models.

Information on test modes and additional testing requirements

Data transfer module demo board can control the EUT work in RF test mode at specified conditions. This radio module must not be installed to co-locate and operating simultaneously with other radios in the host system except in accordance with FCC multi-transmitter product procedures. Additional testing and equipment authorization may be required operate simultaneously with other radio.

Additional testing, Part 15 Subpart B disclaimer

The host product manufacturer is responsible for compliance with any other FCC rules that apply to the host not covered by the modular transmitter grant of certification. The final host product still requires Part 15 Subpart B compliance testing with the modular transmitter installed.

1 Introduction

The IQ11 module is a Cat1 module for LGA package, with stable and reliable performance. It can well meet customer's requirements for cost-effective, low-power applications. It suits to IoT areas, such as PoC, Mobile payment, security and alarm systems, on-board vehicle, DTU, asset tracking, sharing economy, etc.

1.1 Hardware Diagram



Figure 1.1-1 Functional Block Diagram

1.2 Main Features

• CPU

ARM Cortex-M3@204MHz

• Flash

IQ11: >1MB SRAM+4MB Nor Flash

• Frequency bands

FDD-LTE: B2/B4/B5/B12/B13/B66/B71

Output Power

LTE: 22dBm±3dB

• Sensitivity

Table 5.1-3

Data transmission

LTE-FDD: Max. DL 10Mbps, Max. UL 5Mbps

• Power consumption

LTE Standby: 0.85mA @3.8V/AT+ECPMUCFG=1,2

1.3 Specifications

- Supply Voltage Range: 3.3~4.2V (typ3.8V)
- Dimensions: 15.8mm * 17.7mm * 2.35mm
- 109-pin LGA
- Operation Temperature Range: -40°C~+85°C
- Storage Temperature Range: -45°C~+90°C
- Weight : About 1.3g

1.4 Interfaces

- GPIO
- USB2.0
- ADC
- PCM
- (U)SIM: Support 1.8V/3.0V
- UART
- Key
- Antenna

1.5 Peripherals Features

• LCD: SPI Interface 320*240

2 Package Information

2.1 Pin Configuration



Figure 2.1-1 IQ11 Pin (Top View)

2.2 Pin Definition

The IQ11 module has a total of 109 pins, and the specific functions of the interfaces are as follows.

Pin NO.	Pin name	Туре	Function Description	Power Domain	State ⁽¹⁾
			LCC PIN		
1.	GND	G	Ground		GND
2.	RESERVED		Not connect		
3.	RESERVED		Not connect		
4.	RESERVED		Not connect		
5.	RESERVED		Not connect		
6.	RESERVED		Not connect		
7.	PWRKEY	DI	Power key button	1.8~2.3V	Open
8.	RESERVED		Not connect		
9.	ADC0	AI	ADC external input channel 0, 12bit	0.05~1.2V	Open
10.	GND	G	Ground		GND
11.	USIM1_DATA	DIO	USIM1 data	1.8V/3.0V	Open
12.	USIM1_RST	DO	USIM1 reset	1.8V/3.0V	Open
13.	USIM1_CLK	DO	USIM1 clock	1.8V/3.0V	Open
95.	GND	G	Ground		GND
14.	USIM1_VDD	PO	USIM1 output voltage	1.8V/3.0V	Open
15.	RESET_N	DI	System reset signal	1.25V	Open
16.	NET_STATUS	DO	Output PIN as LED control for network status	1.8V	Open
17.	MAIN_RXD	DI	Main UART receive data input	1.45V	Open
18.	MAIN_TXD	DO	Main UART transmit data output	1.8V	Open

Table 2.2-1 IQ11 Pin Description

19.	MAIN_DTR	DI	Main UART data terminal ready	1.2V	Open
20.	MAIN_RI	DO	Main UART ring indicator	1.8V	Open
21.	MAIN_DCD	DO	Main UART data carrier detect	1.8V	Open
22.	MAIN_CTS	DO	Main UART clear to send	1.8V	Open
96.	ADC1	AI	ADC1 external input channel , 12bit	0.05~1.2V	Open
23.	MAIN_RTS	DI	Main UART request to send	1.8V	Open
24.	VDD_EXT	PO	1.8V output voltage, output current up to 2mA	1.8V	Open
25.	STATUS	DO	Output PIN as operating status indicating of module	1.8V	Open
26.	I2S_MCLK	DO	I2S system clock	1.8V	Open
27.	GND	G	Ground		GND
28.	AUX_RXD	DI	Auxiliary UART receive data input	1.45V	Open
29.	AUX_TXD	DO	Auxiliary UART transmit data output	1.8V	Open
30.	PCM_CLK	DO	PCM interface clock	1.8V	Open
31.	PCM_SYNC	DO	PCM interface sync	1.8V	Open
32.	PCM_DIN	DI	PCM I/F data in	1.8V	Open
33.	PCM_DOUT	DO	PCM I/F data out	1.8V	Open
34.	GND	G	Ground		GND
35.	ANT_MAIN	ANT	Main Antenna		Open
97.	RESERVED		Not connect		
36.	GND	G	Ground		GND
37.	GND	G	Ground		GND
38.	DBG_RXD	DI	Debug UART receive data input	1.45V	Open
39.	DBG_TXD	DO	Debug UART transmit data output	1.8V	Open
40.	GND	G	Ground		GND
41.	GND	G	Ground		GND

42.	VBAT	PI	Power supply	3.3~4.2V	VBAT
43.	VBAT	PI	Power supply	3.3~4.2V	VBAT
44.	RESERVED		Not connect		
98.	RESERVED		Not connect		
			LGA PIN		
45.	GND	G	Ground		GND
46.	GND	G	Ground		GND
47.	GND	G	Ground		GND
48.	GND	G	Ground		GND
49.	LCD_RST	DO	LCD RESET signal	1.8V	Open
50.	LCD_SPI_OUT	DO	LCD SPI Data out	1.8V	Open
51.	LCD_SPI_RS	DO	LCD SPI Data /command selection	1.8V	Open
52.	LCD_SPI_CS	DO	LCD SPI chip-select	1.8V	Open
53.	LCD_SPI_CLK	DO	LCD SPI clock	1.8V	Open
54.	GPIO1	I/O	General-purpose input/output	1.8V	Open
55.	GPIO2	I/O	General-purpose input/output	1.8V	Open
56.	GPIO3	I/O	General-purpose input/output	1.8V	Open
57.	GPIO4	I/O	General-purpose input/output	1.8V	Open
58.	GPIO5	I/O	General-purpose input/output	1.8V	Open
59.	USB_DP	Ю	USB port differential data line		Open
60.	USB_DM	Ю	USB port differential data line		Open
61.	RESERVED		Not connect		
62.	USIM2_CLK	DO	USIM2 clock	1.8V	Open
63.	USIM2_RST	DO	USIM2 reset	1.8V	Open
64.	USIM2_DATA	DIO	USIM2 data	1.8V	Open
65.	USIM2_VDD	PO	USIM2 output voltage	1.8V	Open

66.	I2C_SDA	I/O	I2C data	1.8V	Open
67.	I2C_SCL	0	I2C clock	1.8V	Open
68.	RESERVED		Not connect		
69.	RESERVED		Not connect		
70.	GND	G	Ground		GND
71.	GND	G	Ground		GND
72.	GND	G	Ground		GND
73.	GND	G	Ground		GND
74.	RESERVED		Not connect		
75.	RESERVED		Not connect		
76.	RESERVED		Not connect		
77.	RESERVED		Not connect		
78.	LCD_TE	DO	LCD tearing effect	1.8V	Open
79.	USIM1_DET	DI	USIM1 detect pin	1.2V	Open
80.	RESERVED		Not connect		
81.	RESERVED		Not connect		
82.	USB_BOOT	DI	Force software download	1.8V	Open
83.	RESERVED		Not connect		
84.	RESERVED		Not connect		
85.	RESERVED		Not connect		
86.	RESERVED		Not connect		
87.	RESERVED		Not connect		
88.	GND	G	Ground		GND
89.	GND	G	Ground		GND
90.	GND	G	Ground		GND
91.	GND	G	Ground		GND

92.	GND	G	Ground		GND
93.	GND	G	Ground		GND
94.	GND	G	Ground		GND
99.	RESERVED		Not connect		
100.	RESERVED		Not connect		
101.	RESERVED		Not connect		
102.	RESERVED		Not connect		
103.	RESERVED		Not connect		
104.	GRFC2	DO	Generic RF Control 2	1.8V	Open
105.	GRFC1	DO	Generic RF Control 1	1.8V	Open
106.	RESERVED		Not connect		
107.	RESERVED		Not connect		
108.	RESERVED		Not connect		
109.	RESERVED		Not connect		

(1) Suggested status when not in use.

Notes: 1. The USB_BOOT (PIN82) pin must not be pulled up to high level before the module is successfully powered on.

2. The VDD_EXT can output 1.8V during sleep; the voltage domain of the remaining 1.8V/1.45V interfaces will be turned off when the module is asleep, while the voltage domain of the 1.2V interfaces can function normally when the module is asleep.

3. When the MAIN_RXD is enabled with the wake up function, the voltage domain of MAIN_RXD will change to 1.2V after the module is asleep.

Table 2.2-2	Pin Type	Description
-------------	----------	-------------

PI: POWER INPUT	PO: POWER OUTPUT
DI: DIGITAL INPUT	DO: DIGITAL OUTPUT
IO: INPUT OUTPUT	AI: ANALOG INPUT

ANT: ANTENNA

G: GROUND

2.3 Package Information

2.3.1 Dimensions

The IQ11 module mechanical dimensions are described as following figure (Top view, Side view, Back view).



Figure 2.3.1-1 Mechanical Dimensions (Top view, Side view, Back view)

2.3.2 Product Labeling



Figure 2.3.2-1 Label of the IQ11

Item	Description
А	Pin1 mark
В	company name
С	QR codeincluding IMEI number and SN number
D	SN number
E	IMEI number
F	Module name
G	The finished part number of the module
н	CE

2.3.3 Module Size



Figure 2.3.3-1 Module Size (Unit: mm)

2.3.4 Recommend Pad



Figure 2.3.4-1 Recommend Pad (Top view, Unit: mm)

3 Interface Circuit Design

3.1 Power Section

3.1.1 Power Supply

VBAT is the main power supply of the module, its voltage input range is 3.3V to 4.2V, and the recommended voltage is 3.8V. In poor network environments, where the antenna emits at maximum power, the module must choose a power supply that can provide at least 1.2A current capability. A low ESR (ESR= 0.7Ω) 100uF filter capacitor is recommended for the VBAT pin close to the module, and at the same time, it is recommended to add three (100nF, 33pF, 10pF) chip multilayer ceramic capacitors (MLCC) with the best ESR performance to VBAT respectively, and place the capacitors close to the VBAT pin. When connecting the module to an external power supply, VBAT requires star traces. The VBAT trace width should be no less than 1.2mm. In principle, the longer the VBAT trace, the wider the required trace width.

Considering various complex application scenarios of module, it is strongly recommended that module add TVS at VBAT to provide ESD/EOS protection for module power supply. It is recommended to choose VRWM=4.7V and PPP≥500W for TVS.

ð



Figure 3.1.1-1 Power Supply Circuit

Notes: When the module has no network, the RTC clock error of the module is relatively large, there will be a few minutes of error in 24 hours. If you want to get accurate time, you need to synchronize the network time.

If the voltage drop is not large, it is recommended to use LDO. LDO requires over-current capacity of more than 1.2A, because LDO is a linear buck, its transient response capacity is poor, and the front and rear terminals need to be equipped with a large amount of capacitance, to prevent high-power transmission when the voltage fluctuation is too large, may lead to reset or shutdown. The output voltage needs to be controlled at 3.8V.



Figure 3.1.1-2 LDO Power Supply Circuit

If the voltage drop is large, it is recommended to use DC/DC, the output current requirements of more than 1.2A, such as Figure 3.1.1-3 using DC/DC switching power supply, supplemented by a large capacity (more than 330uF), to ensure the normal operation of RF PA (power amplifier). The advantage of the reference design is that it can provide better transient current response, meet the working requirement of the module under the weak signal, and prevent the network drop or port restart caused by power shortage.



Figure 3.1.1-3 DC/DC Power Supply Circuit

3.1.2 Hardware Power On

Module 7-pin is the Power on key. Pulling down the PWRKEY at least 1s and then releasing, the module will boot. It is internally pull-up to 1.8V to 2.2V, and does not need to pull up externally.

There are two ways to shut down the module: 1. Use the AT command AT+POWEROFF to shut down the module and the shut down process takes about 3s to complete; 2. Pull down PWRKEY for more than 3s and then release to shut down.



Figure 3.1.2-1 Turn On Circuit

Notes: PWRKEY can be pulled down to the ground through a 0R resistor to achieve power-on and boot.

3.1.3 Hardware Reset

Module 15-pin is the hardware reset input. The module will reset hardware when it receives a 1s low level signal. It is internally pull-up to 1.25V, and does not need to pull up externally. RESET_N can be directly connected to the 1.8V~3.3V port of MCU. The module will not restart after reset.



Figure 3.1.3-1 System Reset

3.2 (U)SIM Interface

3.2.1 Pin Description

The IQ11 module supports dual (U)SIM cards single standby. Module's (U)SIM1 card (pin number: 11, 12, 13, 14) supports and can automatically detect 1.8V and 3.0V (U)SIM cards, (U)SIM2 card (pin number: 62, 63, 64, 65) only supports detecting 1.8V (U)SIM card.

The (U)SIM card interface signals are shown in Table 3.2.1-1.

Pin No.	Pin Name	ame Signal Description Further Description	
11	USIM1_DATA	(U)SIM1 card data pin	(U)SIM1 card data signal, two-way signal
12	USIM1_RST	(U)SIM1 card reset pin	(U)SIM1 card reset signal, output by the module
13	USIM1_CLK	(U)SIM1 card clock pin	(U)SIM1 card clock signal, output by the module
14	USIM1_VDD	(U)SIM1 card power	(U)SIM1 card power supply, output by the module
79	USIM1_DET	(U)SIM1 card hot-plug detection pin	(U)SIM1 card hot plug detection signal, input signal
62	USIM2_CLK	(U)SIM2 card clock pin	(U)SIM2 card clock signal, output by the module
63	USIM2_RST	(U)SIM2 card reset pin	(U)SIM2 card reset signal, output by the module
64	USIM2_DATA	(U)SIM2 card data pin	(U)SIM2 card data signal, two-way signal
65	USIM2_VDD	(U)SIM2 card power	(U)SIM2 card power supply, output by the module

Table 3.2.1-1	USIM Pin	Description
		•

3.2.2 (U)SIM Interface Application

The (U)SIM1 card signal group (pin numbers: 11, 12, 13, 14) and the (U)SIM2 card signal group (pin numbers: 62, 63, 64, 65), on the line near the (U)SIM card seat, please note the need to add ESD protection devices when designing.

In order to meet the requirements of 3GPP TS 27.005 protocol and EMC certification, the proposed (U)SIM card is arranged near the module (U)SIM card interface, and avoid to layout too long resulting in serious waveform distortion, affecting the signal integrity. USIM_CLK and USIM_DATA signals are recommended to be protected. Paralleling a 1uF capacitor between GND and USIM_VDD, it can filter out the interference of radio frequency signals.



Figure 3.2.2-1 (U)SIM Circuit



3.3 USB Interface

3.3.1 Pin Description

The USB interface conforms to the USB2.0 specification and electrical characteristics. It supports full-speed and high-speed modes. The data exchange between the main processor (AP) and the module is mainly completed through the USB interface. The module's USB only supports slave mode.

The USB is mainly used for data transmission, firmware update, module program testing and send AT command. The USB_DM/DP differential impedance need to be controlled at 90ohm ±10%, and it should be protected up and down, and can't be crossed with other lines. The ESD device capacitance on USB_DM/DP is recommended to be less than 3pF. USB circuit is as follow.



Figure 3.3.2-1 USB Application Circuit

Notes: If you use the serial port communication, the USB_DM/DP reserved test points respectively in order to firmware update. If USB_DM/DP is used to communicate with the MCU, the position of the USB_DM/DP signal near the module needs to reserve a test point and the USB_DM/DP requires a series 0R resistor. The resistor is placed near the module and the test point is placed between module and resistor.

3.3.2 Firmware Upgrade

The IQ11 module can use the USB interface or MAIN_UART interface to upgrade the firmware. The IQ11 module requires the module to enter the forced download mode when updating the firmware through the USB interface. When USB_BOOT (PIN82) is detected to be high level during module startup, the module enter USB download mode. The circuit of the USB_BOOT interface is as follow.



Figure 3.3.2-1 The USB_BOOT Circuit

3.4 UART Interface

3.4.1 Pin Description

The IQ11 module provides three UART serial communication interfaces: MAIN_UART can be used as complete non-synchronous communication interface, supporting standard modem handshake signal control and in compliance with the RS-232 interface protocol, also supporting 4-wire serial bus interface or 2-wire serial bus interface mode. DBG_UART is used as a debug port of the IQ11 module. The AUX_UART can be used to connect peripherals.

The three groups of UART port support programmable data width, stop bits, and parity bits, with separate TX and RX FIFOs. The MAIN_UART supports 600bps, 1200bps, 2400bps, 4800bps, 9600bps, 19200bps, 38400bps, 57600bps, 115200bps, 230400bps, and 460800bps baud rates, and the default is 115200bps. This interface is used for AT command communication and data transmission. The DBG_UART supports 3Mbps baud rate for partial log output.

The pin signal definitions are shown in Table 3.4.1-1.

Pin No.	Pin Name	I/O type	Functional Description	
17	MAIN_RXD	DI	Main UART receive data input	
18	MAIN_TXD	DO	Main UART transmit data output	
19	MAIN_DTR	DI	Main UART Data terminal ready (wake up module)	
20	MAIN_RI	DO	Main UART ring indicator.	
21	MAIN_DCD	DO	Main UART data carrier detect	
22	MAIN_CTS	DO	Main UART clear to send	
23	MAIN_RTS	DI	Main UART request to send	
28	AUX_RXD	DI	Auxiliary UART receive data input	
29	AUX_TXD	DO	Auxiliary UART transmit data output	
38	DBG_RXD	DI	Debug UART receive data input	
39	DBG_TXD	DO	Debug UART transmit data output	

Table 3.4.1-1	UART Pin Description
---------------	----------------------

3.4.2 UART Interface Application

If used MAIN_UART in communication between the module and application processor, and the level is 1.8V, the connection mode is shown in Figure 3.4.2-1 and Figure 3.4.2-2. You can use the complete RS232 mode, 4 wires or 2 wires mode connection. Module interface level is 1.8V. If the AP interface level does not match, you must increase the level conversion circuit, as shown in Figure 3.4.2-3.



Figure 3.4.2-1 Connect to AP method (4lines)



Figure 3.4.2-2 Connect to AP method



Figure 3.4.2-3 Level Conversion Circuit



3.5 Status Indication Interface

3.5.1 Network Indicator Control Circuit

The module has a NET_STATUS pin. The reference circuit is shown in Figure 3.5.1-1.



Figure 3.5.1-1 NET_STATUS Circuit

3.5.2 Network Indication Pin State Description

The logic level changes of NET_STATUS (PIN16) in different network states are shown in Table 3.5.2-1.

LED Status	Module Status
OFF	Power off
64ms ON/800ms OFF	Shut down network
64ms ON/3000 ms OFF	Registered network

3.6 I2C Interface

The IQ11 module provides one group of I2C interfaces. This I2C can communicate with peripherals (such as sensor or Codec and so on) through the I2C interface.

Table 3.6-1	I2C Interface Description
-------------	---------------------------

Pin NO.	Pin Name	Mode	Notes	
66	I2C2_SDA		Need to add a pull-up resistor to 1.8V	
67	I2C2_SCL	100KHZ/400KHZ	use 4.7K	

3.7 Interactive Application Interface

3.7.1 Pin Description

The IQ11 module provides a variety of interfaces for interacting with the application processor, including WAKEUP (WAKEUP includes MAIN_DTR and MAIN_RI) and STATUS.

Table 3.7.1-1	Interactive Application Interface
---------------	-----------------------------------

Pin NO.	Pin Name	I/О Туре	Function Description
19	MAIN_DTR	DI	AP wakes up module
20	MAIN_RI	DO	Module wakes up AP
25	STATUS	DO	AP query module status

3.7.2 Interface Application

The IQ11 module provides direct interactive signals to communicate with the AP.

- MAIN_DTR: After the module enters sleep, the host can wake up the module by pulling down this signal. After the host pulls the signal high, the module is allowed to enter sleep. MAIN_DTR can be directly connected to the 1.8V~3.3V port of MCU.
- MAIN_RI: When the module has an event and needs to communicate with the AP, the module can wake up the AP by setting this pin to low level (Low level will last 120ms).

• STATUS: Module status query. Low level indicates power-off state or power-on initialization state, and high level indicates power-on state.

3.8 LCD Interface

The IQ11 module supports LCD function and only support SPI interface. It can provide 3-wire/4-wire SPI interface for data transmission, and the supported resolution can reach 320*240. LCD_SPI_CLK can support up to 25.6MHz. The interface modes of LCD are shown in Table 3.8-1.

Table 3.8-1 LCD_SPI Interface

Mode	LCD_CS	LCD_SPI_CLK	LCD_SPI_DOUT	LCD_SPI_RS
3-wire 9bit mode	•	•	•	1
4-wire 8bit mode	•	•	•	•

3.9 Digital Audio Interface

The IQ11 module provides a digital audio interface (PCM) which can be used as the PCM master device to transmit digital voice signals. During use, the IQ11 module is used as the master device to connect an external codec. PCM_SYNC, PCM_CLK are used as output pins.



Figure 3.5.1-1 PCM Application Circuit (IQ11 module as PCM master device)

Notes: It is recommended to reserve an RC (R=22R, C=22pF) circuit on the signal line of PCM, especially on the PCM_CLK pin.

3.10 ADC Interface

The module provides two ADC for detecting light-sensitive resistors or other devices that require ADC detection. The module supports 12-bit accuracy and the Max voltage of ADC is 1.2V.

Characteristics	Min.	Тур.	Max.	Unit
Input voltage range	0.05		1.2	V

4 Electrical Characteristics

4.1 Electrical Characteristic

Table 4.1-1	Electrical	Characteristic

Parameter	Min.	Nom.	Max.	Unit
VBAT	3.3	3.8	4.2	V
Peak current	-	-	1.2	А

Notes: The over-low voltage can't power on the module. Over-high voltage may be danger to
damage the module.

4.2 Temperature Characteristic

Table 4.2-1	Temperature	Characteristic
-------------	-------------	----------------

State	Min.	Nom.	Max.	Unit
Working	-40	+25	+85	°C
Storage	-45	+25	+90	°C

Notes: When the temperature is over the range, the RF performance may be dropped. It also may cause power down or restart problem.

4.3 Absolute Maximum Power

Pin name	Description	Min.	Тур.	Max.	Unit
VDD_EXT	Digital power for IO	-0.3	1.8	2	V
RESET_N	System reset signal	-0.3		3.6	V
VBAT	Power supply	-0.3		5	V

Table 4.3-1	Absolute	Maximum	Power	Rating

4.4 Recommended Operating Conditions

Table 4.4-1	Recommended	Operating	Range
	rteeenmenaea	oporaning	' ange

Pin name	Description	Min.	Тур.	Max.	Unit
VDD_EXT	Digital power for IO	1.75	1.8	1.85	V

4.5 Power Consumption

Table 4.5-1	Power Consumption
	i onor oonoumpaon

Parameter	Conditions	Min.	Average	Max.	Unit
Power off mode	VBAT=3.8V		1		uA
Flight mode	VBAT=3.8V/AT+CFUN=0, AT+ECPMUCFG=1,1		4.9		mA
Sleep1	VBAT=3.8V/AT+CFUN=0, AT+ECPMUCFG=1,2		52		uA
Sleep2	VBAT=3.8V/AT+CFUN=0, AT+ECPMUCFG=1,3		24		uA
Hibernate	VBAT=3.8V/AT+CFUN=0, AT+ECPMUCFG=1,4		TBD		uA
LTE Standby	VBAT=3.8V/AT+ECPMUCFG=1,2	-	0.85		mA

Peak current	VBAT=3.8V	1.2	А
P			

Notes: The test value of power consumption is the value tested in laboratory condition.

Table 4.5-2 Module Working mode Description			Neter
	Table 4.5-2	Module Working mode Descrip	otion

Operation Mode	Description	Notes
Flight mode	CPU is in IDLE mode, VDD_EXT output 1.8V	
Sleep1	VDD_EXT output 1.8V, 16KB cache Operation, 1MB SRAM Operation	It can be waked up by MAIN_DTR (need to send
Sleep2	VDD_EXT output 1.8V, 16KB cache Operation, 1MB SRAM OFF	AT+QSCLK=1 to pull up the interface to wake up)

4.6 Power Sequence



Figure 4.6-1 Power Sequence Diagram

4.7 Digital Interface Characteristics

Table 4.7-1 Digital IO Voltage

Parameter	Description	Min.	Typical	Max.	Unit
VIH	High-level input voltage	0.7*VDD_EXT	1.8	1.85	V
VIL	Low-level input voltage	0	-	0.2*VDD_EXT	V
VOH	High-level output voltage	0.8*VDD_EXT	1.8	1.85	V

VOL	Low-level output voltage	0	-	0.15*VDD_EXT	V
0					
Notes: Suit to all GPIO, UART interfaces.					

4.8 ESD

The module contains high sensitive electronic and is an electrostatic Sensitive Device. More attentions should be paid to the procedure of handing and packaging. The ESD test results are shown in the following table.

ESD parameter (Tem: 25°C, humidity: 45%)

Table 4.8-1	ESD Performance
Table 4.8-1	ESD Performance

Pin Name	Contact Discharge	Air Discharge
VBAT	±5KV	±10KV
GND	±5KV	±10KV
ANT	±5KV	±10KV

Enhanced ESD performance method:

1. If a converted board is added, it should have enough GND pins and be equally distributed. And the Layout of GND should be enough wide.

2. Key (Power key, USB_BOOT key and RESET_N key) need to add ESD device. Reset key line can't be near the edge of the board.

3. UART and other plug connector need to add ESD devices, and the other control lines from the outside of the machine also need to add ESD devices.

- 4. (U)SIM card should be added ESD protect.
- 5. External antenna, please add ESD device, ESD C_{pf}<0.1pF.

2

Notes: For ESD protect, please add ESD methods according to upper ways.

ESD components include varistors and TVS. For better performance, please use TVS.

Please pay attention to the selection of voltage range for ESD/TVS on the power supply.

5 RF Features

5.1 RF Main Features

- a) Support FDD Cat1;
- b) Support LTE bands include band B2/B4/B5/B12/B13/B66/B71.

The operating frequency range of the product is shown in table 5.1-1.

Band	Uplink band	Downlink band
FDD Band2	1850MHz~1910MHz	1930MHz~1990MHz
FDD Band4	1710MHz~1755MHz	2110 MHz~2155 MHz
FDD Band5	824MHz~849MHz	869MHz~894MHz
FDD Band12	699MHz~716MHz	729MHz~746MHz
FDD Band13	777MHz~787MHz	746MHz~756MHz
FDD Band66	1710MHz~1780MHz	2110MHz~2180MHz
FDD Band71	663MHz~698MHz	617MHz~652MHz

Table 5.1-2 Output Power

Band	Maximum power	Minimum Power
FDD Band2	22dBm±3dB	< -40dBm
FDD Band4	22dBm±3dB	< -40dBm
FDD Band5	22dBm±3dB	< -40dBm
FDD Band12	22dBm±3dB	< -40dBm

FDD Band13	22dBm±3dB	< -40dBm
FDD Band66	22dBm±3dB	< -40dBm
FDD Band71	22dBm±3dB	< -40dBm

Table 5.1-3 Receive Sensitivity

Band	REF SENS @10MHz (Total)
FDD Band2	≤-94.3dBm
FDD Band4	≤-96.3dBm
FDD Band5	≤-94.3dBm
FDD Band12	≤-93.3dBm
FDD Band13	≤-93.3dBm
FDD Band66	≤-95.8dBm
FDD Band71	≤-93.5dBm

5.2 Antenna Circuit Design

The connecting part of the RF antenna supports the PAD form. The connection between the module and the main board antenna interface is required to be welded and connected through a microstrip line or a strip line. The microstrip line or strip line is designed according to the characteristic impedance of 50ohm, and the length of the wire is less than 10mm. Reserved Π matching network.



Figure 5.2-1 Antenna Matching Circuit Schematic

Figure R1, C1, C2 and R2 composition of the antenna matching network for antenna debugging, the default R1, R2 paste 0ohm resistor and C2, C1 empty paste.

RF Connector in the figure is used for testing and conducting test (for example, CE, FCC, etc.), which need to be placed as close as possible by the module, the RF path from the module to the antenna feed point should be kept under 50ohm impedance control.

This product antenna peripheral circuit design, the proposed RF circuit Layout program: RF line trances top layer, a reference to the second layer. Users need to pay attention to the design of the PCB line: to ensure the RF has full reference GND layer.



Figure 5.2-2 Antenna Path Reference Design

5.3 Antenna Design

PIFA or IFA antenna can be used for inner antenna; Whip antenna can be used for external antenna. The antenna gain must less than 3dBi. The recommend area of inner antenna: 100mm*10mm*6mm (L*W*H), the main board length no less than 90mm. The antenna should be as far as possible from the chip and memory, power interface, data cable interface, camera FPC, screen FPC, connector FPC, and other possible EMI modules and devices.

Antenna Parameters		Parameter Requirements	
Antenna efficiency		>40%	
S11/VSWR		<-10dB	
Polarization mode		Linear polarization	
TRP	Low Band	>18dBm	
	Middle Band	>18dBm	
	High Band	>18dBm	
TIS	Low Band	<-92dBm (@10MHz)	
	Middle Band	<-92dBm (@10MHz)	
	High Band	<-92dBm (@10MHz)	
Low Band	Band 5/12/13/71		
Middle Band	Band 2/4/66		

Table 5.3-1 Antenna Parameters

6 Storage, Production and Package

6.1 Storage

The rank of moisture proof of the module is level 3. There is an obvious sign on the table of the internal and the external packaging.

In the vacuum sealed bag, the module can be stored for 12 months when the temperature is below 40°C and the humidity is below 90% under good air circulation.

Humidity level is described detail as follows:

Rank	Factory Environment 23 \pm 5°C, Relative Humidity < 60%RH	
1	No control < 30°C / 85%RH	
2	One year	
2a	4 weeks	
3	168 hours	
4	72 hours	
5	48 hours	
5a	24 hours	
6	Baking before using, SMT during the time table signs	

Table 6.1-1 Humidity Level

Notes: Moving, storage, production of module must meet the demand of IPC/JEDEC J-STD-033.

6.2 Production

The module is a humidity sensitive device. If the device needs reflow soldering, disassembly and maintenance, we must strictly comply with the requirements of humidity sensitive device. If module is damp, a reflow soldering or using a hot-air gun maintenance will lead to internal damage, because the water vapor has the rapid expansion of the burst, causing physical injury to the device, like PCB foaming and BGA component fail. So customers should refer to the following recommendations.

6.2.1 Module Confirmation and Moisture

The module in the production and packaging process should be strictly accordance with the humidity sensitive device operation. The factory packaging is vacuum bag, desiccant, and humidity indicator card. Please pay attention to the moisture control before SMT and the confirmation of the following aspects.

Demand of Baking Confirmation

Smart module uses vacuum sealed bag, which can make it stored for 12 months under the condition of temp 40°C and humidity < 90%. The module should be baked before reflowing soldering if any of the conditions below happen.

- 1. Storage exceeds the time limit.
- 2. Package damages and vacuum bags have air leakage.
- 3. Humidity indicating card change the color at 10%.
- 4. Module is placed naked in the air over 168 hours.
- 5. Module is placed naked in the air under 168 hours but not temp 30°C and humidity < 60%.

Baking Condition Confirmation

The moisture proof level of the smart module is level 3. And the baking conditions are as follows.

Table 6.2.1-1	Baking Conditions
---------------	-------------------

Baking Conditions	125±5°C / 5%RH	45±5°C / 5%RH
Baking time	8 hours	192 hours
Description	Not use the original tray	Can use the original tray

\rightarrow

Notes: The original anti-ESD tray temperature does not exceed 50°C. Otherwise the tray will be deformed.

The anti-ESD tray of the original packaging is only used for packaging, and can't be used as a SMT tray.

During taking and placing, please take notes of ESD and cannot be placed as overlay.

Customer Product Maintenance

If maintenance module after SMT, it is easy for damp module to damage when removing, so the module disassembly and other related maintenance operations should complete within 48 hours after SMT, or need to bake and then maintenance the module.

Because the module return from the field work can't ensure the dry state, it must be baked in accordance with the conditions of baking, then for disassembly and maintenance. If it has been exposed to the humid environment for a long time, please properly extend the baking time, such as 125°C/36 hours.

6.2.2 SMT Reflow Attentions

The module has the BGA chips, chip resistances and capacitances internally, which will melt at high

temperature. If module melt completely encountered a large shock, such as excessive vibration of reflux conveyor belt or hit the board, internal components will easily shift or be false welding. So, using intelligent modules over the furnace need to pay attention to:

- Modules can't be vibrate larger, namely customer requirements as far as possible in orbit (chain) furnace, furnace, avoid on the barbed wire furnace, in order to ensure smooth furnace.
- The highest temperature can't too high. In the condition that meet the welding quality of customer motherboard and module, the lower furnace temperature and the shorter maximum temperature time, the better.

Some customer's temperature curve in the line is not suitable, high temperature is too high, and customer motherboard melt good, but non-performing rate is on the high side. Through the analysis of the causes, it found that melt again of BGA components lead device offset and short circuit. After adjusting the temperature curve, it can ensure that the customer's motherboard the welding quality, and also improve the pass through rate. Non-performing rate is controlled below the 2/10000.

6.2.3 SMT Stencil Design and the Problem of Less Tin Soldering

Part of customers found false welding or circuit short when reflowing. The main reason is module tin less, PCB distortion or tins too large. Suggestions are as follows:

- Suggest use ladder stencil, which means the depth of the region of module is thicker than other areas. Please adjust validation according to the measured thickness of solder paste, the actual company conditions and experience value. The products need to strictly test.
- Stencil: Reference module package and the user can adjust according to their company experience; Outside of the module, the stencil extends outside. The GND pads use the net stencil.

6.2.4 SMT Attentions

If customer motherboard is thin and slender with a furnace deformation, warping risks, you will be

suggested to create "a furnace vehicle" to ensure the welding quality. Other production proposals are as follows:

- The solder pastes use brands like Alfa.
- The module must use the SMT machine mount (important), and do not recommend manually placed or manual welding.
- For SMT quality, Please ensure the necessary condition according to actual condition of factory before SMT, like SMT pressure, speed (very important), stencil ways.
- We must use the reflow oven more than 8 temperature zones, and strictly control the furnace temperature curve.

Recommended temperature:

- B. constant temperature zone: temperature 140-210°C, time: 60s-120s.
- E. recirculation zone: PEAK temperature 220-245°C, time: 45s-75s.



Figure 6.2.4-1 Temperature Curve

Notes: Customer's board deformation must be controlled well. By reducing the number of imposition or increasing patch clamp to reduce the deformation.

Module thickness of the stencil is recommended to be thickened, and the rest position can

be maintained by 0.1mm.

6.3 Packaging Information

The IQ11 module is packaged with a roll of tape and sealed with a vacuum-sealed antistatic bag.

Coil tape

One coil can hold 500 modules, as shown in the figure.



Figure 6.3-1 Coil Tape Information (Unit: mm)

7 Safety Information

For the reasonable usage of the module, please comply with all these safety notices of this page. The product manufacturers should send followed safety information to user, operator or product's spec.



The devices using the module may disturb some electronic equipment. Put the module away from the phone, TV, radio and automation equipment to avoid the module and the equipment to interfere with each other.



Shut down the mobile device or change to flying mode before boarding. The Using of wireless appliances in an aircraft is forbidden to avoid the interference, or else cause to unsafe flying, even violate the law.



In hospital or health care center, switch off the mobile devices. RF interference may damage the medical devices, like hearing-aid, cochlear implant and heart pacemaker etc.



Mobile devices can't guarantee to connect in all conditions, like no fee or with an invalid SIM card. When you need emergent help, please remember using emergency calls and make sure your device power on in an area with well signal.



Put the module away from inflammable gases. Switch off the mobile device when close to gas station, oil depot, chemical plant etc.



The module is not water proof. Please don't use the module in the area with high humidity like bathroom, which will decelerate the physical performance, insulation resistance and mechanical strength.



Non-professionals can't teardown the module which will damage it. Refer to the specification or communicate the related staffs to repair and maintain it.



Please switch on the module before cleaning. The staffs should be equipped with anti-ESD clothing and gloves.

The users and product manufacturers should abide by the national law of wireless modules and devices. If not, Mobiletek will not respond the related damages.