

深圳市最天维科技有限公司

# **V7S** User Manual

# Ver:001





#### Amendment Records

Product	Version	Person	Establish/	Reason for	
name	number	in charge	amend date	change	The major change contents
V7S	001	Nancy	2024- 8-15	N/A	NEW
Note:					

1. Please fill the form if there is any update.

2. For the first time saving the file, note "N/A" in the "reason for change" and "major change contents" line.



# Safety maintenance:

Please maintain your system properly to make sure its service life and reduce the damage risk.

- It should avoid the humidity and extreme temperature when being used.
- Avoid prolonged exposure of the unit to direct sunlight or strong ultraviolet light.
- Do not drop the unit or let it be in any place with severe shock / vibration.
- Please avoid the collision as the LCD screen is very easy to be scratched. Do not use any sharp object to touch the screen.
- To clean the outside fuselage, please turn off the power, unplug the power cord, scrub / wipe with slightly damp soft cloth. When cleaning the screen, please wipe with the lint free soft cloth.
- Never attempt to disassemble or repair the machine, otherwise the unit may be damaged.
- Do not place your unit or accessories together with other flammable liquids, gases, or other explosive materials, to avoid danger.
- Please unplug the power plug and remove the built-in battery if long-term no-use, or thunder weather.



# Contents

- 1. Product Description
  - 1.1 Brief Introduction
  - 1.2 Optional Functions
  - 1.3 Basic Parameters
- 2. Structure Function Explanation
- 2.1 Interface
- 3. Extended Cable Definition
  - 3.1 Definition
  - 3.2 Serial Port
  - 3.3 CAN test interface
- 4. Micro SIM Card & Memory Card Instructions
- 5. Basic Operation
  - 5.1 Click and Slide
  - 5.2 Long-press and Drag
  - 5.3 Install APK
  - 5.4 Delete
- 6.MENU
  - 6.1 Icon Bar
  - 6.2 Menu Setting
- 7. Accessories
  - 7.1 Standard accessories
  - 7.2 Optional accessories
- 8. Update firmware
  - 8.1 Supported host OS
  - 8.2 Install RK USB Driver
  - 8.3 Connect Device
  - 8.4.Flash update.img
- 9. Trouble Shooting



1. Product Description

1.1 Brief Introduction

- Android 11 operating system
- 7-inch 1024x600 TFT-LCD screen
- WiFi, 1000Mbps Ethernet port and 4G high speed internet surfing
- > Built-in high-sensitivity receiving module and active GPS antenna
- > 2MP front camera
- ➢ With USB DEVICE and USB HOST
- Support 128GB TF card storage
- Touch button + virtual button
- > Double track earphone port, built-in 2W left and right speaker, with microphone

input

- RS232 port
- Compliant with IP65 standard
- Support VESA 75MM\*75MM mounting & RAM 38MM\*30MM
  - **1.2 Optional Functions**
- ➢ 4G Modem Module
- > 2000mAh Li-ion battery (built-in)



### 1.3 Specifications

Specifications		Description			
	Processor	64bit RK3568 Quad-core Cortex-A55, up to 2.0GHz			
	Graphic	Mali-G52-2EE, 800MHz			
Core	RAM	2GB(4GB optional) LPDDR4			
	ROM	16GB(32GB optional) eMMC			
	OS	Android 11			
	LCD panel	7 inch TFT-LCD, LED backlight			
	Resolutions	1024x600			
	Brightness	500nits (typical)			
Display	Contrast Ratio	800:1			
	View Angle (° )	75/75(L/R), 70/75(U/D)			
	Touch panel	G+G multi-touch capacitive touch panel			
	WiFi	IEEE 802.11 b/g/n (optional)			
	Bluetooth	Ver 4.0			
Wireless	Cellular	4G Full Netcom (3G optional)			
	Positioning	Integrated GPS+GLONASS+BEIDOU(optional)			
	Speaker	Built-in speaker(2W, 8Ω) x 2			
	Microphone	Internal microphone			
	Camera	2M CMOS (Front)			
	Video	Video Decode: 4K@60fps			
		H.264&H.265&VP9			
		Profile0/2 video			
		decode, 1080P multi			
		Video Encodo: 1090D video			
Multimedia	Video	encoding for H 264 and H 265			
Multimedia	Audio	MP3, WMA, OGG, APE, FLAC, AAC etc.			
		12V.500mA (Max )/Optional			
	G-sensor	ontional			
	Gyroscope	optional			



	Ophoard I/O parta	1 x TF card slot(up to 128GB)				
	Onboard I/O ports	1 x SIM card slot				
		1 x USB 3.0 Host				
		1 x DC in				
		1 x RJ45(10/100/1000 Mbps) (support POE)				
		1 x RS422/485				
	Cable 1	1 x RS232				
		1 x OTG 2.0				
Extended I/O ports						
		1x DC in				
		1 x ACC				
	Cable 2	2 x CAN bus(optional)				
		1 x AV IN (support NTSC)				
		1 x reverse gear trigger				
	Function Key	Power, Menu, Volume+, Volume-, Reset				
	Power light	LED light				
	DC In	12V DC (9~36V)				
Power Supply	Battery	3.7V 2000mAh, Lithium-Polymer battery pack				
Power	Normal mod	≤ 6W				
consumption	Charging mode	≤ 10w				
	IP rating	IP65				
Environment		-20° C ~ 70° C (w/o battery)				
	Operating Temp.	-20° C ~50° C (w/ battery)				
	Storage Temp.	-20° C ~ 80° C				
	Dimensions	200W x138H x 36D mm				
Mechanical	Weight	0.79kg				
	mount	75MM*75MM VESA or 38MM*30MM RAM				
<b>A</b>	Standard	DC adaptor , Extended Cables				
Accessories	optional	Sunshade				

# 2.Structure Function Explanation

# 2.1 Interface









#### Accessory



- 1. Power Key: Short Key:sleep/ wake up V7S Length Key: boot, power off
- 2. Menu: Enter the menu interface
- 3. Volume +: Increase the volume
- 4. Volume -: Decrease the volume
- 5. TF Card: Extended to 128G TF card
- 6. SIM Card: Identify network communication
- 7. USB ports: be able to connect with USB driver/ mouse/ keyboard
- 8. LED:

Red light: charging the battery Green light: battery charging saturation



- 9. Front camera
- 10. Microphone interface
- 11. Reset key: used in mechanical down without reset operation
- 12. 38mm\*30mm RAM mounting screw holes
  - 75mm\*75mm VESA mounting screw holes
- 13. Speaker

#### **3 Extended Cable**

3.1 Definition:

Cable 1





Cable 2





3.2 Serial port

## RS232/ RS422 test:

Connect RS232 or RS422 with DB9 testing jig and click Device\_test\_RS232, and print the data as below:

RS232

/dev/ttyS5Test B

RS422

/dev/ttyS0Test A

Device_Test(0/1)		
串口测试		1
/dev/ttyS0]Test A /dev/ttyS0]Test A	<pre>[/dev/ttyS5]Test B [/dev/ttyS5]Test B</pre>	
返回测试界面		返回上一项测试



#### 3.3 CAN test interface

Device_Test(0/1)	
CAN单	独测试
发送再ば 发: 10:05:57-077 can1 011 01 02:03:04:05:06:07:08 发: 10:05:57-418 can1 011 01:02:03:04:05:06:07:08 发: 10:05:58-145 can1 011 01:02:03:04:05:06:07:08 发: 10:05:59-474 can1 011 01:02:03:04:05:06:07:08 定: 10:05:59-539 can1 011 01:02:03:04:05:06:07:08 发: 10:05:59-539 can1 011 01:02:03:04:05:06:07:08 发: 10:05:00-292 can1 011 01:02:03:04:05:06:07:08 发: 10:05:00-617 can1 011 01:02:03:04:05:06:07:08 发: 10:06:01-352 can1 011 01:02:03:04:05:06:07:08	変送測试
返回测试界面 🖌 通过	失败 🚽 返回去一项测试

Device_Test(0/1)	
CAN单独测试	
接收面试 收:10.0522-611 mCommand:candump.can1	
戦 10:05:36-626 can1 000 [8] 41 42 43 44 45 46 47 48 戦 10:05:37-547 can1 000 [8] 41 42 43 44 45 46 47 48 戦 10:05:38-168 can1 000 [8] 41 42 43 44 45 46 47 48	
校 10:05:38-603 can1 000 [#] 41 42 43 44 45 46 47 48 校 10:05:39-138 can1 000 [#] 41 42 43 44 45 46 47 48 校 10:05:39-900 can1 000 [#] 41 42 43 44 45 46 47 48	发送游试
8, 1005 41-466 Can'i 000 [#] 4142 43 44 45 46 47 48	接收测试
返回测试界面 🖌 通过 失败 🚽	返回上一项测试



#### 4. Micro SIM Card & Memory Card Instructions

- In order to avoid damaging of the 3G/4G card & memory card, please insert the card smoothly and push slightly before you draw it out.
- The memory card will be heat after long time working.
- If you don't correctly use the memory card or cut the power when it being read, maybe some data will be damaged.
- If you don't correctly use 3G/4G card or cut the power when it being read, the network will be interrupted.
- If you do not use Micro SD card for a long time, please put it into packing box.

#### **5.Basic Operation**

5.1 Click and Slide:



5.2 Long-press and Drag

Long-press	Drag
•	

#### 5.3 Install APK

Settings→Security→Unknown sources→Install APK



#### 5.4 Delete

5.4.1 Delete APK

Long-press the application icon, and drag to the Home screen, then drop to the recycle, lift-up to delete this software.



深圳市最天维科技有限公司 Universities Santway Technology Co., 14



### 6.MENU

#### 6.1 Icon Bar

Icon bar shows on the top of screen:

Icon	Name	Description
▼	Wi-Fi	Wi-Fi signal connection and status of signal weakness or strength.
	No SIM card	Icon displayed when no SIM card.
	Mobile Network	Network available but not surf the Internet via 2G/3G/4G.

	SA	INTWAY Redent	则市晟天维科技有限公司 mater Samtway Technology Co., Ltd.	
36		Signal connection and	d status.	
3:25	Time	Current time		
0	Wi-Fi Hotspot	Wi-Fi Hotspot availat	ble	
*	Bluetooth	Bluetooth available		
•	Position	GPS positioning		
$\mathbf{T}$	Flight Mode	Flight mode status		

## 6.2 Menu Setting





6.2.1 Drop down from the top of the screen to enter notification bar. The notification bar shows system, running and error notice.

	*	Θ	
TP-LRIK, DE44	Burnoth	the MotUmburth	
0		102	
Auto-miane	Barrery Server	Mission June Rot 2004 Land	
+	( <u>=</u> )	iox.	
Applane maile	Street Frank	Ready Dure	
/	**	ی ک	
9.0			

 $6.2.2\ {\rm Click}\ {\rm `Settings'}\ {\rm to}\ {\rm launch}\ {\rm setting}\ {\rm in}\ {\rm the}\ {\rm application}\ {\rm list}$ 

Setting according to users' needs. Click search icon to search function options on the upper right corner of screen. To set Wi-Fi, Bluetooth, mobile network

Set VPN, Hotspot, Ethernet functions in 'Network & Internet' option.

10.00	1.	 1.0.14					
	The second distance of		-				
-	Annual States		See.	÷			
	And the Additional Additiona Additional Additional Additiona Additional Additional Additional Additional Additional Addit	÷					
۵	And a second sec	1	Trees.	-			
-	- Strategy Reference and a second		-				
	Ameri American de Carlos	3	277.	-			
	The second secon						

6.2.3 To view and set brightness, wallpaper, screen rotation, screen timeout in 'Display' option.

100	10.04					+ + + 1
+	Depley					9,
	inginese 	ere .				
	Date Party		2			110
	-					
	Print					
	Sciencista Territori	-				
	Same big	in.				
	Delte -					
			4			





Ì	View	RAM	in the	'About	tablet'	option		
	2.4)							1.175
	Ahmut tables							- 4
				0	-			
	Thing .							
	11.							
	-							
	Resident states	141						
	Norwalds Annual State							
	the second second							
			- 4			-	-	

**6.2.4** To manage language& input and reset options in 'System' option. Add new language is available.

10,000	0.08			10.45	10.00				10000
+	Longergen & Hand				*	14-page			
5	The second				31				
	and a second sec								

6.2.5 When unrecovered problems occurred, try to click 'Backup' & 'reset' and 'Factory data reset' then follow the instructions. Device will delete settings and applications after restart, and restore to factory defaults. (Please backup all important files before reset. Otherwise files will be deleted automatically and restore to factory defaults.

 1.00					4.4.707						11.87
Inte					+	West latter	÷				- 6
-						inerest of	*****	-			
						-	-				
		-	_	 		the state of		ŝ.			
	•		•					- 4		 	

6.2.6 To set date & time and accessibility in 'System' option. View Android version, Build number, kernel version, status information in 'About tablet ' option.

(Do NOT operate if unfamiliar with 'Developer options')



10:01 AM	1.0					8.5. #1
•	System					٩
۰	Languages & input Observ					
	Gestures					
0	Date & time GMT+00.00					
œ	Backup orr					
0	Reset options Meteorick, spps, or device (a	an berreatt				
a I	Multiple users Signations Demot					
	System update					
	-	-	۰	-0	0	
HITTAH	1.0					1.5.47
6	About tablet					٩
	Device WIFT MAC adds d0/5358/7a75	1014 <sup>1</sup>				
	Muetooth address . 32/32/11/37/02 int					
	Ethernet MAC address solox/sk/texp/xe					
	Up time 32.18					

# 7. Accessories

#### 7.1 Standard accessories:

- DC 12V adapter 1pc
- Extension Cable 1pc

#### 7.2 Optional accessories:

• Sunshade 1pc

# 8. Update firmware

#### 8.1 Supported host OS

- Windows XP (32/64bit)
- Windows 7 (32/64bit)
- Windows 8 (32/64bit)
- Windows 10 (32/64bit)



#### 8.2 Install RK USB Driver

Uncompress DriverAssitant.zip, then run DriverInstall.exe inside.

#### 8.3 Connect Device

8.3.1 Use USB OTG cable to connect host and V7S together.

8.3.2 Plug in the power

8.3.3 Run AndroidTool.exe: (Note: If using Windows 7/8, you'll need to right click it, select to run it as Administrator)

If AndroidTool defaults to display in Chinese. We need to change it to English. Open config.ini with an text editor (like notepad).

#### The starting lines are:

#选择工具语言:Selected=1(中文);Selected=2(英文)	
[Language]	
(inds=2	
Selected=1	
LangPath=Language\	

Change "Selected=1" to "Selected=2", and save. From now on, AndroidTool will display in English.

8.4.Flash update.img

8.4.1 Switch to "Upgrade Firmware" tab page. Show "found one MSC device"

8.4.2 Click "Firmware" button and open the image file. Detail information of the image file, like version and chip

8.4.3 Click "Switch" button to change ADB Device to LOADER Device.

8.4.4 Click "Upgrade" button to start flash.

8.4.5 Flash update success, Auto reset device.

miost isap	al anage an	Hanna Adai	most function			Switch Bockush Success	
Firmwale	Opgrade	Switch	EceseFlash				
FarVet	11.0.00	Londer V	AC ER	Chip tofs:	800560		
Firmware	1 WIFW	7-356682/‡\\	115-6631開井いれ		COULD_CAN IN		



## 9. Trouble Shooting

#### 9.1 Power Problem Cannot boot up

• Wrong cable connection:

Connect Extended cable with device first, and connect the AC end of DC adapter with DC input port of Extended cable, then the other end of DC adapter connect with power plug socket.

• Bad connection: Check every connection and socket of power source.

#### 9.2 Screen Problem

- No picture on screen.
- The application reaction time is too long and cannot be activated when clicked.
- The image appears delay or still when switching.

Please restart your system if the device has any problem as described above.

Display screen is misty. Please check whether the display screen surface has dust filth or not. Please simply wipe with clean and soft cloth.

#### Warning:

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

#### **FCC Statement:**

This equipment has been tested and found to comply with the limits for a Class B Digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that Interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/ TV technician for help.

The equipment complies with FCC Radiation exposure limit set forth for uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

Note: Due to constant effort to improve products and product features, specifications may change without prior notice.