

Contents

MENU MAP	14
FOR YOUR SAFETY	24
 <i>Traffic Safety</i>	24
 <i>Do Not Use in Hospitals</i>	24
 <i>Do Not Use in Airplanes</i>	24
 <i>Do Not Use in Gasoline Stations</i>	24
 <i>Do Not Use in Explosive Sites</i>	25
 <i>Operating Environment</i>	25
 <i>Standard Usage</i>	25
 <i>Accessories and Batteries</i>	25
 <i>Appropriate Maintenance</i>	25
 <i>Emergency Calls (SOS)</i>	25
 <i>Use with proper care to reduce electromagnetic interference (EMI)</i>	26
GETTING STARTED	27

	PHONE OVERVIEW.....	27
	INSTALLATION & REMOVAL	28
	<i>Installing the battery</i>	28
	<i>Removing the battery</i>	28
	<i>Inserting the SIM Card</i>	29
	<i>Removing the SIM Card</i>	29
	<i>Connecting the Charger</i>	30
	<i>Removing the Charger</i>	30
	KEYPAD DESCRIPTION	31
	ALPHANUMERIC MAPPING	33
	DISPLAY INDICATORS.	35
	BASIC OPERATION 	36
	<i>Making a Call</i>	36
	<i>The SIM Card</i>	37
	<i>Battery and Charger</i>	37
	<i>Switching on the Phone</i>	38
	<i>PIN and PIN2 (4 to 8 digits)</i>	38
	<i>PUK1 and PUK2 (8 digits)</i>	38
	<i>Calling</i>	39
	<i>Dialing Emergency Numbers</i>	39

	<i>Correcting an Entry</i>	39
	<i>Answering a Call</i>	39
	<i>Recent Calls</i>	40
	<i>Speed Dialing</i>	40
	<i>Holding a Call</i>	40
	<i>Multi-party Calls</i>	40
	<i>Input Methods</i>	41
	1. T9 English (Predictive Text Mode)	42
	2. ABC.....	43
	3. Pinyin	43
	4. Symbols.....	43
	5. 123	43
	MENU FUNCTION 	45
	PHONE BOOK	45
	<i>Search</i>	45
	<i>Add Entry</i>	46
	<i>Edit</i>	47
	<i>Delete</i>	48
	<i>Copy</i>	48
	<i>P.Book Settings</i>	48
	1. Caller Group.....	48
	2. Sorting.....	49
	3. Display SIM Records	49

	<i>Memory Status</i>	49
	<i>Add to Black List</i>	49
	<i>Add to White List</i>	49
	CAMERA	49
	<i>Snap Shoot Mode</i>	50
	<i>Self-Timer</i>	50
	<i>Photo Album</i>	50
	<i>Camera Settings</i>	50
1.	Set Shot Mode.....	51
⊙	Shot mode.....	51
⊙	Size	51
⊙	Continuous time.....	51
⊙	Add Frame	52
⊙	Night shot mode.....	52
⊙	Add date.....	52
⊙	Add Text	52
⊙	Quality	53
2.	Special Effect	53
3.	Advanced.....	53
⊙	Timekeeper	53
⊙	Set file name	53
⊙	Sound effect.....	53
⊙	Info Display	53
⊙	Softkey display	54
⊙	Set to default.....	54
	MESSAGES	54
	<i>SMS</i>	54

1. Write.....	54
2. Inbox	55
3. Outbox.....	55
4. Delete message.....	56
5. Free count.....	56
6. Settings.....	56
⊙ Pre-Message	56
⊙ SMS Center	56
⊙ Validity Period	57
⊙ Auto Display	57
⊙ Status Report.....	57
⊙ Storage Area	57
 <i>MMS</i>	57
1. Write.....	57
⊙ From Templates	61
2. Inbox	61
3. Outbox.....	61
4. Drafts.....	61
5. Sent	61
6. Templates	61
7. MMS Settings	62
⊙ Connection.....	62
Add New:	62
Add from list.....	62
⊙ Reception.....	62
Always.....	62
Never	62
⊙ Message Validity.....	62
1 Hour.....	62
6 Hours	62
1 Day	62
3 Days.....	62

1 Week.....	62
Maximum	62
⊙ Allow Advertisement	62
⊙ Save Sent Msgs.....	62
 <i>Broadcast</i>	63
1. Read	63
2. Filter	63
3. Auto Display	63
 <i>Voice Mail</i>	64
⊙ Listen to voice message	64
⊙ Voice mailbox number.....	64
 <i>WAP PUSH Message</i>	64
1. Home.....	65
2. Bookmarks	65
3. Go To URL.....	65
4. Save Items	65
5. History.....	65
6. Reload	66
7. Forward	66
8. Snapshots	66
9. Advanced.....	66
Secure Prompt	66
Current Certificate	67
CA Certificates	67
Authentication	67
 PROFILE	67
 <i>Adjust</i>	67
1. Activate	67
2. Ringtone and Volume	67

3. Key Sound.....	67
4. Crescendo.....	68
5. SMS Rec Tone.....	68
6. Calling Vibration.....	68
7. Message Vibration.....	68
8. Service Tone.....	68
 CALL LISTS	68
 <i>Massed Call</i>	68
 <i>Incoming</i>	69
 <i>Outgoing</i>	69
 <i>Call Info</i>	69
1. Last Call	69
2. Total Calls	69
3. 1-minute Beep	69
4. Charge Info.....	69
⊙ Total Charge.....	70
⊙ Max Charge	70
⊙ Unit Price.....	70
 SETTINGS	70
 <i>Personal</i>	70
1. Language.....	70
2. Greetings	70
3. Power On/Off Melody.....	70
4. Folder On/Off Melody.....	70
5. Hot Key	71
6. Own Number	71
 <i>Clock</i>	71
1. Set Date	71

2. Set Alarm.....	72
3. Power Off.....	72
 <i>Screen</i>	73
1. Standby mode.....	73
2. Network Name	73
3. Show Clock.....	73
4. Standby LED.....	73
5. Contrast.....	73
 <i>Call Setting</i>	73
1. Call Waiting.....	73
⊙ Activate.....	73
⊙ Cancel.....	73
⊙ Status	74
2. Divert	74
⊙ Forward to	74
⊙ Unreachable.....	74
⊙ If No Reply	74
⊙ All Calls.....	74
⊙ If Busy.....	74
⊙ Status	74
⊙ Cancel All.....	74
3. Answer Mode	74
⊙ Normal answer.....	74
⊙ Any key answer	74
⊙ Folder answer	75
4. Present Number.....	75
 <i>Network</i>	75
1. Select Method.....	75
2. New Search	75
3. Select Sequence.....	75
 <i>Security</i>	75

1. Bar Calls.....	75
⊙ All Out.....	76
⊙ Out Intl.....	76
⊙ Out X Home.....	76
⊙ All In.....	76
⊙ In If Abr.....	76
⊙ Status.....	76
⊙ Cancel All.....	76
2. PIN Check.....	76
3. PIN Change.....	76
4. PIN2 Change.....	76
5. Fixed Numbers.....	77
6. SIM Lock.....	77
⊙ Set Lock.....	77
⊙ Change PCK.....	77
 <i>Call Guard</i>	77
1. Black List.....	77
⊙ Add Entry.....	77
⊙ Edit.....	77
⊙ Search.....	77
⊙ Delete All.....	77
⊙ Delete.....	78
2. White List.....	78
⊙ Add Entry.....	78
⊙ Edit.....	78
⊙ Search.....	78
⊙ Delete All.....	78
⊙ Delete.....	78
3. Call Guard Settings.....	78
⊙ Activate Black List.....	78
⊙ Activate White List.....	78
⊙ Deactivate All.....	78

 <i>Reset Setting</i>	78
 MMEDIA	79
 <i>File Manager</i>	79
⊙ Open File	79
⊙ Send MMS	79
⊙ Save as Wallpaper	79
⊙ Rename	79
⊙ Delete File	79
⊙ Delete all file	79
⊙ File Sort	79
By Name	79
By Date	80
By Type	80
⊙ View	80
List	80
Icon	80
⊙ Detail Info	80
Free Space	80
 <i>Game</i>	80
1. Game	80
⊙ Hostage Salvation	80
⊙ Reversi	81
 <i>Tone Edit</i>	81
1. Play	81
2. Edit	82
⊙ Keypad functions	82
⊙ Edit	82
3. Reset	83
4. Tempo	83

5. Instrument	83
6. Rename	83
 PIM.....	83
 CALCULATOR	83
 Calendar	84
1. <i>View Day Note</i>	84
2. <i>Make Note</i>	85
3. <i>Erase Note</i>	85
4. <i>View All Notes</i>	85
5. <i>Go To Date</i>	85
 <i>Exchange Rate</i>	86
 <i>Voice Memos</i>	86
1. Record	86
2. Playback	86
⊙ Playback	86
⊙ Delete One	86
⊙ Label	86
3. Options	86
⊙ Self Only	87
⊙ Other Party Only	87
⊙ Both	87
 <i>World clock</i>	87
⊙ Set Location	87
Automatic	87
Manual	87
 <i>MC Management</i>	88
⊙ Set Date	88
⊙ Query	88

⊙ Female Note.....	88
⊙ Delete All Date	88

WAP (WIRELESS APPLICATION PROTOCOL) 88

 <i>Access WAP</i>	88
 <i>Favorites</i>	89
1. New Bookmark	89
2. New Folder.....	90
3. Delete all	90
4. Hotkeys	90
 <i>Go To URL</i>	92
 <i>WAP Settings</i>	92
1. Connection	92
⊙ Add New	92
Name	92
Homepage	92
IP Address.....	92
Bearer.....	92
User name	93
Password	93
DNS IP address.	93
Linger Time.....	93
APN	93
Security	93
Store	93
⊙ Add from List	93
2. Color Scheme	93

3. Clear Cache	93
4. Reset all	93
 STK (SIM TOOL KIT)	94
BATTERY 	95
CARE AND MAINTENANCE 	96
FCC REGULATIONS	97
FCC RF EXPOSURE INFORMATION	98
<i>Body-worn Operation</i>	98

Menu Map

Phone Book

- Search
- Add Entry
- Edit
- Delete
- Copy
- P. Book Settings
 - 1. Caller Groups
 - 2. Sorting
 - 3. Display SIM Records
- Memory Status
- Add to Black list
- Add to White list

Camera

- Shoot
- Self-Timer
- To Album
- Settings
 - 1. Set Shot Mode
 - ⊙ Shot Mode
 - ⊙ Size (Only in Normal & Cont. Mode)
 - ⊙ Cont. Time (Only in Cont. Mode)
 - ⊙ Add Frame (Except for Normal Mode)
 - ⊙ Night Shot Mode (Except for Cont. Mode)
 - ⊙ Add Date (Except for Normal Mode)
 - ⊙ Add Text (Except for Normal Mode)
 - ⊙ Quality
 - 2. Special Mode
 - 3. Advanced
 - ⊙ Timekeeper

- ⊙ Set File Name
- ⊙ Sound Effect
- ⊙ Info Display
- ⊙ Softkey Switch
- ⊙ Set to Default

Messages

●SMS

1. Write
 2. Inbox
 3. Outbox
 4. Delete
 5. Free Count
 6. Settings
- ⊙ Pre-Message
 - ⊙ SMS Center
 - ⊙ Valid Time
 - ⊙ Auto Display
 - ⊙ Status Report
 - ⊙ Storage Area

●MMS

1. Write
 2. Inbox
 3. Outbox
 4. Drafts
 5. Sent
 6. Templates
 7. MMS Settings
- ⊙ Connection
 - ⊙ Reception
 - ⊙ Message Validity
 - ⊙ Allow Advertisement
 - ⊙ Save Sent Messages

●Broadcast

1. Read
2. Filter
3. Auto Display
- Voice Mail
1. Call V-mail
2. Voice Mail#
- WAP Push Message
1. Home
2. Bookmarks
3. Go To URL
4. Save Items
5. History
6. Reload
7. Forward
8. Snapshots
9. Advanced

Audio Profile

- Typical
- Silent
- Outdoor
- Handsfree
- Profile1
- 1. Activate
- 2. Ringtone and Volume
- 3. Key Sound
- 4. Crescendo
- 5. SMS Rec Tone
- 6. Calling Vibration
- 7. Message Vibration
- 8. Service Tone
- 9. Auto Answer (Only in Handsfree mode)
- 10. Rename (Only in Profile1 mode)

Call Lists

- Missed Calls
- Incoming Calls
- Outgoing Calls
- Call Info
 1. Last Call
 2. Total Calls
 3. 1-min Beep
 4. Charge Info
- ⊙ Total Charge
- ⊙ Max Charge
- ⊙ Unit Price
- 5. Total Outgoing
- 6. Total Incoming

Settings

- Personal
 1. Language
 2. Greetings
 3. Power On/Off Melody
 4. Folder On/Off Melody
 5. Hot Key
 6. Own Number
- Clock
 1. Set Date/Time
 2. Set Alarm
 3. Power Off
- Screen
 1. Standby mode
- ⊙ Picture & Text
 - ⊙ Calendar
 2. Network Name
 3. Show Clock
 4. Standby LED

- 5. Contrast
 - Call Settings
 - 1. Call Waiting
 - ⊙ Activate
 - ⊙ Cancel
 - ⊙ Status
 - 2. Divert
 - ⊙ Forward to
 - ⊙ Unreachable
 - ⊙ If No Reply
 - ⊙ All Calls
 - ⊙ If Busy
 - ⊙ Status
 - ⊙ Cancel All
 - 3. Answer Mode
 - ⊙ Normal Answer
 - ⊙ Any key Answer
 - ⊙ Folder Answer
 - 4. Present No.
- Network
 - 1. Sel. Method
 - ⊙ Auto
 - ⊙ Manual
 - 2. New Search
 - 3. Sel. Sequence
- Security
 - 1. Bar Calls
 - ⊙ All Out
 - ⊙ Out Intl
 - ⊙ Out X Home
 - ⊙ All In
 - ⊙ In If Abr
 - ⊙ Status

- ⊙ Cancel All
- 2. PIN Check
- ⊙ PIN Enable
- ⊙ PIN Disable
- 3. PIN Change
- 4. PIN2 Change
- 5. Fixed Numbers
- 6. SIM Lock
- ⊙ Set Lock
- ⊙ Change PCK
- Call Guard
- 1. Black List
- ⊙ Add Entry
- ⊙ Edit
- ⊙ Search
- ⊙ Delete All
- ⊙ Delete
- 2. White List
- ⊙ Add Entry
- ⊙ Edit
- ⊙ Search
- ⊙ Delete All
- ⊙ Delete
- 3. Call Guard Settings
- ⊙ Activate Black List
- ⊙ Activate White List
- ⊙ Deactivate All
- Reset Settings

Multi Media

- File Manager
- 1. Album
- ⊙ Open File
- ⊙ Send MMS

- ⊙ Save as Wallpaper
- ⊙ Rename
- ⊙ Delete File
- ⊙ Delete All Files
- ⊙ File Sort
- ⊙ View
- ⊙ Detail Info
- 2. Image
- ⊙ Open file
- ⊙ Send MMS
- ⊙ Save as Wallpaper
- ⊙ Rename
- ⊙ Delete File
- ⊙ Delete All Files
- ⊙ File Sort
- ⊙ View
- ⊙ Detail Info
- 3. Audio
- ⊙ Open file
- ⊙ Send MMS
- ⊙ Rename
- ⊙ Delete File
- ⊙ Delete All Files
- ⊙ File Sort
- ⊙ Detail Info
- 4. Frame
- ⊙ Open File
- ⊙ Send MMS
- ⊙ Save as Wallpaper
- ⊙ Rename
- ⊙ Delete File
- ⊙ Delete All Files
- ⊙ File Sort

- ⊙ View
- ⊙ Detail Info
- 5. Free Space
- Tone Edit
 - 1. Play
 - 2. Edit
- ⊙ Save
- ⊙ Help
- 3. Reset
- 4. Tempo
 - ⊙ More Slowly
 - ⊙ Slowly
 - ⊙ Normal
 - ⊙ Fast
 - ⊙ More Fast
- 5. Instrument
 - ⊙ BritePno
 - ⊙ Marimba
 - ⊙ Harp
 - ⊙ Crystal
 - ⊙ Banjo
- 6. Rename
- Game
 - 1. Hostage Salvation
 - 2. Reversi

PIM

- Calculator
- Calendar
 - 1. View Day Note
 - 2. Make Note
 - 3. Erase Note
 - 4. View All Notes
 - 5. Go to Date

- Exchange Rate
- Voice Memo
 1. Record
 2. Playback
 - ⊙ Playback
 - ⊙ Delete One
 - ⊙ Label
 3. Options
 - ⊙ Self Only
 - ⊙ Other Party Only
 - ⊙ Both
- World Clock
 - ⊙ Auto
 - ⊙ Manual
- MC Management
 - ⊙ Set Date
 - ⊙ Query
 - ⊙ Female Note
 - ⊙ Delete All Date

WAP

- Access WAP
- XG.COM
- Favorites
 1. Details
 2. Delete
 3. New Bookmark
 4. New Folder
 5. Move
 6. Move to Folder
 7. Delete All
 8. Hotkeys
- Go To URL
- WAP Settings

1. Connection
 - ⊙ Add New
 - ⊙ Add from List
2. Color Scheme
3. Clear Cache
4. Reset All

STK

For Your Safety

Only proper operation can ensure your personal safety. Be sure to carefully read these simple guidelines before you use the phone. Breaking the rules may be dangerous or illegal. Further detailed information is given in this user manual.



Traffic Safety

Don't use a mobile phone while driving. For your safety, you should park the vehicle before making or answering a call. Using a handsfree car kit or earpiece is highly recommended.



Do Not Use in Hospitals

The use of mobile phones is prohibited and may cause interference with the functionality in medical devices in the hospitals. Check the laws and regulations or posted notices. To avoid electromagnetic interference (EMI) with medical devices, please switch off the phone near medical equipment.



Do Not Use in Airplanes

The use of mobile phones in an aircraft may disrupt radio transmissions and signals. This, therefore, can be dangerous to the operation of the aircraft. Be sure to switch off the phone while on board an aircraft. It is highly recommended to detach the battery pack from the handset to prevent accidentally switching on the phone by miss-touching the power key.



Do Not Use in Gasoline Stations

It is advisable that users switch off the phone at a refueling point. The threat mobile phones pose to gas stations and their users is primarily the result of their ability to produce sparks that can be generated by the high-powered battery inside the phone.



Do Not Use in Explosive Sites

The use of mobile phones should be restricted near potentially explosive atmosphere sites such as chemical plants, fuel storage, or the areas where blasting operations are in process. Observe restrictions, and follow any posted regulations or rules.



Operating Environment

Mobile radio transmitting equipment, including mobile phones, may be subject to interference and may cause danger. Therefore, it is highly recommended that you follow any special regulations in any area. Switch the phone off whenever the use is forbidden.



Standard Usage

For the satisfactory operation of the mobile phone, it should be used only in a normal operating position. Do not touch the antenna unnecessarily.



Accessories and Batteries

This phone can only be connected to approved accessories and batteries. Do not connect incompatible products.



Appropriate Maintenance

Only qualified and authorized personnel should service the phone equipment. Faulty installation or repair may be hazardous.



Emergency Calls (SOS)

An emergency call "112" can be made with the phone in any circumstances, and even the phone is locked. When making an emergency call, you must be sure to give all the necessary

information, such as your name, your mobile phone number, the location and the emergency situation, as accurately as possible. In order to deliver the sufficient information to a rescue institute, do not disconnect your phone until told to do so.




**Use with proper care to reduce
electromagnetic interference (EMI)**

This product has passed the inspection of the Directorate-General of Telecommunications, Ministry of Transportation and Communication. The highest reported SAR values which are: Head 0.801 W/kg; Body-worn 0.112 W/kg are lower than the standard value at 1.6 W/kg, maximum.

Getting Started

Phone Overview




⚠ Warning: Please do not detach any parts of this mobile phone and only use original manufacturer components to guaranty the quality of transmission.

Installation & Removal




Installing the battery

1. Place the battery pack downward and gently slide its side corners into this phone's bottom fillister.
2. Hold and press the battery pack until it contacts to the phone. Make sure that the metallic connector is surely facing the built-in hinged-type connectors on the phone.
3. Push and slide it to clasp the cover latch.



Removing the battery

1. Switch off the phone first and gently pushes the latch forward to separate it from the cover latch.
2. Lift up the bottom of the battery pack and remove the battery from phone.




Important! : Risk of explosion if an incorrect type replaces battery.



Inserting the SIM Card

1. Find the SIM slot. Place your SIM card golden contact area downward.
2. Place the SIM card with leaning 30° and gently insert the SIM into SIM card slot and slide the card folder over the SIM card to lock the card in its place..




Important! : Before removing the cover, always switch off the power first and disconnect the phone from the charger or any other devices.



Removing the SIM Card

Switch off the power first and remove the battery. Press down the SIM latch and slide SIM upward to remove SIM from holder and slot as shown in the figure.



Important! : Keep all miniature SIM cards out of the reach of small children. The SIM card and its contacts can be easily damaged by scratches or bending, so be careful when handling, inserting and removing the card.



Connecting the Charger

To connect the travel charger to the mobile phone, you should install the battery first. Follow the travel charger instruction, and plug the connector with the  sign upside into mobile phone. See the figure below.



Note:

1. Do not remove your battery or SIM card while charging.
2. Use a compatible or appropriate charger for the phone.
3. Manipulate the charger carefully, or the connector might be damaged easily.



Removing the Charger

When removing the charger from battery, disconnect the plug from the electrical outlet. Press the release buttons on two sides of the connector simultaneously and pull out the connector from mobile phone.

Keypad Description

Key	Description
	★ Answering a call, call hold; or call retrieve by press the key once again. ★ Affirmative inputs: OK, select, call, save and reply. Press this key to access function menu.
	★ Negative inputs: option, end, return, cancel, abort, and quit. ★ When a phone call is in progress, press this key to mute the microphone so that the other party will not listen to your voice. ★ In standby mode, press this key to instantly access WAP, to Album, Profile and Softkey Switch. Pressing it once again will make the screen back to standby mode.
	★ In standby mode, press this key to instantly access shot function. You can then press it once again to take a picture.
	★ Press this key to dial out a call. ★ Answering a call, call hold; or call retrieve by press the key once again. ★ In standby mode, press it to view an overall list of the last 60 phone numbers comprising incoming, outgoing and missed calls.
	★ Press this key to end a call ★ Press and hold it to switch on/off your phone. ★ Press it to return to standby mode while function menu is in progress.
	★ Press this key to switch entry methods.

Key	Description
	★Press this key to erase single character, number, or symbol from the right to left. ★Long press this key will delete all texts or phone numbers you entered.
	★Scroll the keys vertically or horizontally to access function menu, submenu and settings/selections. ★Shortcut functions: Up –SMS menu table. Down – Phone book list Left and Right – Standby pictures display
	★The symbols of numerals and letters. Keypads 2~9 are set as hotkeys; shortcut keys to access 8 main functions. Please refer to hotkey setup instructions for details on page 71.
	★Press and hold this key for two seconds to launch voice mailbox function. Access the voice box number (generally 3 digits) of your telecom service provider before using this phone for the first time.
	★Press and hold this key for two seconds and the “+” will be automatically turn to an international dial-up code. The symbol “+” represents your international dial-up code.
	★Press this key, and “#” sign will be shown on the screen; then enter phonebook address number (SIM: 1 to 3 digits, depending on SIM capacity, Phone Memory; 2001~2250) and press  to dial out this call as the other prompt way to making a call. ★Press and hold it for 2 seconds and then “P” sign will be shown on the screen; then

Key	Description
	launch Voice Dial function as a hotkey. Fast access to make a call with extension number – Enter phone number and long press this key until a pop-up character “P” shows, and then enter extension number and then press dialing key. ★In editorial mode, press the key to switch among input methods and numbers.
	★Press and hold this key for 2 seconds to enable or disable vibration function. ★In English Mode, press this key to switch between upper and lower case. ★In T9 Input Method, press this key to switch among input methods and symbols.
	★Press $\Delta \nabla$ upon this sidekey to adjust volume during a call. ★In folder-close mode, press and hold Δ bottom upon the sidekey to activate self-timer function. First aim the targeted object at the lens of self-timer and long press Δ again to take a picture. ★Press ∇ to end and exit by this function. ★In folder-close mode, press this sidekey upward to activate the backlight of Sub_LCM. ★In folder-close mode, press this key to turn off alarm. ★In folder-close mode, press and hold this key to reject a call.



Alphanumeric Mapping

The alphabetical and numerical keypad mapping relations are listed on the following table:

	Upper Case Mode	Lower Case Mode
1	Space ./\()[]{} 1	Space ./\()[]{} 1
2	A B C 2 Ä Å Æ ç	a b c 2 ä å æ ç
3	D E F 3 É	d e f 3 é è
4	G H I 4	g h i 4 ì
5	J K L 5	J k l 5
6	M N O 6 Ñ Ö	m n o 6 ñ ö ò
7	P Q R S 7 ß	p q r s 7 ß
8	T U V 8 Ü	t u v 8 ü ù
9	W X Y Z 9	w x y z 9
0	Space + - * / () 0	Space + - * / () 0
*	* . , ; ' " _ @ < > ! ª º ⌂ ϕ ø	* . , ; ' " _ @ < > ! ª º ⌂ ϕ ø
#	# / = ? & % ^ € \$ ¥ £ Δ Φ Γ Λ Ω Π Ψ Σ Θ Ξ	# / = ? & % ^ € \$ ¥ £ Δ Φ Γ Λ Ω Π Ψ Σ Θ Ξ

Note:

1. Press  to switch between upper and lower case and symbols.
2. By pressing and holding , you can switch among English letters, symbols and numbers.

3. Pressing a number key in the editing mode will generate the corresponding character appearing on the display.
4. Press again the key immediately after releasing it, and it goes to the next character in sequence as above table. Switching characters will depend upon the duration of the key pressing.
5. After releasing the key and wait for a second, the cursor will move to next spot for new input.
6. If there is any difference between the character sets listed in the table and on the phone, please refer to the displayed characters on the phone.



Display Indicators.



Indicator	Description
	This icon shows the battery power level indicator. The more green area the battery has, the stronger the battery's power capacity is charged. The battery cell flashes right and left before it is fully charged.
	The earpiece has been inserted and available.
	The roaming function is activated
	The vibration call alert is activated
	The mute function is activated. (With blue color)
	Both mute and vibration functions are activated.
	Alarm is activated.
	New SMS is in mailbox.
	Inbox is full of messages.

Indicator	Description
	The signal strength of network connection at your current location. The more the bars are, the stronger the signal is received. (The total is four cells.)
	Shows that the data transmission cord has been inserted.
	CSD Connection is on.
	WAP browsing is in connection.
	Call guard is activated.
	New MMS message is in mailbox.
	MMS Storage capacity is full.
	MMS message is downloading.
	MMS message is sending.

Basic Operation



Making a Call

1. Switch off the power first and properly installs the SIM card.
2. The phone still can be connected with the travel charger and used normally even when the battery runs out of power,
3. Press and hold  for two seconds to switch on the phone. If the display indicates "Enter PIN ", please input the PIN number to unlock your SIM card, (please refer to the Manual provided by the telecom service provider for more details) and then press .

4. Input the area code and the phone number, and press  to dial the number.

Important! : Important! :

Check the signal strength before making a call. The signal indicator on the left side of the phone's screen shows the strength of the network radio signal. The indicator scrolls as the signal strength increases and decreases. To get the strongest signal, try moving your phone slightly. If you're inside a building, move toward a window.



The SIM Card

Your telecom service provider usually offers the SIM card. For the SIM installation, please see on to [page 29](#). This phone can be used only with legally issued SIM cards and receive or send the calls only within the SIM network service range.



Battery and Charger

The Li-ion battery that comes with this phone is rechargeable. Please use the charger and the battery provided by the original manufacturer to ensure safety and a long lifetime for the cellular phone.

1. Place the charger into an appropriate outlet that meets the requirements of this phone. The other end is connected to the phone. While the phone is being recharged, the screen will automatically show the current power recharge status of the battery via a flashing signal. The phone that is switched on can still function normally while being recharged. Once the recharging process is done, the flashing signal will terminate.
2. Once the recharging process is done, the charger can be disconnected from the phone and electrical outlet.
3. This is an international charger (Model is subject to change in different countries). Read instructions on the charger label

before use.

4. A 'battery low' message will display on the screen to alert you to a battery low condition. The phone will automatically shut down when the battery is exceptionally low.
5. If the battery totally runs out of power, the battery needs to be recharged at least ten minutes. Otherwise, this phone may be difficult to be switched on.



Switching on the Phone

To switch on the phone, please hold  for around 2~3 seconds. If the message "Enter PIN:" shows on the screen, the "PIN:" code of the SIM card must be entered in (please refer to the Manual provided by the telecom service provider for more information). Then, press the  to switch on the phone.



PIN and PIN2 (4 to 8 digits)

A PIN (Personal Identification Number) code is stored in your SIM card and is supplied by your SIM card network service provider. To prevent unauthorized use, you need to enter PIN1 code each time while you switch on your phone. Enter the correct PIN1 code and press .

Important! :

1. If a wrong PIN code is entered three consecutive times, the phone becomes locked or disabled. You must ask for your network provider to use the PUK code to unlock or enable the phone again.
2. PIN2 code is for other functions, such as certain number dialing and barring.



PUK1 and PUK2 (8 digits)

The PUK (Personal Unblocking Key) code is required to change a blocked PIN code. Check with your network provider for the code. After getting the PUK1 code and unlocking the PIN1, you

can reset your PIN1.



Calling

Enter the area code and phone number, the press  to dial out a call. The prompt dialing process to reach an extension number is to enter phone number first, pressing and holding  and until "P" shows on the screen. Then you need to enter the extension number right this moment and press  to dial out the phone number. Apply the dialing process will promptly reach the extension number.



Dialing Emergency Numbers

1. Please switch on the phone first. Enter an emergency number "112"; and press  to dial out.
2. Most networks allow users to make emergency calls without inserting a SIM card. In the case of no SIM card, you'll see the  indicator on the bottom-left corner after switching on your phone.
3. In the case of SIM card inserted, SOS sign will be displayed on the down-left corner and without enter 112 number, press  or  keys to dial out.



Correcting an Entry

Pressing the  will erase the last letter or number which you entered.



Answering a Call

Your phone will ring or/and vibrate when receiving a call. Press  or  to answer the call. Press  to terminate the call. If you are using an earpiece, you can press the button of the earpiece to answer or terminate the call.



Recent Calls

The phone will record all the recent calls in which you received, dialed, and missed. Press  to access "Total List" and then



scroll  to browse all recent calls. The recent calls can accommodate up to 30 numbers. Moreover, you can scroll



 to select a number in this option to dial out by pressing . There are seven options for you to operate: "Call", "Move to Phonebook", "Remove", "Add to Black List", "Add to White List", "Send SMS" and "Send MMS".



Speed Dialing

You may quickly search a number stored in SIM card by entering the address (SIM Card: depend on SIM card capacity, Phone memory address: 2001~2250) of a certain phone. Each phone number comes with an address number in phone book.

Under standby mode, you can press  to get a "#" sign on the screen and type in the address of the phone number which you want to dial after the "#" sign. Then, press  to dial a call.



Holding a Call

Press  to put the on-line call on hold while you make another call. When the second call is connected, pressing  allows you to switch between these two calls.



Multi-party Calls

1. If you would like a third party to join the conversation while talking to a party, press  and dial the number of the

third party. Once the call goes through, press  and

 to conduct a three-party call.

2. If you would like to talk to a fourth party, repeat step one to conduct a four-party call. (This system allows a maximum of 6-party call.)
3. If you want to terminate the connection with any one of the parties during a multi-party call, you can follow the steps below:

(1). Press  first.

(2). Press the sequence number in which the party joined the conversation. (For example, the sequence number of the first call is 1 and the one of the second call is 2)

(3). After pressing , the party now can leave this multi-party conversation.

Important! :

Make sure that you do not have a call on hold before making a multi-party call.



Input Methods

Only in editorial mode, you can input desired content in different input methods such as letters, numbers and symbols. This mobile phone features various entry fields coming with name field of Phonebook and name search, file rename of To Album, content of Message, file rename of tone edit, note making in the calendar, notes for alarm, rename of voice memo files, text of greeting, WAP file name, rename of the Profile 1, and the rename of audio and image file names in File Manager and so

forth. Press  to access editorial mode to switch among various input modes. According to the setup of language, you can have default setting of input method in your own language.

However, if you want to change other input methods, press  to input submenu to choose T9 English, ABC (English), 123

(numeric), and Symbols. Press  to switch upper case and lower case in T9 English or ABC English input method. Moreover, you can switch between the present input mode and symbol input mode by pressing and holding . In addition, you can press and holding  to switch between English and Numeric input modes.

More to the point, you can press  to add Pre-Message, Bitmap, Animation or Sound in editing mode


1. T9 English (Predictive Text Mode)

You can only press the key of letter without selecting particular one. The T9 English will smartly predict the word you want.

Switch upper case and lower case by press . For example, you can have upper case of first letter 『Eng 』, or all in upper case 『ENG 』, or all in lower case 『eng 』 by switching  and pressing numeric key 『123 』.

Example : Smart

Press these keys as follows :



Only six steps to bring about a word “Smart” completely. After inputting in 7、6、2、7、8, two words can be selected, “**Smart**”

and the other is “**Roast** “. Press  to select the wording

such as “**Roast**”. Press  to deselect the yellow highlight.

If you want to re-highlight the whole wording, press down key to recover it. 

2. ABC

Press a number key ( — ) repeatedly until the desired character appears. Note that there are more characters available for a key than are printed on the key. Icons  and  indicate the selected case.  means that the first letter of the text word is written in upper case, and all other letters will automatically be written in lower case. To

insert a number in letter mode, press and hold .

Icon  indicates present letter mode. To switch between upper case and lower case, press . If the next letter is located on the same key as the present one, wait until the cursor appears, and then key in the letter.

3. Pinyin

Input the corresponding English letter keys that fit the spelling of a word you want and thus you will see the desired word displaying on the screen. For example, if you want to use Pinyin input mode to get "meili" (美麗) you can input the following keys

 (one input) →  (2 consecutive inputs) →  (3 consecutive inputs) →  (2 consecutive inputs) →  (2 consecutive inputs) to get the word "meili". Use  to switch among upper case and lower case.

4. Symbols

The most common punctuation marks are available under

. You can press  repeatedly to reach the desired punctuation mark. Press  to open a list of specific characters. Use the navigation bar to move through the list and press  to select a character.

5. 123

Press the corresponding numeric keys to secure a number on the screen.

Menu Function

For speedy access to certain options, press  to proceed with Access WAP, To Album, Profile, and Soft Key Switch. Moreover, this mobile phone also features menu functions to meet your needs by manipulating  :

Phone Book

The Phone Book allows you not only to save the names and phone numbers in the SIM card or in the memory of the phone, but also to proceed with the following functions: Search, Add Entry, Edit, Delete, Copy, P. book Setting, Memory Status, Add to Black List and Add to White List. First press  to access Phone Book and a list of phone numbers will be shown. Move the cursor to one phone number stored in phone book and then press  once more to access submenu to manage its functions as mentioned above. The phone memory module has 10 fields, and SIM module 6 fields for content editing or new entry. You can

scroll  to move forward and backward to those fields to enter your desired content and then press to  save. If you

want to access the submenu, press  left/right key. After entering the content, press  to save or  to discard this

record. If there are three sets of phone number, scroll  vertically to select the desired one and press  to dial.



Search

Phone Book provides several quick-search functions.

1. Character Input Search:

When you directly input initial characters or words, the phone will proceed with name search to show the most corresponding

content of the current record. Surely you can press  to enter editorial mode and input the characters or words to get the data you are searching.

2. Caller Group Search:



You can scroll  to search six Caller Groups. When you apply this search function, the caller group icon will display on the top right corner of the screen.

3. Quick Search:

Input the first one letter (or more than one) that fits in with your list, then the first one will be highlighted and all matched data will be listed down.

Important! : When you are trying to change caller groups setting of one certain phone number, its sequence and content in phone book list won't be varied.



Add Entry

After pressing  to access the function, items with new records including storage type (SIM/Phone), name, telephone number, caller picture, caller groups, e-mail, birthday, and record number, will display on the screen.

1. The phone will automatically assign a memory location to save the data on the SIM or handset itself according to your selection.
2. You will need to enter both the phone number and name, and no data will be saved if you leave any of these two items in blank.

In the name field, press  to enter text input mode, and press



again for input methods selection. See on [page 41](#).



3. When you want to create caller pictures, you can scroll to choose instant snapshot, or pictures or graphics stored in Album or Image as your caller pictures. Caller pictures can be stored only in handset memory (NVM).

4. You may assign a caller group to a phone number, and so that you can identify it next time when it comes in. There are 7 default



choices accessible by pressing and choosing from the submenu; those are Family, VIP, Colleagues, Friend, Classmates, Business, and None.

5. Enter E-mail address into the field and save it in handset (NVM).



Press to search underscore "_", and dot "." and input them into E-mail field. This field can be saved only in handset (NVM).

6. Enter the birthday and the date format is dd/mm/yyyy. This field can be saved only in handset (NVM).

7. Normally, the phone will automatically generate an address number on entry field. If you want to assign a memory address to the data, you may enter the address and the phone will save the data into the address you assign. However, if you leave it empty, no data can be saved.

8. Three sets of phone numbers can be saved into handset setting (NVM), and one phone number for SIM card setting.



Edit

This function allows you to modify or edit an existed phone record.



Scroll to pick a saved phone record and press to





scroll to select the field you want to modify. All fields and items are manipulated as the same as above "Add Entry".



Delete

Select this function to remove the phone record from your phone book. After accessing this function, you can press  to choose three deletion options: "Delete One", "Delete All in SIM Card", and "Delete All in Phone". A message prompt will be given to ask for your confirmation of this deletion before data deletion is executed. Press  to delete data or press  to cancel.



Copy

You may use this function to copy single or all phone records to SIM or handset memory at your will. On launching this function, the system will automatically provide you an available position. You may also give a designated position to save your data instead of system assigned number.



P.Book Settings

1. Caller Group

This option is designed to set a ring tone corresponding with a specific incoming call. You can select one of the seven ring tone groups to following accessing this option: Family, VIP, Colleagues,

Friends, Classmates, Business and None by pressing



Press the  key to access this option, scroll  to select the ring tone from the list, and press  to play the tone.

Press the  key to switch the tone you want.

2. Sorting

This function is for you to select the way phone number is sorted in your phone list. You may sort By Pinyin (Chinese Phonetic Alp) or By Alphabet and save the sort setting into the handset.

3. Display SIM Records

There are two display modes. One is to display the phone numbers restored in handset only. The other is to display all the phone numbers regardless phone numbers saved in handset or SIM card. You can switch your screen to show the phone numbers by handset only or by all at your willing.



Memory Status

This option provides inquiry about the total number of records and the empty spaces left for the phone records in the current SIM and the memory of the handset. At this stage, memory capacity in SIM card is a total of 100 records and that in handset is 250 ones. (Note that the memory capacity of a SIM card supplied by various telecom service companies could be different.)



Add to Black List

You can press  to add phone numbers into black list. Phone numbers stored in black list will be blocked and refused to answer.



Add to White List

You can press  to add phone numbers into white list. Only phone numbers stored in white list are authorized to answer.



Camera

The camera lens are embedded on top of the sub LCD screen.

Press  to enter the camera function and set camera options.

Press  to instantly access snap shoot mode.



Snap Shoot Mode

You can take a picture after accessing this mode. Press  to take a picture, and you can hear the camera shoot sound. The pop-up window "Save Successfully" will appear and the taken picture will be automatically saved into photo album and display on the screen. Press  to select more options, including Delete, send MMS, save to Wallpaper, Caller Picture, to Album and rename. Press  to exit by this option.



Self-Timer

In folder-close mode, press and hold  bottom upon the sidekey to activate self-timer function. First aim the targeted object at the lens of self-timer and long press  again to take a picture. Press  to end and exit by this function.



Photo Album

Access this option and scroll  to browse pictures in the photo album. Press  to select more options, including Open file, Send MMS, Save to Wallpaper, Rename, Delete File, Delete all files, File Sort, View, and Detail Info. For more detailed info on these functions, please refer to [page 79](#) File Manager.



Camera Settings

In snap shoot mode, press  once more to access camera settings.

1. Set Shot Mode

In this menu, you can choose and adjust the following settings:

⊙ Shot mode

Aside from normal mode, frame mode, continuous mode, and twice shot, are also supported in set shot mode. When you activate twice shot function, two pictures taken sequentially will be integrated into one picture.

Important! : Twice shot and continuous mode cannot mutually support each other for their different functional attributes and shot modes. Moreover, only images sized by 128 x 143 can be selected in frame mode and continuous mode, and add date and add text as well.

⊙ Size

Here you can pick picture size of largest (**640 x 480** pixels), large (**320 x 240** pixels), normal (**128 x 143** pixels) and small (**64 x 72** pixels), the default is set to normal. The smaller the image size is, the less storage is required; hence more pictures can be taken. Please note that the screen supports normal size. When the image size is **64 x 72**, **320 x 240** or **640 x 480**, the screen display of the image will not be shown, as it should be. Only normal size can meet the screen display.

⊙ Continuous time

Designed to support continuous mode only, this function allows you to take four types of continuous shoots. You can set the shot interval in between each shoot to 0.5 seconds, 1 second and 1.5 seconds, then press  to enable it. When starting this function, you can see the indicator  displaying on the top left corner of the screen. Press  to take the pictures, after all four pictures

had been taken, they will automatically be saved to the photo album and then display on the screen. Press option button  to select more options, including open file, delete, delete all, send MMS, save to wallpaper, caller picture, to album and rename.

⊙ Add Frame

This function allows you to set a particular frame for your picture; five sets of frames are available for you choice. You can enable or disable this function by pressing . Besides, you can press



to promptly switch the frames you want when enabling this option.

⊙ Night shot mode

This function allows you to take picture in poor lighting conditions. You can choose to enable or disable this option. When you enable this option, the indicator  will be displayed on the top left corner of the screen. **Notice that night shot mode doesn't support continuous mode.**

⊙ Add date

You can activate this option to add the date on the image.

⊙ Add Text

- Enable/Disable this option
- Set text position

Set the text to be position on the top, in the middle, or at the bottom of the picture.

- Set color



Press  to access palette and then uses  to select the color.

- Enter content

You could enter the content after the cursor is position in the entry

box · press  to select entry methods.

⊙ Quality

You can also choose among picture quality of low, normal, and high, the default is set to low.

2. Special Effect

This option sophisticatedly supports different special effects for your pictures. These effects comprise normal, embossment, negatives, sketch, oil painting, black/white and sepia.

3. Advanced

Various advanced settings are described below:

⊙ Timekeeper

Timekeeper can be set to 5, 10 or 15 seconds; the indicator  will be displayed on the top-left corner of the screen when this

function is enabled. Press  once again and the picture will be taken after the timer run out.

⊙ Set file name

Press  key to access the entry box and enter the file name.

⊙ Sound effect

You can hear shoot tone when taking a shoot when switching on the camera sounds.

⊙ Info Display

When switching on this option, you can see these indicators below on the screen when they are enabled.



⊙ Softkey display

Here you can choose whether to display the pop-up window by pressing  and  on the screen.

⊙ Set to default

This will restore original factory settings.

Messages

This phone allows you to enjoy sending and receiving a variety of messages. Please contact with your network and telecom service provider for more details on which services you can use.

SMS

Press  to access this menu and further press  to access the submenu's options, including send, send & store, send & save to pre-message, store, and save to pre-message right after you have edited messages and the recipient's phone numbers. "Send" option allows you to send the messages. "Send & store" option allows you to simultaneously store and send the message. "Send & save to pre-message option" allows you to save the message as a pre-message and meantime send it. "Store" will only store the message into the SIM card.

1. Write

Press  to access the message editor. Press  to switch among entry methods. You can add text, pictures, animation, and sounds into your message. If you would like to add pre-messages, pictures, animation or sounds into the message, press  and

scroll  to select the desired items, and then press 

to confirm. You could enter the content after the cursor is position

in the input box · press  to select entry methods · For details on how to use text input methods, please refer to [page 41](#). Before

entering the recipient's phone number, you can scroll  to access phonebook and instantly search the number or enter it instead. After that, you can send, send & store, or store the message.

2. Inbox

When you access the inbox, you will see a list of all received messages (saved in the memory of both the phone and the SIM card) displayed on the screen, including the names, phone numbers of the message senders. All unread messages will be indicated with the  icon. Press  to select and display the content of a message on the screen. For multiple-page messages,

you can scroll  to read the entire message. Press  to select more options, including "delete messages", "forward", "reply", "call" and "store number". "Delete" can allow you to erase this particular message saved in the phone or SIM card. Reply option allows you reply a message to the sender of this message. "Forward" allows you to send this message to others. Call/ Store option will list all the numbers in the messages and you can then select a number to call out or store to the phonebook. To delete all the messages in the inbox, you can select the "delete all" at the bottom of the list.

3. Outbox

After editing a message, you can select "save" or "save and send". You can assign the message to be saved on the phone or on the SIM card. When you select "send and save", the icon  (save

on the handset) or  (save on the SIM card) will show on the screen. When you select "save" only, the icon  (save on the handset) or  (save on the SIM card) will show on the screen.

4. Delete message

Similar to the delete function above, press  and you will be prompted to confirm whether to delete the selected message from inbox or outbox.

5. Free count

This option allows you to check the total amount of messages that can be stored plus the amount of free space available currently on both the phone and the SIM card. Message will be saved into the phone by default, and will be saved into the SIM card once the phone is full. The total amount of messages that can be saved into the phone is 100. The total amount of messages that can be saved into the SIM card will depend on each individual SIM card storage capacity.

⊙ NOTE:

If messages in inbox/outbox are particularly long, they will be regarded and calculated as two, three, or more messages. Therefore, the free space displayed on the screen will be identified less than the total amounts of messages minus the realistic number of messages in inbox/outbox.

6. Settings

⊙ Pre-Message

Here you can add up to eight frequently used messages and save them as pre-message.

These messages are all empty by default.

⊙ SMS Center

This menu item allows you to set the SMS center number. (Please contact your network service center for details)

⊙ Validity Period

If your message fails to be delivered for some situations such as that phone is switched off, your message service center can save the message and send it later until the valid time expires. You can set the validity period on twelve hours, one day, one week, one month, or maximum period.

⊙ Auto Display

When you activate this option, a notification will appear after a message is received, you could read it at once or later. If this

option is disabled, you can only see the indicator  displaying on the screen plus a prompt tone when a message is received.

⊙ Status Report

When you activate this option, you will be notified by the SMS center once the message you sent has been delivered to the recipient.

⊙ Storage Area

This allows you to save the message on the phone or on the SIM card.



MMS

The Multimedia Messaging Service (MMS) is, as its name suggests, the ability to send messages comprising a combination of text, sounds, images, slides and video to MMS-capable handsets. More to the point, the contents in the MMS can be presented as slides. This phone is capable of sending a MMS of approximately 50K at a time. The total storage on this phone is around 5 MB for you to save all your text, pictures, animation and sounds.

1. Write

⊙ New

This option provides you with the function to compose your personalized MMS. First access the entry and editing area, press



to promptly bring up a list of entry methods coming with T9,

ABC, numbers, emotional icons and regularly applied Internet



symbols. Scroll to select from the different entry methods and press  to confirm. The entry methods you select will display at the bottom-right corner.

NOTE Ø If the warning message “MMS connection not set” displays after you attempt to compose a new message, please set the MMS connection by selecting your network service operator from the default connection list. (MMS Settings > Connection > Add from list)

Here you can add text, images, slides or sounds into the



messages. Scroll to select and switch among the options and then press  to confirm. Press  to return to the previous menu.

In text entry fields, press  to access and use



to select an existing template you want to edit or start in editing a whole new message. Refer to the description on the previous page on how to edit contents while in entry field. As for adding new images, you can select which folder you want to add it from photo album or image folder. To add a sound, you can simply select a



sound file. To add a slide, scroll to move the cursor to “+” mark and then press  to confirm and go into next slide. Before pressing  to exit from editing status, you can save it as a draft and enter file name if necessary.

MMS menu options include:

□ Send message

Press  to access the option and press  again. Select "yes" to send the message when the dialog "Send

this 1K message" displays on the screen. Scroll to move the cursor to "Address Book..." and then press  to assign a number from the phonebook or else you can instantly access into the entry fields. If you try to enter several addresses, you need to separate them by a space. After you complete the entries, press  to

access option menu. You can scroll  to move the cursor to select the function options in which include send MMS, send E-mail, cancel and advanced. Press  to select an option. Advanced includes the following a-d options; press  to access an option , press  to save and return to the previous menu.

a. Message title : When you select this option, press

 key to access the input field, press  once again to start in content editing. For detail description on input method, please refer to [page 41](#)

b. Delivery timing : Delivery time allows you to set the date and time for the message to be delivered to the recipient. Validity Period allows you to set how long the message will be available for the recipient to download; you can set it to

30 minutes, one hour, six hours, one day and one week.

c. Carbon copy (cc) and Blind carbon copy (bcc): Scroll



to move the cursor onto Cc...
或 Bcc... to access phonebook, or
move the cursor and press  to
enter the input field. Then press 
once again to start in content editing.
For detail description on input method,
please refer to [page 41](#)

d. Message Format: MMS or E-mail format is optional.

☐ Preview

Various materials in MMS such as text, images and sounds can be previewed.

☐ Save

You can save the contents of the message as a draft and complete it anytime. Or you can save it as one of your templates.

☐ Settings



You can scroll to move the cursor then press  to select from the two options; slide duration, and slide format.

a. Slide duration : You can set the duration (5/20/40/60 seconds and manual setting) of every slide to be displayed in a MMS.

b. Slide format : You can set how the image is position on the screen with four different options: at the bottom, on the top, to the left or to

the right.

☐ Add slide

You can add a new slide if necessary.

☐ Delete slide

This option enables you to delete a slide.

Important! : For this phone, each MMS permits a maximum capacity of 128x143 jpeg file.

⊙ From Templates

There are two defaults MMS templates to choose from. Simply select and open the template you wanted to start in editing it.

2. Inbox

All incoming MMS messages will be saved into Inbox. Same as regular messages, the system will also lists the information of sender, so you would know the MMS is sent by which mobile phone number or email account. The formats and methods of receiving MMS depend on the service that provide by your service provider.

3. Outbox

When a MMS is sent, if the receiver's mobile phone does not support MMS function, a SMS (short message) will be sent to your mobile phone to inform you. You may also connect to the Internet via WAP function for sending and receiving MMS.

4. Drafts

You may save the incomplete messages as a draft, and go back to modify it anytime at your will.

5. Sent

Users may also save all sent messages. When a message is sent successfully, it will be saved under the folder of Sent

6. Templates

Select the name of template and press  button to open or delete it. If no template in memory, it shows empty template.

7. MMS Settings

You can use this function to set up the connection for receiving MMS.

⊙ Connection

┆ Add New:

Allow you to add a new connection, please refer to [page 92](#).
WAP connection set up.

┆ Add from list

⊙ Reception

┆ Always

┆ Never

⊙ Message Validity

┆ 1 Hour

┆ 6 Hours

┆ 1 Day

┆ 3 Days

┆ 1 Week

┆ Maximum

⊙ Allow Advertisement

You can turn on or turn off the advertisement function.

⊙ Save Sent Msgs

Allow you to automatically turn on or turn off to save the messages that are sent.



Broadcast

The network operator sends broadcast messages to all users in a certain area. Please contact your network operator for more details on whether they provide this service.

1. Read

This allows you to read the last broadcast message received. The phone stores this last message only when it is switched on.

2. Filter

This allows you to select the type of cell broadcast messages you want to receive. The filter menu contains a list of codes for CB type of messages, which are defined by the network service.

⊙ All

Receive all broadcast messages.

⊙ None

Receive no messages.

⊙ List

List all the channels in which you want the messages to be received. Depended on different broadcast area, the number of the channel will be different. By pressing the , you can access selection menu to add or delete.

3. Auto Display

This allows you to switch the auto display function on/off. When the function is set on, broadcast messages will be automatically



displayed. Scroll  to view the messages. Pressing OK or NO allows you to exit. Broadcast messages automatically disappear after a short period of time.

(Note: The function requires the support by telecom service provider. Contact you telecom service provider if you want to use this service.)



Voice Mail

⊙ Listen to voice message

Here you can directly dial out the default voice mailbox number.
(You need to set your mailbox number before using this function.)

⊙ Voice mailbox number

Here you can enter your voice mailbox number. The number you entered will be saved on the phone. If you change the SIM card (provide by different network operator), please also change the corresponding number; otherwise you can't successfully dial out. If you have not set up your voice mailbox number before, you will be prompted to enter it when you press the voice mailbox hotkey



Please contact your network operator for the voice mailbox number.

⊙ Note

You could directly access your voice mailbox by pressing and holding  in standby mode.



WAP PUSH Message

WAP (Wireless Application Protocol) PUSH message is an application platform that enables enterprise owners (need to rent WAP PUSH brief code or specific code transaction) to send, search PUSH Message interface. Users can compose programs and the interfaces to send and search WAP Messages. This built-in WAP2.0 browser enables you to browse WML- written WAP WebPages. In addition, the inbox of WAP PUSH Message can receive a variety of functional services from Internet service provider such as news reception or MMS notices. You can press



to instantly access WAP browser to glance at website addresses and the contents only if the message is already connected to the website address. When "Alert Inbox" shows on

the screen, press  or  and then push  to use the functions below. Press  to return to previous step.

⊙ NOTE:

WAP 2.0 Push (HTTP & WSP) requires network service provided by telecom Service Company. The definition of  and  operations are made by the websites themselves. In general, short pressing  is back to previous command/step and long pressing  is back to previous page. In WAP browser, the screen will be back to WAP main page when you long press  and short pressing  will be return to the standby mode.

1. Home

In this option you can browse and use function list in the main page.

2. Bookmarks

Access this option and press  to browse mark sites, or press  once more to manage these options, including "new bookmark", "new folder", "delete all" and "Hotkeys". Please refer to [page 89](#).

3. Go To URL

You can shift your WAP Push messages to the desired website from current one (URL). In text entry area, you can enter a URL as well as WWW entry mode.

4. Save Items

This option will record the saved items and content.

5. History

An indication of alert inbox is shown in this option. Press  to display URL or delete history records.

6. Reload

Access this option to reload and browse WAP Push messages.

7. Forward

Access this option to forward WAP Push messages.

8. Snapshots

You can enable snapshot functions in this option.

9. Advanced

⊙ Restart Browser

Access this option to reboot the browser.

⊙ Delete Cookies

In this option you can decide whether delete all cookies or not.

⊙ Multimedia

You can decide whether disable Images/ Background Sounds/ Objects Downloads or not.

⊙ View Title Region

In this option you can view title region and wrap text in title region.

⊙ Scroll Mode

Scroll Modes : Block / Smooth

Scroll Speed : Fast / Medium / Slow

⊙ Send Referrer

This option enables you to turn on / off HTTP send referrer header.

⊙ Key Press Timeout

In this option you can adjust four key pressing timeout levels: fast, medium, slow and off.

⊙ Circuit Prompt

In this option you can turn on or turn off the circuit.

⊙ Security

⌋ Secure Prompt

- › Current Certificate
- › CA Certificates
- › Authentication

Profile

There are five profiles (Typical, Silent, Outdoor, Handsfree, and Profile1) to meet your different needs. Select a desired profile and push “Activate” to enable profile function. If you want to personalize the profile, launch the Adjust menu and select the item you want to personalize.



Adjust

You can change the setting of the follow profiles with this function.

1. Activate

Activate the settings of the profile you want.

2. Ringtone and Volume



Scroll  to select the ringing tone pattern. When you select and play the tone, you can set the volume of tone at the same time. There are 19 ringtone patterns for your option, including 15 in-built tones, 3 tones and one random-play tone. Please refer to all downloadable ringtones under audio of file manager in Multi Media. You can hear the ringtone and then press  to access



the tone and use  to adjust volume.

3. Key Sound

You can set on/off the volume of the keypad tones. They are

DTMF, Silent and Normal.

4. Crescendo

In this menu, the ring tone's is adjusted to a gradual increase in volume of a musical passage. You can select to turn it on or off.

5. SMS Rec Tone

When receiving SMS message, the phone will alert you with ring. You can select to turn it on or off.

6. Calling Vibration

Access this option to switch on/off calling vibration.

7. Message Vibration

Access this option to switch on/off message vibration.

8. Service Tone

When this function is set on, the phone will generate a tone when a network is available.

Call Lists

This menu records the charge info and the length of time or duration of all incoming and outgoing calls in hours, minutes, and seconds. Please contact with your telecom service provider for more charge information.



Massed Call

In this menu, the screen will display all the missed calls. You can



scroll to select one of missed calls and press  to execute the following optional functions coming with "call", "move to phonebook", "remove", "add to black list", "add to white list", "send SMS" and "send to MMS". An accessional option listed at

the bottom of this menu is "Delete All".



Incoming

List all of answered calls. The functions are the same with above.



Outgoing

List all of dial-out calls. The function is the same with above.



Call Info

This menu records the charge info and the length of time or duration of all incoming and outgoing calls in hours, minutes, and seconds.

1. Last Call

This submenu displays the duration of the last call. Press  to clear present info.

2. Total Calls

This submenu displays the total duration of all incoming and outgoing calls. Press  to clear present info.

3. 1-minute Beep

This submenu features a charge-saving beep that begins at the 55th second of each minute while a call is in progress. This function enables you to control the duration of each outgoing call.

4. Charge Info

This submenu allows you to set a restricted call charge and charge rating. Also, it is able to calculate total call charge to facilitate charge control.

Note: this function including Total Charge, telecommunication service provider will support Max Charge and Unit Price. Please contact with your supplier for detail.

⊙ Total Charge

This submenu displays the total charge of all calls. Pressing  allows you to reset the value, but it requires entering PIN2 before you do.

⊙ Max Charge

This allows you to set a maximum limit to your total cost. You can't dial any number if you go over your limit until the total charge has been reset. As similar to total charge, you need to enter PIN2 for setting.

⊙ Unit Price

This allows you to enter the unit price. After entering your PIN 2

code you can input price and unit. Scrolling  allows you to select different entry fields.

Settings

Personal

1. Language

You may choose English or Spanish as your phone language.

2. Greetings

You may enter greeting words in the edit window so that the phone will display greetings each time you switch on this phone.

3. Power On/Off Melody

You may select one of the melody types that will play each time you switch on this phone.

4. Folder On/Off Melody

You may select the melody that will play whenever you open or close the folder.

5. Hot Key

This option features 8 shortcut keys (long numeric key 2-9) with the following functions:

Long Key 1 is predefined as Call Voice Mail Box.

2. Messages -----	Long Key 2
3. Silent -----	Long Key 3
4. Show Clock -----	Long Key 4
5. Calendar -----	Long Key 5
6. Calculator -----	Long Key 6
7. Record -----	Long Key 7
8. Game-----	Long Key 8
9. Standby Mode -----	Long Key 9

In idle mode, this function allows you to activate long-key shortcut function by pressing and holding a designated key for two seconds.

If users want to change the programming of shortcut keys, please follow the procedures described below:

- Enter the menu. Scroll  to select the numeric key for setting. Press  to confirm.
- Then scroll  once again to choose the functions and set. Press  to confirm.

6. Own Number

You may store the SIM number in the phone.



Clock

You may set time, date, alarm and auto power off with the clock setting function.

1. Set Date

After accessing the menu, scroll  to select setting date, time, data format and time format. If you select 12-hour system,

the cursor will stop at AM/PM. Scroll  once again to select

AM/PM. You may scroll  to select date and time formats. Available date formats: yy/ mm/ dd or dd/ mm/ yy or mm/ dd/ yy. Available time formats: 24-hour or 12-hour

2. Set Alarm

In this option, there are a variety of alarm melodies for alarm

setting. Scroll  to set the date/ time, alarm melody, snooze on/off and notes of the alarm. In alarm mode you may select alarm on/off from Sunday to Saturday. Alarm notes

Snooze on /off Settings:

(1). In folder-open mode, snooze function can be infinitely activated when turned on. Choose "Snooze off" to disable this function.

(2). In folder-close mode, pressing  can simply turn off alarm while snooze function will be still infinitely activated and can't be turned off.

(3). In folder-open/close mode, snooze function can perform four times when no action is carried out. Notice that each interval is five minutes and the total duration of snooze is 20 minutes

3. Power Off

In this menu, you may set the function and the time of turning off your handset daily.



Screen

1. Standby mode

There are two standby screen modes: picture and text and calendar.

2. Network Name

This option enables you to display the name of the telecom service company on the screen.

3. Show Clock

This options enables you to set "show clock" to display time and date on the screen.

4. Standby LED

Access this option to activate Standby LED. When this function is enabled, the standby LED will flash each five-second interval.

5. Contrast



Scroll to adjust shading value of the screen.



Call Setting

1. Call Waiting

You may set the call waiting function in this menu.

⊙ Activate

When activating call-waiting function, you will be alerted by audio and video signals right after another call is coming in during making a call.

⊙ Cancel

If you cancel this function, the phone won't alert you of another incoming call but directly divert that call to other number or your

voice mailbox.

⊙ Status

It reports current status for Activate or Cancel

2. Divert

Call divert is a common telecom service. When you are unable to answer a call or the signal is out of service range, you can divert all incoming calls to another assigned number.

⊙ Forward to

Set the number that you assign your unanswered calls diverted to after a 15-second delay. (The default delay time is 15 seconds). When a call comes in, the phone will divert the call to the preset number after the delay time.

⊙ Unreachable

Turn on/ of "divert when not reached" function.

⊙ If No Reply

Turn on/ of "divert if not answered" function.

⊙ All Calls

Turn on/ of "divert all calls" function.

⊙ If Busy

Turn on/ of "Set 'divert when busy" function.

⊙ Status

Turn on/ of "Get status of all divert " functions.

⊙ Cancel All

You can access this option to cancel the setting for diverting all incoming calls.

3. Answer Mode

⊙ Normal answer

Press  to answer an incoming call when this function is enabled.

⊙ Any key answer

Press any key to receive an incoming call.

⊙ Folder answer

Open folder to answer an incoming call.

4. Present Number

This option sets the handset to show or not to show its phone number when dialing out a call.



Network

You have to complete registration in the telecom Internet service center before using your mobile phone. When you switch on your phone, the telecom Internet name you used last time will be searched out and presented. The mobile phone will try to register a new telecom Internet in case of some reasons that leads the disconnection to the original telecom Internet service center.

1. Select Method

When the phone is switched on, it looks for available networks and then selects one of them. You can also manually select the desired network from the list.

2. New Search

You can search available networks and manually select one of them.

3. Select Sequence

You can add the networks by manually. Enter the Country Code and Network Code to add the new network into the list.



Security

1. Bar Calls

Call barring is a telecom-network function that enables users to bar both incoming and outgoing calls in different conditions. Enter the Supplementary Services Password (obtainable from telecom

service provider) before setting up call barring. Please set mailbox to OFF before applying call barring.

⊙ All Out

You may bar all out calls (except emergency call) with this function.

⊙ Out Intl

You may bar all out international calls with this function.

⊙ Out X Home

You may bar all out international calls during roaming except calls to home country.

⊙ All In

You may bar all ingoing calls with this function.

⊙ In If Abr

You may bar all ingoing calls (roaming) when you are abroad with this function.

⊙ Status

You may check the status of call barring with this function.

⊙ Cancel All

You may cancel all barring.

Note: The availability of barring services is subject to the network functions.

2. PIN Check

Access this function to enable or disable PIN protection function. When switching on the phone, you have to enter PIN first so as to access the network-searching screen.

3. PIN Change

Make sure that you have PIN enabled. When you switch the power on, the phone will prompt you to input the PIN number.

4. PIN2 Change

Changes the PIN2 number. You need to input the original PIN2 number before you make changes. (Please contact your

telecommunication company for detail.)

5. Fixed Numbers

This function only dials the numbers in the fixed dialing phonebook. (It needs the PIN2 number).

6. SIM Lock

This function allows you to lock the phone with a specific SIM card. This feature is designed to prevent somebody else from using your lost or stolen SIM card(s).

⊙ Set Lock

Access this option to activate the SIM lock function.

⊙ Change PCK

This allows you to change PCK code.

Note: The factory default PCK is supported by the manufacturer is (0000).



Call Guard

Access this option to set phone numbers into the black/white list. The call guard- listed incoming phone calls will be rejected

1. Black List

⊙ Add Entry

The five methods to add your phone records into white list include "Manual", "Add from phonebook", "Add from call list", Add phonebook groups", "Add unknown numbers".

⊙ Edit

In this option you can edit a certain phone record and name in black list.

⊙ Search

In this option you can search for a record saved in black list via the search of name and phone number.

⊙ Delete All

You can access this option to delete all data saved in black list.

⊙ Delete

You have deleted a certain number record after you set this option.

2. White List

⊙ Add Entry

This option is In common with above “Add Entry” in black list.

⊙ Edit

In this option you can edit a certain phone record and name in white list.

⊙ Search

In this option you can search for a record saved in white list via the search of name and phone number.

⊙ Delete All

You can access this option to delete all data saved in white list.

⊙ Delete

You have deleted a certain number record after you set this option.

3. Call Guard Settings

⊙ Activate Black List

When you activate the option, the black list is set as call guard.

⊙ Activate White List

When you activate the option, the white list is set as call guard.

⊙ Deactivate All

You can set this option to deactivate call guard.



Reset Setting

In this option, you may decide whether you want to convert the settings of your handset to the reset settings.

MMedia

File Manager

In file manager menu, Album, Image, Audio, and OSD frames can be manipulated by a variety of functions below:

below:

You can select a file to carry out a variety of functions below:

⊙ Open File

Select a file in Album and press  to open it as full screen display.

⊙ Send MMS

Scroll  to select a file and press  to send MMS. Please refer to [page 61](#) for detail.

⊙ Save as Wallpaper

You can save the file as wallpaper.

⊙ Rename

Select a file and access dialogue box to rename the file name.

Press  to enter content and chputoose OK to modify the file name. See in methods on [page 41](#). Notice that Chinese entry mode is not supported.

⊙ Delete File

Delete the selected file.

⊙ Delete all file

Delete all files saved in Album

⊙ File Sort

┆ By Name

- ┆ By Date
- ┆ By Type

⊙ View

- ┆ List



Scroll to display selected image.

- ┆ Icon

Display 9 image files on the screen at the same time.

⊙ Detail Info.

The detail information will include image type, file name, file date, and file size.

Free Space

This option indicates the total space stored and free memory.
Note.

⊙ NOTE:

This mobile phone permits a maximum of 50KG file. In addition, it only supports jpeg graphic format while uploading and downloading. Notice that a graphic file larger than 128 x 143 jpeg can't be viewed.



Game

1. Game

⊙ Hostage Salvation

First secure picture for bad guy from camera snapshot or from what was used in last game or file manager to start game. Use 1 to 9 numeric keys to shoot the corresponding pictures on the screen. In Level I, shoot the bad guy to add 10 scores and shoot the good guy to deduct 5 scores. Besides, each surplus second

you have can add a score. In Level II, shoot the bad guy to add 20 scores and shoot the good guy to deduct 5 scores. Each surplus second you have can add 2 score. This game enables the user to turn on or off the game sound. When the game is in progress, press  to pause and press  to exit.

⊙ Reversi

Before starting a game, the sequence order must be selected ("Play First" or "Player Later"). When the game starts, you can use



to position the black piece. Press  to confirm the surrounding of white piece. When the chessboard is full of pieces, and there are more blacks than whites, the black will win the game. The game under this section allows you to save and continue the game without restart over every time. Press  to save your scores and pause. Press  to continue the game. You may also save the scores and exit after pressing . Next time you access the same game; select stored game to continue the game when you exited last time. Any incoming calls while playing games, you may press  to answer the call and save the game that is being played.



Tone Edit

In this function menu, you can create your own tones and setup them as your ringtones under Audio Profile. There are total 5 tones for you to edit. Press  to enter edit mode including play, edit, reset, tempo, instrument, and name.

1. Play

This section allows you to display the edited melody from the mobile phone. Press  to exit while playing. Otherwise, the system will exit until the melody is complete played.

2. Edit

⊙ Keypad functions

Numeric 1~7 represent the musical notation from Do to Si, 60 notes can be entered.

 High octave

 Delay in one beat for previous note

 A rest

 Raise half tone or a dot to extend half beat for previous note.

 One extends (half beat or a quarter beat) and lower.

⊙ Edit

follow the steps below :

a. Press numeric pads 1~7 to select note. Press  to delay in one beat for previous note, display on screen as "-". Press  to enter a rest note displayed as "0 "

b. Press  to switch into higher octave

c. Press  to raise or lower half tone, "#" or "." is displayed on screen.

d. Press  to switch for long note "-half tone = a quarter tone" and for lower octave "." If higher octave is selected, there won't be any mark for lower octaves.

e. After a tone is edited, press  up and down to move the cursor to the next position, and then continue editing the next tone.

f. If the setting is not correct, please move the cursor to the incorrect symbol to have direct revision or move the cursor to last the note and press  to delete the note and re-enter.

g. Once editing is complete, press  to exit. If users want to restore the original setting, press  to cancel the editing.

3. Reset

When you have confirmed to tone reset settings, the defined tone will be clear.

4. Tempo

There are five modes: More slowly, Slowly, Normal, Fast, More fast. You can select any of the modes to adjust the rhythm.

5. Instrument

Select the instrument to edit the tone including BritePno, Marimba, Harp, Crystal, and Banjo.

6. Rename


Allow you to enter the name for the tone. Under dialogue box, press  to enter edit mode. For Input methods, please refer to [page 41](#)

PIM

A variety of functions are available as your personal convenient tools

Calculator

1. Enter the operational digits when you see "0" is shown on the screen. (press  key for adding decimal point)
2. Choose operational sign: See on the screen



3. Enter second number.

4. Press or key to get the result. If a mistake is made during the operation, press key to make a correction. Press and hold for a few seconds to clear all the digits.



Calendar

You may check your reminders in this menu. First, the current date will be displayed.

Scroll until the cursor moves to the desired date, and

search the desired month by scrolling . Then, press to create calendar menu, and press to exit menu. You

may scroll to select a reminder, and then push to launch the selected reminder menu (View Day Note, Make Note, Erase Note, View All Notes, Go To Date).

1. View Day Note

Select today's reminder to view content, and push to edit or erase content.

2. Make Note



Press  to select reminder types including Meeting, Birthday, Anniversary, and Customize.

 Set date:

 Set time:

 Set alarm: After the time and date of the reminder are set,



press  to set the alarm (5/10/15 minutes before) for the reminder,

You can enter the memo into the reminder field, See enter input methods on [page 41](#) Press  to terminate the function.

3. Erase Note

Select erase types: erase reminders of chosen day, erase one by one, erase all, and auto delete. In auto delete, there are 3 items; they are auto del 1 month before, auto del 2 month before, and auto del 3 month before.

4. View All Notes

While checking all the notes, press  to enter the delete,



modify or move data menu option. Press  to view the content of each individual note. If the content length is longer than



one page, press  key to change pages.

5. Go To Date

Enter the date on which you want to receive the reminder.



Exchange Rate



For first time users, press  to move cursor to Set Rate to enter exchange rate for both Domestic and Foreign. After setting, enter the Domestic currency value, the Foreign exchange value will be automatically calculated on the screen.



Voice Memos

Voice reminder allows you to record a maximum 20-second audio input. The main advantage of this function is to assist users in record messages when they do not have a pen and paper at hand.

1. Record

When users want to record messages, they simply access this menu and press the "Record" key to start the voice recording process.

2. Playback

⊙ Playback

When you want to play the messages, simply access this menu and press the "Play" key to listen to the recorded message. If there is a * mark before a certain record, it means the message has not been played before.

⊙ Delete One

In this option, you can delete the saved records individually.

⊙ Label

In this option, you can check the time, date and record length of a certain recorded memo.

3. Options

In this option, you can select one of the following methods of memo recording:

⊙ Self Only

When this function is on, it can only record the conversation of this phone content.

⊙ Other Party Only

When this function is on, it can only record the conversation of the call content.

⊙ Both

This function enables you to record directly from the caller and the

content of conversation. When on the line, press  to enter record item, and press  to confirm recording.

Note: The 'two-way recording' (default) will be resumed after

each recording. Press  or  to record the conversation while a call is in progress.



World clock



In this option, you may press  keys to browse the current time of the place over the world.

⊙ Set Location

You may set your present location to browse the time in different countries with the time display function.

┆ Automatic

The mobile phone will automatically set the location for you.

┆ Manual

You may select your own location with the manual setup.



MC Management

This option is an in-built menstrual calendar and ovulation predictor. It is designed for females to record their ovulation cycle. All you need to know to get started is the length of your menstrual cycle and the date of your last period. Simply enter these data and Ovulation Calendar will do the rest! There are four options available for your Set Date, Query, Female Note, and Delete All Date

⊙ Set Date

Simply enter the length of your menstrual cycle and the date of your last period and then press  to save. Your menstrual day



will display on the screen. You can scroll  to check the date of ovulation and the date of having the chances of conceiving a boy or a girl.

⊙ Query

Ovulation Calendar will calculate your fertile days on the screen right after you enter your last menstrual day and period. .

⊙ Female Note

This option provides brief note necessary to know, including the natural method to calculate your menstrual day so that you can know the possibility of conceiving a boy or a girl and also avoid an unwanted pregnancy.

⊙ Delete All Date

Access this option to delete all data and dates saved in ovulation calendar.



WAP (Wireless Application Protocol)



Access WAP

You can use this function to browse the World Wide Web to get the latest information. The data will appear in a special format compatible with your mobile phone. You might have to register with your system service provider to be able to connect to the World Wide Web except HTML websites.



Favorites

You can use bookmarks to connect the Internet. There are 1-12 my Favorites are set on screen. Browse them by

scrolling . Press  to access Internet on the selected item,.

Press  to select other function such as New Bookmark, New Folder, Delete all, and Hotkeys.



If there is not existed bookmark within folder, manipulate to move the cursor to the context, and build new bookmark and Hotkeys. If the bookmark exists, then it will display with title, URL, and folder name that can be modified and saved.

1. New Bookmark

Press numeric key 1, and enter Title and URL to save as a bookmark. To enter the field of Title, press  to enter edit mode first, and press  button to select T9 English, symbol, numbers, Emotions, and ABC entry method. You may also press



 to select a exist Title. When using T9 English and ABC method to input, you can press  to switch upper case and lower case or first letter capital.

Press  to go to the bottom of screen, a Save button appears on screen, press  to save the bookmark; press  to go back to Bookmarks menu.

2. New Folder

Press  to enter Folder edit mode. Press numeric key 2 to create a new folder. After entering edit mode, use the same input methods as above. After entering complete text, repeat

pressing  until a "Save" button shown on screen, press  to save data. Or you can press  to return to Bookmark menu.

3. Delete all


This option allows you to delete all folders and bookmarks.

4. Hotkeys

There are 1-9 numerics keys enable to be set as hotkeys. If you want to assign numeric key 1 as a hotkey for the specific website,

use  to move the cursor to "1 Unassigned" and press

 to go to bookmark list. Press  to select that specific website URL. Press  to select the bookmark to complete the hotkey setting.

Graphic and Message of Browser

Shows the version of OPENWAVE and Copyrights.

Definition of WAP Keys

	Back to the previous page, according to WML definition.	Back to previous page
	Back to standby page.	Back to WAP main page.
	Clear a character or a letter	Clear all characters or letters
		Alert Inbox shows.

1. In standby mode, you can press  to connect Internet and browse websites.
2. My favorites will indicate images or pictures as number order like 1.2.3....8
3. When you choose CSD as your transmission method in use of WAP, the icon  will display on the screen. When the connection fails, the icon will disappear.
4. When you choose GPRS as your transmission method in use

of WAP, the icon  will display on the screen. When the connection fails, the icon will disappear.



Go To URL

This allows you to set up the protocol web site.



WAP Settings

You can set a connection file name from the connection list. The icon  showing on the left side of the file name is the default one.

Press  to access setting mode.

1. Connection

You can select one of the . The connection will be made through the chosen file.

⊙ Add New

⌋ Name

Access the "name" function screen, you can clear the preset file name (press the  key), and rename it.

⌋ Homepage

You can reset the homepage by pressing the  key to clear the preset Web address and then entering the new web address.

⌋ IP Address

Access this function to set the IP web address you want to connect to.

⌋ Bearer

Supports both GPRS and CSD.

┆ User name

Access this function to set a username to register to the WAP website. The function needs to be supported by your telecom service provider.

┆ Password

Set the password for logging in the WAP website.

┆ DNS IP address.

Set DNS IP address to register to WAP website. Telecom service provider provides the service.

┆ Linger Time

Modify Linger Time for connection, press  to enter Linger Time field. The default setting is 90 seconds. (Unit: second)

┆ APN

If you select GPRS to browse information, you need to enter the Access Point Name of your system service provider.

┆ Security

This function provides the Internet security service, you can enable or disable this function.

┆ Store

Save all settings.

⊙ Add from List

You can choose the WAP connection system from the list.

2. Color Scheme

Color palette provides three colors: Blue, Red and Green.

3. Clear Cache

This option allows you to clear all data from Cache temporary memory.

4. Reset all

Select this option to go back to WAP default setting.

 STK (SIM TOOL KIT).

This selection menu can be displayed if your SIM card supports Value-added Services. Regarding the details as to how to use SIM services, as well as price and other information, please contact your telecomm service company.

Important:

Your telecom service provider offers the STK service. Your telecom service provider defines the name of menu, title, and content. Due to the content size may be too big to fit into the screen of your mobile phone; some of text may not be displayed.

Battery

- ⦿ The battery is rechargeable up to hundreds of times, but its capacity will reduce. You may need to replace a new battery when the operation duration (calling and standing duration) reduces evidently.
- ⦿ Remove charger from the source each time after charging. Over charging will shorten the life of the battery. Avoid charging a battery for over 24 consecutive hours.
- ⦿ Use only batteries certified by the mobile phone manufacturer.
- ⦿ Extreme temperatures will affect charging performance. The desirable ambient temperature for charging is 0°C-45°C (32°F-113°F).
- ⦿ Do not use damaged or old batteries.
- ⦿ Avoid contacts of the + and – poles of the battery with metals, such as coins, scissors, and pens. It will damage or cause short circuit to the battery. Place spare batteries in a safe place or wrap them up with insulated materials before putting inside your pocket or handbags.
- ⦿ Extreme temperatures will reduce the capacity or shorten the life of batteries. Avoid placing batteries in extreme temperatures, such as inside vehicles or near air-conditioner outlets. The desirable battery storage temperature is 15°C-25°C (59°F-77°F). Batteries that have been charged may not work properly in extreme temperatures.
- ⦿ Keep batteries away from water or fire.
- ⦿ Dispose batteries according to local environmental regulations.

Care and Maintenance

Follow the instructions below to take care of your mobile phone. They will help you to enjoy life with this product.

- ⦿ Keep the mobile phone and its accessories out of children's reach.
- ⦿ Keep the mobile phone dry. Rain, moisture and liquid contain minerals that will corrode the circuit of the mobile phone.
- ⦿ Keep the mobile phone away from dirt or dust.
- ⦿ Keep the mobile phone away from heat. Heat will shorten the lifespan of electronics, damage the batteries, or even deform or corrode the shell of the mobile phone.
- ⦿ Keep the mobile phone away from coldness. Condensation takes place and the moisture will damage the circuit board when the mobile phone resumes normal temperature.
- ⦿ Do not open the mobile phone. Non-professional treatment may cause damage to the mobile phone.
- ⦿ Avoid falling, impact or vibration of the mobile phone. Improper external force may damage the circuit of the mobile phone.
- ⦿ Do not clean the mobile phone with chemical solutions or detergents. Gently wipe the shell of the mobile phone with a soft cotton cloth and clear water or mild soap.
- ⦿ Use accessories and batteries from the manufacturer.
- ⦿ Contact your nearest service station if the mobile phone is out of order. Our well-trained technicians will provide you the best service.

FCC Regulations

Conditions of Use

Operation of this TG7E mobile phone is subject to the following two conditions; (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This TG7E mobile phone generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. If this device does cause harmful interference to radio or television reception, which can be determined by turning the device on and off, the user is encouraged to try to correct the interference by one or more of the following measures:

- 1). Reorient or relocate the receiving antenna.
- 2). Increase the distance between the device and receiver.
- 3). Connect the device into an outlet on a circuit different from that to which the receiver is connected.
- 4). Consult the dealer or an experienced radio/TV technician for help.

The radiated output power of this internal wireless radio is far below the FCC radio frequency exposure limits. Nevertheless, the wireless radio shall be used in such a manner that the radio is 1.5 cm or further from the human body. However, the user of wireless radios may be restricted in some places or situations, such as aboard airplanes. If you are unsure of restrictions, you are encouraged to ask for authorization before turning on the wireless radio. Several restrictions and cautions of using mobile phone are listed in the **Safety**.

FCC RF Exposure Information

Read this information before using your handset

In August 1996 the Federal Communication Commission (FCC) of the United States with its action in Report and Order FCC 96-326 adopted an updated safety standard for human exposure to radio frequency (RF) electromagnetic energy emitted by FCC regulated transmitters. Those guidelines are consistent with the safety standard previously set by both U.S and international standards bodies. The design of this phone complies with the FCC guidelines and these international standards.

Use only the supplied or an approved antenna. Unauthorized antennas, modifications, or attachments could impair call quality, damage the phone, or result in violation of FCC regulations.

Do not use the phone with a damaged antenna. If a damaged antenna comes into contact with the skin, a minor burn may result. Please contact your local dealer for replacement antenna.

Body-worn Operation

This device was tested for typical body-worn operations. To comply with FCC RF exposure requirements, a minimum separation distance of 1.5 cm must be maintained between the user's body and the handset, including the antenna. Third-party belt-clips, holsters, and similar accessories used by this device should not contain any metallic components. Body-worn accessories that do not meet these requirements may not comply with FCC RF exposure requirements and should be avoided.

For more information about RF exposure, please visit the FCC website at www.fcc.gov