


AVerMedia AW310 Smart Microphone Quick Guide

In the Box




Microphone



Receiver



Quick Guide



USB AC Adapter

English-1




USB Power Cable



3.5 mm to 6.3 mm
Audio Cable



Carrying Bag





Lanyard


English-2

Microphone


- 1 Battery LED
- 2 Power LED
- 3 Multi-function switch



English-3




- 4 Sound inlet (I/O)
- 5 USB power jack
- 6 Lanyard hole
- 7 Clip





English-4

Receiver




- 1 Power button
- 2 USB power jack
- 3 Power LED
- 4 3.5 mm mic. out jack



English-5

Installation



Note: To avoid excessive sound on initial sound test, lower your audio system volume first.


- 1 Connect the receiver to a power outlet.
- 2 Connect the receiver to a mic. input. Press the Power button.
- 3 Turn on the microphone and start using.*

* If both Power LEDs continue to flash, re-synchronize the microphone and receiver by pressing both power buttons simultaneously for 3 seconds and wait until the LEDs turn solid.

English-6

English-7

Charging



Flashing: Low Battery

Solid: Charging


Off: Fully Charged

Note: Fully charge your microphone before first use.

English-8

Pendant Form

- 1 Remove the clip.



- 2 Attach the lanyard.




- 3 Place it around your neck.




English-9

Clip Form

- 1 Rotate the clip.




- 2 Clip it on.




English-10

AVerMedia


Contenu de la Boîte




Microphone



Récepteur



Guide Utilisateur




Adaptateur USB AC

Français-1




Câble Alimentation USB



Câble Audio
3.5mm vers 6.3mm



Sac de Transport




Cordon

Français-2


www.avermedia.com

Microphone

- 1 Batterie LED
- 2 Alimentation LED
- 3 Switch multi fonction



Français-3



- 4 Tête de micro (I/O)
- 5 Jack alimentation USB
- 6 Trou cordon
- 7 Clip


Alimentation LED

Constant: On

Clignotant: Synchronisation

Français-4

Récepteur



- 1 Bouton alimentation
- 2 Jack alimentation USB
- 3 LED alimentation
- 4 Jack micro 3.5mm

Presser pour On/Off.
Presser et Appuyer 3 sec
pour synchroniser.


Alimentation LED

Constant: On

Clignotant: Synchronisation

Français-5

Installation




Remarque: pour éviter un volume sonore excessif lors de votre premier test de son, veuillez diminuer le son sur votre système audio.

- 1 Connecter le récepteur à une source d'alimentation.
- 2 Connecter le récepteur à une entrée micro. Appuyer sur le bouton marche.
- 3 Allumer le micro et commencer l'utilisation.*

* Si les deux LEDs d'alimentation continuent à clignoter, re-synchroniser le microphone et le récepteur en appuyant sur les 2 boutons d'alimentation simultanément pendant 3 secondes, et attendre que les LEDs arrêtent de clignoter.

Français-6

Mise en Charge



Batterie LED

Clignote: Batterie Faible

Constant: En Charge


Eteint: Entièrement chargé

Remarque: Charger complètement votre microphone avant la première utilisation.

Français-8

Pendentif

- 1 Enlever le clip.



- 2 Attacher le cordon.




- 3 Placer le autour du cou.




Français-9

Clip Form

- 1 Tourner le clip.



- 2 Accrocher-le à la veste.



Français-10

Disclaimer

All the screen shots in this documentation are only example images. The images may vary depending on the product and software version. Information presented in this documentation has been carefully checked for reliability; however, no responsibility is assumed for inaccuracies. The information contained in this documentation is subject to change without notice.

©2015 by AVerMedia Technologies, Inc. All rights reserved. No part of this publication, in whole or in part, may be reproduced, transmitted, transcribed, altered or translated into any language in any form by any means without the written permission of AVerMedia Technologies, Inc. Information and specification contained in this manual are subject to change without notice and do not represent a commitment on the part of AVerMedia.

For more information, please refer to www.avermedia.com. "AVerMedia" is a trademark or registered trademark of AVerMedia Technologies, Inc. The pictures contained in this manual are provided for reference purposes only. Made in Taiwan (Except Accessories).

US Office

Address: 47358 Fremont Blvd., Fremont, CA 94538
Website: www.avermedia-usa.com
Telephone: (408)-263-3828

Headquarters

Address: No 135, Jan 1st Rd., Zhonghe Dist.,
New Taipei City 23585, Taiwan
Website: www.avermedia.com
Telephone: 886-2-2226-3630

v1.0 03/2015

Do not attempt to disassemble or modify the battery pack. Attempting to do so can cause an explosion, or liquid leakage from the battery. The battery pack is covered by AVerMedia, or a disassembled or modified is not covered by the warranty.

If the rechargeable battery pack is incorrectly replaced, there is danger of an explosion. The battery pack contains a small amount of harmful substances. To avoid possible injury:

- Replace with a battery of the type recommended by AVerMedia.
- Keep the battery pack away from fire.
- Do not expose it to water or rain.
- Do not attempt to disassemble it.
- Do not short-circuit it.
- Keep it away from children.
- Do not drop the battery pack.
- Do not put the battery pack in trash that is disposed of in landfills. When disposing of the battery, comply with local ordinances or regulations.
- The battery pack should be stored at room temperature, charged to approximately 30 to 50% of capacity. We recommend that battery pack be charged about once per year to prevent over-discharge.

Limited Warranty

AVerMedia warrants that the Product is free from defects in material and/or workmanship under normal use.

AVerMedia does not warrant that the operation of the Product will be uninterrupted or error-free. The Limited Warranty does not cover:

- The warranty period has expired;
- Product that has (a) serial numbers or the warranty sticker that have been removed, tampered, damaged or altered, or (b) nonconforming;
- Product purchased from an unauthorized distributor;
- Product has been tested, altered, modified, repaired or serviced by someone other than

AVerMedia (or its authorized service centers);

- Failure to adhere to user's manual.

- Product that are operated in combination with third party's software which may be obtained by user or provided by AVerMedia in the product packaging.

- Product that are operated in combination with third party's device(s)/equipment(s), or the damage is caused from computer viruses

- Damage caused by (a) misuse, abuse, neglect, improper use of the physical or operating environment (such as the exterior ruptures, moisture, exposure to temperature, high or low humidity, power overload, placement subject to extreme environments that include a lack of ventilation or stacking, throwing, soaking, etc.) or modification; (b) improper or unauthorized installation, wiring, repair, testing; (c) use of the Product outside AVerMedia published guidelines; (d) accident, fire, acts of God or force majeure such as natural disasters, environmental distress, or lightning; power surges; (e) improper maintenance or failure to use the information contained in accordance with the Product.

- Other than the above, similar circumstances not attributable to AVerMedia.

Warranty Period

The term of the warranty begins from the date of purchase. Your dated sales receipt showing the date of purchase is the proof of purchase. The warranty period varies by product and is generally 1 or 2 years; consult your original AVerMedia product packaging or user information provided by AVerMedia and local in-country distributor at the time of purchase for the warranty term specific to your product ("Warranty Period").

How to Obtain Warranty Service – Contact Your Local In-Country Distributor

- To obtain warranty service, an original or copy of the sales receipt from the original retailer is required.

- A separate warranty may be provided by international distributors. This warranty is provided by the local in-country distributor and this distributor provides local service for your device. Distributor warranties are only valid in the area of intended distribution.

- When a Product or part is replaced, the replacement item becomes your property and the returned product or part becomes the property of AVerMedia or its distributor.

Usage of Personal Contact Information

If you obtain service under this warranty, you agree to and fully authorize AVerMedia or its distributor to store, use, and handle information related to the warranty service, as well as your personal contact information, including but not limited to your name, phone number, address, and email. AVerMedia or its distributor requires this information to perform the necessary service set forth by this warranty. For warranty service and outcome satisfaction, AVerMedia reserves the right to contact you in order to understand the problems that occur during usage of the product; the company may also notify you about any product recalls or safety issues.

To achieve satisfactory results, you agree to fully license AVerMedia to transfer his/her customer information to the country or region of the original purchase. This allows AVerMedia to undertake the scope of product or parts maintenance of the warranty service. AVerMedia may also disclose this information under certain legal requirements. How to provide Warranty Service

Services may vary by geographic region, please contact AVerMedia or its distributor for a response regarding the appropriate services for your Product. The Warranty Service may be provided by the following types.

a. Customer Delivery Service

According to "Customer Delivery Service," the customer must pay for their own product to be delivered to a designated service center for repair or replacement, and all risks are borne by the customer. The customer may retrieve the product after the repair or replacement process has been completed. Should the customer fail to collect the product, the company will handle the product as it sees fit without incurring any liability.

b. Mail-In Service

According to "Mail-In Service," customers will be required to pay for their own products to be mailed to a designated service center for repair or replacement, and all the risks are borne by the customer. After the product has been repaired or replaced, AVerMedia will send the product back to the customer at their own expense and bear all risks, except where otherwise specified by service dealers.

c. Customers' Two-Way Mail Service

According to "Customers' Two-Way Mail Service," customers will be required to pay for their own product to be delivered to a designated service center for repair or replacement, and all the risks are borne by the customer. After the product has been repaired or replaced, the product will be returned to the customer, for which all delivery and other risks are borne by the customer. If the customer fails to arrange for the return transport of the product, the company will handle the product as it sees fit without incurring any liability.

No On-Site Service

AVerMedia and its distributor do not provide on-site service, including but not limited to, installation, maintenance, instructing, troubleshooting problems, the usage of the product or the warranty service. In the event that calling, updating software,

or other means fail to resolve the issue, AVerMedia and its distributor will arrange warranty service as specified under "Scope of Warranty Services (a)."

Limitation of Liability

AVerMedia accepts responsibility for the damage of loss of products only under the following circumstances: when the company has a product in store or when a product is being transported by the company.

If any information contained in the product (including confidential information, proprietary information, or personal information) is missing or revealed, AVerMedia or its service dealers are without responsibility.

Under any circumstances, if the solutions proposed under the warranty have not fulfilled its basic purpose, AVerMedia, its subsidiaries, suppliers, and dealers do not assume any burden of liability: (a) loss, damage, or disclosure of client data; (b) special damages, incidental damages, punitive damages, or consequential damages, including but not limited to loss of profits, loss of business revenue, goodwill, or anticipated damage to balance loss, and even if the possibility has been raised, whether the claim is based on contract, warranty, negligence, strict liability, or other liability. Under the circumstances that AVerMedia, its subsidiaries, suppliers and distributors assumes responsibility for damages caused by any reason, the amount of its total liability shall not exceed the actual payable of direct damages, nor shall it exceed the amount paid by the customer for the product.

Prejudice to the foregoing restriction does not apply to personal injury or death caused by injury, nor does it apply to the compensation required by law for AVerMedia to assume with regards to real or tangible property. Where the law does not exclude or limit incidental or consequential damages, the above limitations or

exclusions may not apply to the customer.

Other Rights

This warranty provides the customer with specific legal rights. The customer may be subject to jurisdiction in accordance with the relevant laws in his or her district, but the customer is subject to the laws and regulations that govern the country or state where the product was originally purchased. This warranty does not affect any legal rights, including the limitations or exclusions laid out by this contract; instead, the control of the consumer goods sold is governed by the relevant laws or regulations born of consumer rights.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC NOTICE (Class B)

Federal Communications Commission Statement

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by tuning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/television technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

CE Class B

European Community Compliance Statement
This product is herewith confirmed to comply with the requirements set out in the Council Directives on the approximation of the laws of the Member States relating to R&TTE Directive 1999/5/EC, Low Voltage Directive (LVD) 2014/35/EU.