	Features	Pairing the Microphone	Using the Microphone
	 3 Hour Playtime Built-In 3w Speaker Built-In Media Controls TF and Micro SD Memory Card Support (up to 16GB) 	 Bluetooth Pairing Press and hold the Power button to start pairing your device. Once the device is ON you will hear "It's Karaoke Time!", and the Light Indicator will illuminate a solid blue light. Open your smartphone's Bluetooth menu to enable Bluetooth and search for 	Power On/Off Press and hold the Power button to turn the microphone ON. You will hear "It's Karaoke Time!". Press and hold the Power button to turn OFF. Adjusting Volume
Wireless Karaoke Microphone	Contents - 1 Wireless Microphone - Micro-USB Charging Cable - User Manual with Warranty Information	 Bluetooth devices. Select "ISK101" from the list of devices. After successfully pairing, you will hear "Let's Sing!" from the microphone and the blue light will turn solid. Note: If a previously paired device is in range while the microphone is ON, the speaker will connect to it automatically. 	Press and hold down the Volume - button to decrease the speaker volume. Press and hold down the Volume + button to increase the speaker volume. Alternatively, you can adjust the volume using the Mic Volume slider, push up to increase the microphone volume or push down to decrease. Adjusting Echo Push the Echo slider up to increase echo effect and push down to decrease.
	A Quick Look Microphone Controls and Ports Volume Power/Play/ Pause/Remove Music Volume +/- Next Track Volume -/Previous Track	ISK101	Switching Modes To enter memory card mode, insert an SD card into the TF memory card slot. You will hear "Memory Card Mode". To enter USB mode, insert a USB into the USB port. You will hear "USB Mode". Music Control To play or pause the music press the Play/Pause button. To change the music track, press the Next Track button to change to the next track on a playlist or press the Previous Track button to change to the previous track. Remove Music To mute the vocals from the microphone, press the Power button twice. You will hear "Music Removed" once the vocals have been removed. Voice Changer Press and hold the Mode Button to switch between 5 different voice settings.
User Manual ISK101	 Charging the Microphone To charge the microphone, attach the small end of the micro-USB charging cable (included) to the charging port located at the bottom of the microphone. Attach the other end to a USB power port on a computer or USB charging adapter. A RED light will turn ON while the microphone is charging, and will turn OFF once charging is complete. 	TWS Pairing To connect two ISK101 Karaoke Microphones together, turn ON both microphones at the same time, then quickly double press the Mode button. The two microphones will automatically find each other and connect. When the connection is successful, you will hear "beep". After the microphones are paired to each other, connect to your Bluetooth-enabled device. **Note - make sure your microphone is not connected to Bluetooth before enter TWS pairing mode.	Using the USB Port and Memory Card Slot Your microphone comes with a USB Port and a TF Memory Card Slot. - When a USB thumb drive or jump drive is inserted into the USB Port, your microphone will play any .MP3, .WMA, or .WAV music file stored on the drive. - When a TF card is inserted into the TF Card Slot, your microphone will play any .MP3 music file stored on the card.

Safety Precautions	FCC Statement	One Year Warranty	
 When using your microphone, basic safety precautions should always be followed including: 1. READ ALL INSTRUCTIONS BEFORE USING YOUR MICROPHONE. 2. Do not submerge microphone in water. Do not place microphone on wet surfaces. 3. Only clean using a clean, soft cloth. 4. Do not allow children to play with this product. This product contains small pieces that can be a choking hazard. Parental supervision is advised. 5. Do not expose product to excessive heat or fire. 6. Do not expose product to extreme cold or hot temperatures to avoid battery damage. 7. Do not attempt to repair this product yourself. Contact a qualified service center if the product is in need of service. 8. Do not drop, crush, or expose this product with water, as electric shock may occur. 10. Unplug charging cable when not in use or during thunderstorms. 	This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particula r installation. If this equipment does cause harmful interference to radio or t elevision reception, which can be determined by turning the equipment off a nd on, the user is encouraged to try to correct the interference by one or mo re of the following measures: -Reorient or relocate the receiving antenna. -Increase the separation between the equipment and receiver. -Connet the equipment into an outlet on a circuit different from that to which the receiver is connected. -Consult the dealer or an experienced radio/TV technician for help. To assure continued compliance, any changes or modifications not expressly approved by the party.Responsible for compliance could void the user's authority to operate this equipment. This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device may not cause harmful interference, including interference that may cause undesired operation. FCC Radiation Exposure Statement: The device has been evaluated to meet general RF exposure requirement.	 This warranty covers the original consumer purchaser only and is not transferable. This warranty covers products that fail to function properly UNDER NORMAL USAGE, due to defects in material or workmanship. Your product will be repaired or replaced at no charge for parts or labor for a period of one year. What Is Not Covered by Warranty Damages or malfunctions not resulting from defects in material or workmanship and damages or malfunctions from other than normal use, including but limited to, repair by unauthorized parties, tampering, modification or accident. To Obtain Warranty Service and Troubleshooting Information: Call 1-800-592-9541 or visit our website at www.vivitar.com. To receive Warranty service along with the name and address of an authorized product service center, the original consumer purchaser must contact us for problem determination and service procedures. Proof of purchase in the form of a bill of sale or receipted involce, evidencing that the product is within the applicable Warranty period(s), MUST be presented in order to obtain the requested service. It is your responsibility to properly package and send any defective product. Any products received by the authorized service center at your expense. Do not include any other items or a cacesories with the defective product. Any products received by the authorized service center that are not covered by warranty will be returned unrepaired. For Consumers in Australia Only Faulty product should be returned to point of sale, requiring proof of purchase for a refund or exchange. Our goods come with guarantees that cannot be excluded under the 	vivitar ISING
Specifications	The device can ben used in the portable exposure condition with restiction.	Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss	
USB/Memory Card Support: MAX 16GB USB Output: 3W Battery Capacity: 3.7V ==1200mAh Charging Time: Approximately 2-3 Hours Play Time: Approximately 3 Hours* Charging Cable: Micro-USB Power Supply: Li-ion battery Bluetooth Version: 5.3		or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. For all Technical Support in Australia please dial 1-800-006-614	© 2023 Sakar International 195 Carter Drive Edison, NJ 08817 Support: 800 592 9541 www.vivitar.com